

ETSI TS 124 008 V13.7.0 (2016-10)



**Digital cellular telecommunications system (Phase 2+) (GSM);
Universal Mobile Telecommunications System (UMTS);
LTE;
Mobile radio interface Layer 3 specification;
Core network protocols;
Stage 3
(3GPP TS 24.008 version 13.7.0 Release 13)**



Reference

RTS/TSGC-0124008vd70

Keywords

GSM,LTE,UMTS

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

The present document can be downloaded from:
<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the only prevailing document is the print of the Portable Document Format (PDF) version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.
Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:
<https://portal.etsi.org/People/CommitteeSupportStaff.aspx>

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.
The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2016.
All rights reserved.

DECT™, PLUGTESTS™, UMTS™ and the ETSI logo are Trade Marks of ETSI registered for the benefit of its Members.
3GPP™ and **LTE™** are Trade Marks of ETSI registered for the benefit of its Members and
of the 3GPP Organizational Partners.
GSM® and the GSM logo are Trade Marks registered and owned by the GSM Association.

Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Foreword

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under
<http://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are NOT allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Foreword.....	2
Modal verbs terminology.....	2
Foreword.....	28
Introduction	28
1 Scope	29
1.1 Scope of the Technical Specification	29
1.2 Application to the interface structures.....	29
1.3 Structure of layer 3 procedures.....	29
1.4 Test procedures	30
1.5 Use of logical channels in A/Gb mode.....	30
1.6 Overview of control procedures	30
1.6.1 List of procedures	30
1.7 Applicability of implementations	32
1.7.1 Voice Group Call Service (VGCS) and Voice Broadcast Service (VBS).....	32
1.7.2 General Packet Radio Service (GPRS).....	32
1.7.2.1 Packet services in GSM (A/Gb mode only)	32
1.7.2.2 Packet services in Iu mode (Iu mode only)	33
1.8 Handling of NAS signalling low priority indication	33
1.9 Restrictions.....	34
2 References	34
2.1 Definitions and abbreviations.....	40
2.1.1 Random values.....	41
2.1.2 Vocabulary.....	41
3 Radio Resource management procedures.....	46
4 Elementary procedures for Mobility Management.....	46
4.1 General	46
4.1.1 MM and GMM procedures	47
4.1.1.1 Types of MM and GMM procedures	47
4.1.1.1.1 Integrity Checking of Signalling Messages in the Mobile Station (Iu mode only).....	48
4.1.1.1.2 Integrity protection for emergency call (Iu mode only).....	50
4.1.1.2 MM-GMM co-ordination for GPRS MS's	50
4.1.1.2.1 GPRS MS operating in mode A or B in a network that operates in mode I	50
4.1.1.2.2 GPRS MS operating in mode A or B in a network that operates in mode II	52
4.1.1.2A Coordination between GMM and EMM	52
4.1.1.3 Core Network System Information for MM (Iu mode only)	52
4.1.1.4 Core Network System Information for GMM (Iu mode only)	52
4.1.1.4.1 General	52
4.1.1.4.2 Control of Network Mode of Operation I.....	53
4.1.1.5 Access class control	53
4.1.1.6 Specific requirements for MS configured to use timer T3245	53
4.1.1.6A Specific requirements for the MS when receiving non-integrity protected reject messages	54
4.1.1.7 Handling of NAS level mobility management congestion control.....	58
4.1.1.8 Handling of security related parameters at switch on and switch off	59
4.1.1.9 Equivalent PLMNs list	59
4.1.1.10 Dedicated core network.....	60
4.1.2 MM sublayer states.....	60
4.1.2.1 MM sublayer states in the mobile station	60
4.1.2.1.1 Main states.....	60
4.1.2.1.2 Substates of the MM IDLE state	64
4.1.2.2 The update Status	66
4.1.2.3 MM sublayer states on the network side	66
4.1.3 GPRS mobility management (GMM) sublayer states.....	68

4.1.3.1	GMM states in the MS	68
4.1.3.1.1	Main states.....	68
4.1.3.1.2	Substates of state GMM-DEREGISTERED.....	69
4.1.3.1.3	Substates of state GMM-REGISTERED.....	69
4.1.3.2	GPRS update status	72
4.1.3.3	GMM mobility management states on the network side	72
4.1.3.3.1	Main States	73
4.1.3.3.2	Substates of state GMM-REGISTERED	73
4.2	Behaviour of the MS in MM Idle state, GMM-DEREGISTERED state and GMM-REGISTERED state	74
4.2.1	Primary Service State selection	74
4.2.1.1	Selection of the Service State after Power On.....	74
4.2.1.2	Other Cases	75
4.2.2	Detailed Description of the MS behaviour in MM IDLE State.	75
4.2.2.1	Service State, NORMAL SERVICE	75
4.2.2.2	Service State, ATTEMPTING TO UPDATE	76
4.2.2.3	Service State, LIMITED SERVICE	76
4.2.2.4	Service State, NO IMSI.....	77
4.2.2.5	Service State, SEARCH FOR PLMN, NORMAL SERVICE.....	77
4.2.2.6	Service State, SEARCH FOR PLMN	78
4.2.2.7	Service State, RECEIVING GROUP CALL (NORMAL SERVICE)	78
4.2.2.8	Service State, RECEIVING GROUP CALL (LIMITED SERVICE)	78
4.2.2.9	Service State, eCALL INACTIVE.....	79
4.2.3	Service state when back to state MM IDLE from another state.....	79
4.2.4	Behaviour in state GMM-DEREGISTERED.....	80
4.2.4.1	Primary substate selection.....	80
4.2.4.1.1	Selection of the substate after power on or enabling the MS's GPRS capability.....	80
4.2.4.1.2	Other Cases.....	81
4.2.4.2	Detailed description of the MS behaviour in state GMM-DEREGISTERED.....	81
4.2.4.2.1	Substate, NORMAL-SERVICE	81
4.2.4.2.2	Substate, ATTEMPTING-TO-ATTACH	81
4.2.4.2.3	Substate, LIMITED-SERVICE	82
4.2.4.2.4	Substate, NO-IMSI	82
4.2.4.2.5	Substate, NO-CELL	82
4.2.4.2.6	Substate, PLMN-SEARCH	82
4.2.4.2.7	Substate, ATTACH-NEEDED	82
4.2.4.2.8	Substate, SUSPENDED (A/Gb mode only)	82
4.2.4.3	Substate when back to state GMM-DEREGISTERED from another GMM state	82
4.2.5	Behaviour in state GMM-REGISTERED.....	83
4.2.5.1	Detailed description of the MS behaviour in state GMM-REGISTERED.....	83
4.2.5.1.1	Substate, NORMAL-SERVICE	83
4.2.5.1.2	Substate, SUSPENDED (A/Gb mode only)	83
4.2.5.1.3	Substate, UPDATE-NEEDED.....	84
4.2.5.1.4	Substate, ATTEMPTING-TO-UPDATE	84
4.2.5.1.5	Substate, NO-CELL-AVAILABLE	84
4.2.5.1.6	Substate, LIMITED-SERVICE	84
4.2.5.1.7	Substate, ATTEMPTING-TO-UPDATE-MM	85
4.2.5.1.8	Substate, PLMN-SEARCH	85
4.3	MM common procedures	85
4.3.1	TMSI reallocation procedure	85
4.3.1.1	TMSI reallocation initiation by the network	86
4.3.1.2	TMSI reallocation completion by the mobile station	86
4.3.1.3	TMSI reallocation completion in the network.....	86
4.3.1.4	Abnormal cases in the mobile station.....	86
4.3.1.5	Abnormal cases on the network side.....	86
4.3.2	Authentication procedure.....	87
4.3.2a	Authentication procedure used for a UMTS authentication challenge.....	87
4.3.2b	Authentication Procedure used for a GSM authentication challenge	87
4.3.2.1	Authentication request by the network.....	88
4.3.2.2	Authentication response by the mobile station.....	88
4.3.2.3	Authentication processing in the network.....	89
4.3.2.3a	128-bit circuit-switched GSM ciphering key	89
4.3.2.4	Ciphering key sequence number	89

4.3.2.5	Authentication not accepted by the network	90
4.3.2.5.1	Authentication not accepted by the MS	91
4.3.2.6	Abnormal cases	91
4.3.2.6.1	MS behaviour towards a network that has failed the authentication procedure.....	94
4.3.2.7	Handling of keys at intersystem change from Iu mode to A/Gb mode	94
4.3.2.7a	Use of established security contexts.....	95
4.3.2.8	Handling of keys at intersystem change from A/Gb mode to Iu mode	96
4.3.2.9	Void.....	97
4.3.2.10	Derivation of keys at SRVCC or vSRVCC handover from S1 mode	97
4.3.2.10.0	General	97
4.3.2.10.1	PDN connection with integrity protection	97
4.3.2.10.2	PDN connection without integrity protection.....	97
4.3.2.11	Derivation of keys at SRVCC handover from Iu mode to Iu mode	97
4.3.2.11.1	PDN connection with integrity protection	97
4.3.2.11.2	PDN connection without integrity protection.....	98
4.3.2.12	Derivation of keys at SRVCC handover from Iu mode to A/Gb mode.....	99
4.3.2.12.1	PDN connection with integrity protection	99
4.3.2.12.2	PDN connection without integrity protection.....	100
4.3.2.13	Derivation of keys at CS to PS SRVCC handover from A/Gb mode to Iu mode	100
4.3.3	Identification procedure.....	102
4.3.3.1	Identity request by the network	102
4.3.3.2	Identification response by the mobile station.....	102
4.3.3.3	Abnormal cases	102
4.3.4	IMSI detach procedure.....	103
4.3.4.0	General	103
4.3.4.1	IMSI detach initiation by the mobile station	103
4.3.4.2	IMSI detach procedure in the network	104
4.3.4.3	IMSI detach completion by the mobile station.....	104
4.3.4.4	Abnormal cases	104
4.3.5	Abort procedure	104
4.3.5.1	Abort procedure initiation by the network	104
4.3.5.2	Abort procedure in the mobile station.....	105
4.3.6	MM information procedure.....	105
4.3.6.1	MM information procedure initiation by the network	105
4.3.6.2	MM information procedure in the mobile station	105
4.4	MM specific procedures	105
4.4.1	Location updating procedure	105
4.4.2	Periodic updating	107
4.4.3	IMSI attach procedure	108
4.4.4	Generic Location Updating procedure	109
4.4.4.1	Location updating initiation by the mobile station.....	109
4.4.4.1a	Network Request for Additional mobile station Capability Information	109
4.4.4.2	Identification request from the network	109
4.4.4.3	Authentication by the network	109
4.4.4.4	Security mode setting by the network	109
4.4.4.5	Location Update Attempt Counter	109
4.4.4.6	Location updating accepted by the network	110
4.4.4.7	Location updating not accepted by the network	112
4.4.4.8	Release of RR connection after location updating	114
4.4.4.9	Abnormal cases on the mobile station side	114
4.4.4.10	Abnormal cases on the network side	116
4.4.5	Void	116
4.4.6	Void	116
4.4.7	eCall inactivity procedure	116
4.5	Connection management sublayer service provision	117
4.5.1	MM connection establishment	117
4.5.1.1	MM connection establishment initiated by the mobile station.....	117
4.5.1.2	Abnormal cases	121
4.5.1.3	MM connection establishment initiated by the network	122
4.5.1.3.1	Mobile Terminating CM Activity.....	122
4.5.1.3.2	Mobile Originating CM Activity \$(CCBS)\$	123
4.5.1.3.3	Paging response in Iu mode (Iu mode only)	124

4.5.1.3.4	Paging response for CS fallback.....	124
4.5.1.4	Abnormal cases	125
4.5.1.5	MM connection establishment for emergency calls.....	125
4.5.1.5a	MM connection establishment for emergency calls for CS fallback.....	126
4.5.1.6	Call re-establishment.....	126
4.5.1.6.1	Call re-establishment, initiation by the mobile station	126
4.5.1.6.2	Abnormal cases	128
4.5.1.7	Forced release during MO MM connection establishment	129
4.5.1.8	MM connection establishment due to SRVCC or vSRVCC handover	129
4.5.2	MM connection information transfer phase.....	130
4.5.2.1	Sending CM messages	130
4.5.2.2	Receiving CM messages	130
4.5.2.3	Abnormal cases	130
4.5.3	MM connection release.....	130
4.5.3.1	Release of associated RR connection	131
4.5.3.2	Uplink release in a voice group call	131
4.6	Receiving a MM STATUS message by a MM entity.....	131
4.7	Elementary mobility management procedures for GPRS services	131
4.7.1	General.....	131
4.7.1.1	Lower layer failure.....	131
4.7.1.2	Ciphering of messages (A/Gb mode only)	132
4.7.1.2a	Integrity protection of layer 3 signalling messages (A/Gb mode only and when integrity protection is required)	132
4.7.1.2a.1	General	132
4.7.1.2a.2	Integrity checking of GMM signalling messages in the MS	132
4.7.1.2a.3	Integrity checking of layer 3 signalling messages in the network	133
4.7.1.2a.4	Establishment of integrity protection of layer 3 signalling messages.....	134
4.7.1.2a.5	Optional establishment of integrity protection in the user plane	134
4.7.1.2a.6	Change of security keys.....	134
4.7.1.3	P-TMSI signature	135
4.7.1.4	Radio resource sublayer address handling	135
4.7.1.4.1	Radio resource sublayer address handling (A/Gb mode only)	135
4.7.1.5	P-TMSI handling.....	136
4.7.1.5.1	P-TMSI handling in A/Gb mode	136
4.7.1.5.2	P-TMSI handling in Iu mode	137
4.7.1.5.3	Void.....	137
4.7.1.5.4	Void.....	137
4.7.1.6	Change of network mode of operation	137
4.7.1.6.1	Change of network mode of operation in A/Gb mode (A/Gb mode only)	137
4.7.1.6.2	Change of network mode of operation in Iu mode (Iu mode only)	138
4.7.1.6.3	Change of network mode of operation at Iu mode to A/Gb mode inter-system change	138
4.7.1.6.4	Change of network mode of operation at A/Gb mode to Iu mode inter-system change	139
4.7.1.7	Intersystem change between A/Gb mode and Iu mode	139
4.7.1.7a	Intersystem change from S1 mode to A/Gb mode or S1 mode to Iu mode with ISR activated	140
4.7.1.8	List of forbidden PLMNs for GPRS service	141
4.7.1.8a	Establishment of the PS signalling connection (Iu mode only).....	141
4.7.1.9	Release of the PS signalling connection (Iu mode only).....	142
4.7.2	GPRS Mobility management timers and UMTS PS signalling connection control.....	142
4.7.2.1	READY timer behaviour.....	142
4.7.2.1.1	READY timer behaviour (A/Gb mode only).....	142
4.7.2.1.2	Handling of READY timer in the MS in Iu mode and S1 mode	144
4.7.2.1.2a	Handling of READY timer in the network in Iu mode and S1 mode	144
4.7.2.2	Periodic routing area updating	144
4.7.2.3	PMM-IDLE mode and PMM-CONNECTED mode (Iu mode only)	146
4.7.2.4	Handling of <i>Force to standby</i> in Iu mode (Iu mode only).....	147
4.7.2.5	RA Update procedure for Signalling Connection Re-establishment (Iu mode only)	147
4.7.2.6	Cell Update triggered by low layers.....	147
4.7.2.7	Handling of timer T3302.....	147
4.7.2.8	Handling of timer T3324 (A/Gb mode, Iu mode and S1 mode).....	147
4.7.2.9	Power saving mode	148
4.7.2.10	Extended idle-mode DRX cycle.....	149
4.7.2.11	Interaction between power saving mode and extended idle mode DRX cycle	149

4.7.2.12	Extended coverage for GSM	150
4.7.3	GPRS attach procedure	150
4.7.3.1	GPRS attach procedure for GPRS services	152
4.7.3.1.1	GPRS attach procedure initiation	152
4.7.3.1.2	GMM common procedure initiation	153
4.7.3.1.3	GPRS attach accepted by the network	153
4.7.3.1.4	GPRS attach not accepted by the network	157
4.7.3.1.4a	GPRS attach for emergency bearer services not accepted by the network (UTRAN Iu mode only)	161
4.7.3.1.4b	Attach for initiating a PDN connection for emergency bearer services not accepted by the network (UTRAN Iu mode only)	162
4.7.3.1.5	Abnormal cases in the MS	162
4.7.3.1.6	Abnormal cases on the network side	165
4.7.3.2	Combined GPRS attach procedure for GPRS and non-GPRS services	166
4.7.3.2.1	Combined GPRS attach procedure initiation	167
4.7.3.2.2	GMM Common procedure initiation	167
4.7.3.2.3	Combined GPRS attach accepted by the network	167
4.7.3.2.4	Combined GPRS attach not accepted by the network	169
4.7.3.2.5	Abnormal cases in the MS	173
4.7.3.2.6	Abnormal cases on the network side	174
4.7.4	GPRS detach procedure	174
4.7.4.0	General	174
4.7.4.1	MS initiated GPRS detach procedure	175
4.7.4.1.1	MS initiated GPRS detach procedure initiation	175
4.7.4.1.2	MS initiated GPRS detach procedure completion for GPRS services only	175
4.7.4.1.3	MS initiated combined GPRS detach procedure completion	175
4.7.4.1.4	Abnormal cases in the MS	176
4.7.4.1.5	Abnormal cases on the network side	178
4.7.4.2	Network initiated GPRS detach procedure	178
4.7.4.2.1	Network initiated GPRS detach procedure initiation	178
4.7.4.2.2	Network initiated GPRS detach procedure completion by the MS	178
4.7.4.2.3	Network initiated GPRS detach procedure completion by the network	183
4.7.4.2.4	Abnormal cases on the network side	183
4.7.5	Routing area updating procedure	184
4.7.5.1	Normal and periodic routing area updating procedure	186
4.7.5.1.1	Normal and periodic routing area updating procedure initiation	188
4.7.5.1.2	GMM Common procedure initiation	189
4.7.5.1.3	Normal and periodic routing area updating procedure accepted by the network	189
4.7.5.1.4	Normal and periodic routing area updating procedure not accepted by the network	195
4.7.5.1.4a	Routing area updating procedure for initiating a PDN connection for emergency bearer services not accepted by the network (UTRAN Iu mode only)	201
4.7.5.1.5	Abnormal cases in the MS	201
4.7.5.1.6	Abnormal cases on the network side	205
4.7.5.2	Combined routing area updating procedure	207
4.7.5.2.0	General	207
4.7.5.2.1	Combined routing area updating procedure initiation	207
4.7.5.2.2	GMM Common procedure initiation	209
4.7.5.2.3	Combined routing area updating procedure accepted by the network	209
4.7.5.2.4	Combined routing area updating not accepted by the network	211
4.7.5.2.5	Abnormal cases in the MS	216
4.7.5.2.6	Abnormal cases on the network side	217
4.7.6	P-TMSI reallocation procedure	217
4.7.6.0	General	217
4.7.6.1	P-TMSI reallocation initiation by the network	217
4.7.6.2	P-TMSI reallocation completion by the MS	217
4.7.6.3	P-TMSI reallocation completion by the network	217
4.7.6.3A	Abnormal cases in the MS	218
4.7.6.4	Abnormal cases on the network side	218
4.7.7	Authentication and ciphering procedure	219
4.7.7a	Authentication and ciphering procedure used for UMTS authentication challenge	219
4.7.7b	Authentication and ciphering procedure used for GSM authentication challenge	220
4.7.7c	Change of the ciphering algorithm at PS Handover	220

4.7.7.1	Authentication and ciphering initiation by the network	221
4.7.7.2	Authentication and ciphering response by the MS.....	222
4.7.7.3	Authentication and ciphering completion by the network.....	224
4.7.7.3a	128-bit packet-switched GSM ciphering key	225
4.7.7.3b	128-bit packet-switched GSM integrity key (in A/Gb mode and only if MS supports integrity protection)	225
4.7.7.4	GPRS ciphering key sequence number	226
4.7.7.5	Authentication not accepted by the network	227
4.7.7.5.1	Authentication not accepted by the MS	228
4.7.7.6	Abnormal cases	228
4.7.7.6.1	MS behaviour towards a network that has failed the authentication procedure.....	232
4.7.7.7	Use of established security contexts.....	233
4.7.7.8	Handling of keys at intersystem change from Iu mode to A/Gb mode	234
4.7.7.9	Handling of keys at intersystem change from A/Gb mode to Iu mode	234
4.7.7.10	Handling of keys at intersystem change from S1 mode to Iu mode or A/Gb mode	235
4.7.8	Identification procedure	237
4.7.8.1	Identification initiation by the network	237
4.7.8.2	Identification response by the MS.....	237
4.7.8.3	Identification completion by the network	237
4.7.8.3a	Abnormal cases in the MS	237
4.7.8.4	Abnormal cases on the network side.....	238
4.7.9	Paging procedure	239
4.7.9.1	Paging for GPRS services	239
4.7.9.1.1	Paging for GPRS services using P-TMSI.....	239
4.7.9.1.2	Paging for GPRS services using IMSI.....	240
4.7.9.2	Paging for non-GPRS services.....	241
4.7.10	Receiving a GMM STATUS message by a GMM entity	241
4.7.11	Void	241
4.7.12	GMM Information procedure	241
4.7.12.1	GMM information procedure initiation by the network.....	241
4.7.12.2	GMM information procedure in the mobile station	241
4.7.13	Service Request procedure (Iu mode only).....	241
4.7.13.1	Service Request procedure initiation.....	243
4.7.13.2	GMM common procedure initiation	244
4.7.13.3	Service request procedure accepted by the network.....	244
4.7.13.4	Service request procedure not accepted by the network.....	245
4.7.13.4a	Service request procedure for initiating a PDN connection for emergency bearer services not accepted by the network (UTRAN Iu mode only)	249
4.7.13.5	Abnormal cases in the MS	250
4.7.13.6	Abnormal cases on the network side.....	252
4.7.14	Void	253
5	Elementary procedures for circuit-switched Call Control.....	253
5.1	Overview	253
5.1.1	General.....	253
5.1.2	Call Control States	261
5.1.2.1	Call states at the mobile station side of the interface	261
5.1.2.1.1	Null (State U0)	261
5.1.2.1.2	MM Connection pending (U0.1)	261
5.1.2.1.2a	CC prompt present (U0.2) \$(CCBS)\$	261
5.1.2.1.2b	Wait for network information (U0.3) \$(CCBS)\$.....	261
5.1.2.1.2c	CC-Establishment present (U0.4) \$(CCBS)\$.....	261
5.1.2.1.2d	CC-Establishment confirmed (U0.5) \$(CCBS)\$.....	262
5.1.2.1.2e	Recall present (U0.6) \$(CCBS)\$	262
5.1.2.1.3	Call initiated (U1).....	262
5.1.2.1.4	Mobile originating call proceeding (U3)	262
5.1.2.1.5	Call delivered (U4)	262
5.1.2.1.6	Call present (U6)	262
5.1.2.1.7	Call received (U7)	262
5.1.2.1.8	Connect Request (U8)	262
5.1.2.1.9	Mobile terminating call confirmed (U9).....	262
5.1.2.1.10	Active (U10).....	262

5.1.2.1.11	Disconnect request (U11)	262
5.1.2.1.12	Disconnect indication (U12).....	263
5.1.2.1.13	Release request (U19).....	263
5.1.2.1.14	Mobile originating modify (U26)	263
5.1.2.1.15	Mobile terminating modify (U27)	263
5.1.2.2	Network call states	263
5.1.2.2.1	Null (State N0)	263
5.1.2.2.2	MM connection pending (N0.1)	263
5.1.2.2.2a	CC connection pending (N0.2) \$(CCBS)\$	263
5.1.2.2.2b	Network answer pending (N0.3) \$(CCBS)\$.....	263
5.1.2.2.2c	CC-Establishment present (N0.4) \$(CCBS)\$.....	263
5.1.2.2.2d	CC-Establishment confirmed (N0.5) \$(CCBS)\$.....	263
5.1.2.2.2e	Recall present (N0.6) \$(CCBS)\$	263
5.1.2.2.3	Call initiated (N1).....	264
5.1.2.2.4	Mobile originating call proceeding (N3)	264
5.1.2.2.5	Call delivered (N4)	264
5.1.2.2.6	Call present (N6)	264
5.1.2.2.7	Call received (N7)	264
5.1.2.2.8	Connect request (N8).....	264
5.1.2.2.9	Mobile terminating call confirmed (N9).....	264
5.1.2.2.10	Active (N10).....	264
5.1.2.2.11	Not used.....	264
5.1.2.2.12	Disconnect indication (N12).....	264
5.1.2.2.13	Release request (N19).....	264
5.1.2.2.14	Mobile originating modify (N26)	264
5.1.2.2.15	Mobile terminating modify (N27)	265
5.1.2.2.16	Connect Indication (N28)	265
5.2	Call establishment procedures	265
5.2.1	Mobile originating call establishment.....	265
5.2.1.1	Call initiation.....	266
5.2.1.2	Receipt of a setup message	266
5.2.1.3	Receipt of a CALL PROCEEDING message	268
5.2.1.4	Notification of progressing mobile originated call.....	268
5.2.1.4.1	Notification of interworking in connection with mobile originated call establishment.....	269
5.2.1.4.2	Call progress in the PLMN/ISDN environment	269
5.2.1.5	Alerting	269
5.2.1.6	Call connected.....	270
5.2.1.7	Call rejection	271
5.2.1.8	Transit network selection	271
5.2.1.9	Traffic channel assignment at mobile originating call establishment	271
5.2.1.10	Call queuing at mobile originating call establishment	271
5.2.1.11	Speech Codec Selection	271
5.2.1.12	Cellular Text telephone Modem (CTM) selection	272
5.2.2	Mobile terminating call establishment.....	273
5.2.2.1	Call indication	273
5.2.2.2	Compatibility checking	273
5.2.2.3	Call confirmation	273
5.2.2.3.1	Response to SETUP	273
5.2.2.3.2	Receipt of CALL CONFIRMED and ALERTING by the network	274
5.2.2.3.3	Call failure procedures	275
5.2.2.3.4	Called mobile station clearing during mobile terminating call establishment	275
5.2.2.4	Notification of interworking in connection with mobile terminating call establishment	275
5.2.2.5	Call accept.....	276
5.2.2.6	Active indication	276
5.2.2.7	Traffic channel assignment at mobile terminating call establishment.....	276
5.2.2.8	Call queuing at mobile terminating call establishment	277
5.2.2.9	User connection attachment during a mobile terminating call	277
5.2.2.10	Speech Codec Selection	277
5.2.2.11	Cellular Text telephone Modem (CTM) selection	277
5.2.3	Network initiated MO call \$(CCBS)\$	277
5.2.3.1	Initiation.....	277
5.2.3.2	CC-Establishment present	278

5.2.3.2.1	Recall Alignment Procedure.....	279
5.2.3.3	CC-Establishment confirmation.....	280
5.2.3.4	Recall present.....	280
5.2.3.5	Traffic channel assignment during network initiated mobile originating call establishment.....	281
5.2.4	Call establishment for SRVCC or vSRVCC.....	281
5.2.4.1	General.....	281
5.2.4.2	Call activation for SRVCC.....	281
5.2.4.2a	Call activation for vSRVCC.....	282
5.2.4.2b	Multimedia CAT and vSRVCC handover.....	283
5.2.4.3	Traffic channel assignment and user connection attachment	283
5.2.4.4	State verification	284
5.3	Signalling procedures during the "active" state.....	284
5.3.1	User notification procedure.....	284
5.3.2	Call rearrangements	284
5.3.3	Codec Change Procedure.....	284
5.3.4	Support of Dual Services	284
5.3.4.1	Service Description	284
5.3.4.2	Call establishment	285
5.3.4.2.1	Mobile Originating Establishment.....	285
5.3.4.2.2	Mobile Terminating Establishment	286
5.3.4.3	Changing the Call Mode	286
5.3.4.3.1	Initiation of in-call modification.....	286
5.3.4.3.2	Successful completion of in-call modification	287
5.3.4.3.3	Change of the channel configuration.....	288
5.3.4.3.4	Failure of in-call modification.....	288
5.3.4.4	Abnormal procedures	288
5.3.5	User initiated service level up- and downgrading (A/Gb mode and GERAN Iu mode only)	289
5.3.5.1	Initiation of service level up- and downgrading	289
5.3.5.2	Successful completion of service level up- and downgrading	289
5.3.5.3	Rejection of service level up- and downgrading	290
5.3.5.4	Time-out recovery	290
5.3.6	Support of multimedia calls	290
5.3.6.1	Service description	290
5.3.6.2	Call establishment	290
5.3.6.2.1	Mobile originated multimedia call establishment.....	290
5.3.6.2.2	Mobile terminating multimedia call	291
5.3.6.2.2.1	Fallback to speech.....	292
5.3.6.3	In-call modification in the "active" state	292
5.3.6.3.1	Void.....	293
5.3.6.3.2	Void.....	293
5.3.6.3.3	Void.....	293
5.3.6.4	Multimedia CAT during the alerting phase of a mobile originated call.....	293
5.3.6.5	DTMF transmission during a multimedia call	294
5.3.6.6	vSRVCC handover to a circuit-switched multimedia call.....	294
5.4	Call clearing	294
5.4.1	Terminology	294
5.4.2	Exception conditions.....	294
5.4.3	Clearing initiated by the mobile station	295
5.4.3.1	Initiation of call clearing	295
5.4.3.2	Receipt of a DISCONNECT message from the mobile station.....	295
5.4.3.3	Receipt of a RELEASE message from the network	295
5.4.3.4	Receipt of a RELEASE COMPLETE message from the mobile station	295
5.4.3.5	Abnormal cases	295
5.4.4	Clearing initiated by the network.....	296
5.4.4.1	Clearing initiated by the network: mobile does not support "Prolonged Clearing Procedure"	296
5.4.4.1.1	Clearing when tones/announcements provided	296
5.4.4.1.2	Clearing when tones/announcements not provided	296
5.4.4.1.3	Completion of clearing	297
5.4.4.2	Clearing initiated by the network: mobile supports "Prolonged Clearing Procedure"	297
5.4.4.2.1	Clearing when tones/announcements provided and the network does not indicate that "CCBS activation is possible"	297
5.4.4.2.2	Clearing when the network indicates that "CCBS activation is possible"	298

5.4.4.2.3	Clearing when tones/announcements are not provided and the network does not indicate that "CCBS activation is possible"	299
5.4.4.2.4	Receipt of a RELEASE message from the mobile station.....	299
5.4.4.2.5	Completion of clearing	300
5.4.5	Call clearing for SRVCC from CS to PS	300
5.5	Miscellaneous procedures	300
5.5.1	In-band tones and announcements	300
5.5.2	Call collisions	301
5.5.3	Status procedures	301
5.5.3.1	Status enquiry procedure	301
5.5.3.2	Reception of a STATUS message by a CC entity.....	302
5.5.3.2.1	STATUS message with incompatible state	302
5.5.3.2.2	STATUS message with compatible state	302
5.5.4	Call re-establishment, mobile station side	302
5.5.4.1	Indication from the mobility management sublayer.....	302
5.5.4.2	Reaction of call control	302
5.5.4.3	Completion of re-establishment	303
5.5.4.4	Unsuccessful outcome.....	303
5.5.5	Call re-establishment, network side	303
5.5.5.1	State alignment.....	303
5.5.6	Progress	303
5.5.7	DTMF protocol control procedure.....	303
5.5.7.1	Start DTMF request by the mobile station	304
5.5.7.2	Start DTMF response by the network	304
5.5.7.3	Stop DTMF request by the mobile station	304
5.5.7.4	Stop DTMF response by the network.....	304
5.5.7.5	Sequencing of subsequent start DTMF requests by the mobile station	304
6	Support for packet services	305
6.1	GPRS Session management	305
6.1.1	General.....	305
6.1.2	Session management states	306
6.1.2.1	Session management states in the MS.....	306
6.1.2.1.1	PDP-INACTIVE.....	306
6.1.2.1.2	PDP-ACTIVE-PENDING	306
6.1.2.1.3	PDP-INACTIVE-PENDING.....	306
6.1.2.1.4	PDP-ACTIVE.....	306
6.1.2.1.5	PDP-MODIFY_PENDING	306
6.1.2.1.6	MBMS-ACTIVE-PENDING	306
6.1.2.1.7	MBMS-ACTIVE	306
6.1.2.2	Session management states on the network side	308
6.1.2.2.1	PDP-INACTIVE.....	308
6.1.2.2.2	PDP-ACTIVE-PENDING	308
6.1.2.2.3	PDP-INACTIVE-PENDING.....	308
6.1.2.2.4	PDP-ACTIVE.....	308
6.1.2.2.5	PDP-MODIFY-PENDING	308
6.1.2.2.6	MBMS-ACTIVE-PENDING	309
6.1.2.2.7	MBMS-INACTIVE-PENDING	309
6.1.2.2.8	MBMS-ACTIVE	309
6.1.2A	PDP address allocation	310
6.1.2A.1	General	310
6.1.2A.1.1	Interworking with PDN based on IP.....	310
6.1.2A.1.2	Interworking with PDN based on PPP.....	310
6.1.2A.2	IP address allocation via NAS signalling	311
6.1.3	Session Management procedures	311
6.1.3.0	General	311
6.1.3.1	PDP context activation	311
6.1.3.1.1	Successful PDP context activation initiated by the mobile station	312
6.1.3.1.2	Successful PDP context activation requested by the network	314
6.1.3.1.3	Unsuccessful PDP context activation initiated by the MS.....	315
6.1.3.1.3.1	General	315
6.1.3.1.3.2	Handling of network rejection due to SM cause #26	316

6.1.3.1.3.3	Handling of network rejection due to SM cause other than SM cause #26	317
6.1.3.1.3A	Void.....	321
6.1.3.1.4	Unsuccessful PDP context activation requested by the network	321
6.1.3.1.5	Abnormal cases	321
6.1.3.1.6	Handling Activate PDP context request for MS configured for dual priority	323
6.1.3.2	Secondary PDP Context Activation Procedure	323
6.1.3.2.1	Successful Secondary PDP Context Activation Procedure Initiated by the MS.....	324
6.1.3.2.1a	Successful Secondary PDP Context Activation Procedure Requested by the network	324
6.1.3.2.2	Unsuccessful Secondary PDP Context Activation Procedure initiated by the MS	326
6.1.3.2.2.1	General.....	326
6.1.3.2.2.2	Handling of network rejection due to SM cause #26.....	326
6.1.3.2.2.3	Handling of network rejection due to SM cause other than SM cause #26	328
6.1.3.2.2a	Unsuccessful secondary PDP context activation requested by the network	329
6.1.3.2.3	Abnormal cases	330
6.1.3.3	PDP context modification procedure	333
6.1.3.3.1	Network initiated PDP Context Modification	334
6.1.3.3.2	MS initiated PDP Context Modification accepted by the network	335
6.1.3.3.3	MS initiated PDP Context Modification not accepted by the network	336
6.1.3.3.3.1	General.....	336
6.1.3.3.3.2	Handling of network rejection due to SM cause #26.....	337
6.1.3.3.3.3	Handling of network rejection due to SM cause other than SM cause #26	338
6.1.3.3.3a	Network initiated PDP Context Modification not accepted by the MS	339
6.1.3.3.4	Abnormal cases	340
6.1.3.4	PDP context deactivation procedure	345
6.1.3.4.1	PDP context deactivation initiated by the MS	345
6.1.3.4.2	PDP context deactivation initiated by the network.....	346
6.1.3.4.3	Abnormal cases	348
6.1.3.4a	Void.....	349
6.1.3.5	Void.....	349
6.1.3.5a	Notification procedure	349
6.1.3.5a.1	General	349
6.1.3.5a.2	Notification procedure initiation by the network	349
6.1.3.5a.3	Notification procedure in the MS	350
6.1.3.6	Receiving a SM STATUS message by a SM entity	350
6.1.3.7	Protocol configuration options	351
6.1.3.8	MBMS context activation	351
6.1.3.8.1	Successful MBMS context activation.....	351
6.1.3.8.2	Unsuccessful MBMS context activation requested by the MS	351
6.1.3.8.2.1	General.....	351
6.1.3.8.2.2	Handling of network rejection due to SM cause #26	352
6.1.3.8.2.3	Handling of network rejection due to SM cause other than SM cause #26	353
6.1.3.8.3	Unsuccessful MBMS context activation requested by the network.....	354
6.1.3.8.4	Abnormal cases	354
6.1.3.9	MBMS context deactivation.....	355
6.1.3.9.1	MBMS context deactivation initiated by the network	355
6.1.3.9.2	Abnormal cases	355
6.1.3.10	MBMS protocol configuration options	356
6.1.3.11	Handling of APN based congestion control	356
6.1.3.11A	Handling of group specific session management congestion control.....	356
6.1.3.12	Handling session management request for MS configured for dual priority.....	356
6.1.3.13	Handling of network rejection not due to APN based congestion control	357
6.1.3.14	Handling of WLAN offload control	358
6.2	void.....	358
6.3	Coordination between SM and GMM for supporting ISR	358
6.4	MSISDN notification procedure.....	358
7	Examples of structured procedures	358
8	Handling of unknown, unforeseen, and erroneous protocol data	359
8.1	General	359
8.2	Message too short.....	359
8.3	Unknown or unforeseen transaction identifier	359

8.3.1	Call Control	359
8.3.2	Session Management	360
8.4	Unknown or unforeseen message type	361
8.5	Non-semantical mandatory information element errors	362
8.5.1	Radio resource management	362
8.5.2	Mobility management	362
8.5.3	Call control	362
8.5.4	GMM mobility management	363
8.5.5	Session management	363
8.6	Unknown and unforeseen IEs in the non-imperative message part	363
8.6.1	IEIs unknown in the message	363
8.6.2	Out of sequence IEs	363
8.6.3	Repeated IEs	364
8.7	Non-imperative message part errors	364
8.7.1	Syntactically incorrect optional IEs	364
8.7.2	Conditional IE errors	364
8.8	Messages with semantically incorrect contents	364
9	Message functional definitions and contents	365
9.1	Messages for Radio Resources management	366
9.2	Messages for mobility management	366
9.2.1	Authentication reject	366
9.2.2	Authentication request	367
9.2.2.1	Authentication Parameter AUTN	367
9.2.3	Authentication response	367
9.2.3.1	Authentication Response Parameter	368
9.2.3.2	Authentication Response Parameter (extension)	368
9.2.3a	Authentication Failure	368
9.2.3a.1	Authentication Failure parameter	368
9.2.4	CM Re-establishment request	369
9.2.4.1	Location area identification	369
9.2.4.2	Mobile Station Classmark	369
9.2.4.3	Device properties	369
9.2.5	CM service accept	369
9.2.5a	CM service prompt \$(CCBS)\$	370
9.2.6	CM service reject	370
9.2.6.1	T3246 value	371
9.2.7	CM service abort	371
9.2.8	Abort	371
9.2.9	CM service request	372
9.2.9.1	Mobile Station Classmark	372
9.2.9.2	Priority	372
9.2.9.3	Additional update parameters	372
9.2.9.4	Device properties	372
9.2.10	Identity request	373
9.2.11	Identity response	373
9.2.12	IMSI detach indication	373
9.2.12.1	Mobile Station Classmark	374
9.2.13	Location updating accept	374
9.2.13.1	Follow on proceed	374
9.2.13.2	CTS permission	375
9.2.13.3	Equivalent PLMNs	375
9.2.13.4	Emergency Number List	375
9.2.13.5	Per MS T3212	375
9.2.14	Location updating reject	375
9.2.14.1	T3246 value	375
9.2.15	Location updating request	375
9.2.15.1	Location area identification	376
9.2.15.2	Mobile Station Classmark	376
9.2.15.3	Mobile Station Classmark for Iu mode	376
9.2.15.4	Additional update parameters	376
9.2.15.5	Device properties	376

9.2.15.6	MS network feature support.....	376
9.2.15a	MM information	377
9.2.15a.1	Full name for network	377
9.2.15a.2	Short name for network.....	377
9.2.15a.3	Local time zone	377
9.2.15a.4	Universal time and local time zone	377
9.2.15a.5	LSA Identity.....	378
9.2.15a.6	Network Daylight Saving Time	378
9.2.16	MM Status	378
9.2.17	TMSI reallocation command	378
9.2.18	TMSI reallocation complete	379
9.2.19	MM Null	379
9.3	Messages for circuit-switched call control	380
9.3.1	Alerting	380
9.3.1.1	Alerting (network to mobile station direction).....	380
9.3.1.1.1	Facility.....	381
9.3.1.1.2	Progress indicator	381
9.3.1.1.3	User-user	381
9.3.1.2	Alerting (mobile station to network direction).....	381
9.3.1.2.1	Facility.....	382
9.3.1.2.2	User-user	382
9.3.1.2.3	SS version.....	382
9.3.2	Call confirmed	382
9.3.2.1	Repeat indicator	383
9.3.2.2	Bearer capability 1 and bearer capability 2	383
9.3.2.3	Cause	384
9.3.2.4	CC Capabilities	384
9.3.2.5	Stream Identifier	384
9.3.2.6	Supported Codecs	384
9.3.3	Call proceeding	384
9.3.3.1	Repeat indicator	384
9.3.3.2	Bearer capability 1 and bearer capability 2	385
9.3.3.3	Facility	385
9.3.3.4	Progress Indicator	385
9.3.3.5	Priority granted	385
9.3.3.6	Network Call Control Capabilities	385
9.3.4	Congestion control.....	385
9.3.4.1	Cause	386
9.3.5	Connect	386
9.3.5.1	Connect (network to mobile station direction).....	386
9.3.5.1.1	Facility.....	386
9.3.5.1.2	Progress indicator	386
9.3.5.1.3	User-user	386
9.3.5.2	Connect (mobile station to network direction).....	386
9.3.5.2.1	Facility.....	387
9.3.5.2.2	User-user	387
9.3.5.2.3	SS version.....	387
9.3.5.2.4	Stream Identifier.....	387
9.3.6	Connect acknowledge	387
9.3.7	Disconnect	388
9.3.7.1	Disconnect (network to mobile station direction)	388
9.3.7.1.1	Facility.....	388
9.3.7.1.2	Progress indicator	388
9.3.7.1.3	User-user	388
9.3.7.1.4	Allowed actions \$(CCBS)\$	388
9.3.7.2	Disconnect (mobile station to network direction)	389
9.3.7.2.1	Facility.....	389
9.3.7.2.2	User-user	389
9.3.7.2.3	SS version.....	389
9.3.8	Emergency setup.....	389
9.3.8.1	Bearer capability	390
9.3.8.2	Stream Identifier	390

9.3.8.3	Supported Codecs	390
9.3.8.4	Emergency category.....	390
9.3.9	Facility	390
9.3.9.1	Facility (network to mobile station direction).....	390
9.3.9.2	Facility (mobile station to network direction).....	391
9.3.9.2.1	SS version.....	391
9.3.10	Hold	392
9.3.11	Hold Acknowledge	392
9.3.12	Hold Reject	392
9.3.13	Modify	393
9.3.13.1	Low layer compatibility	393
9.3.13.2	High layer compatibility	393
9.3.13.3	Reverse call setup direction.....	393
9.3.13.4	Void.....	394
9.3.13.5	Network-initiated Service Upgrade indicator.....	394
9.3.14	Modify complete	394
9.3.14.1	Low layer compatibility	394
9.3.14.2	High layer compatibility	394
9.3.14.3	Reverse call setup direction.....	394
9.3.15	Modify reject	394
9.3.15.1	Low layer compatibility	395
9.3.15.2	High layer compatibility	395
9.3.16	Notify	395
9.3.17	Progress	395
9.3.17.1	User-user	396
9.3.17.2	Progress indicator.....	396
9.3.17a	CC-Establishment \$(CCBS)\$	396
9.3.17a.1	Void.....	397
9.3.17a.2	Setup container.....	397
9.3.17b	CC-Establishment confirmed \$(CCBS)\$	397
9.3.17b.1	Repeat indicator	397
9.3.17b.2	Bearer capability 1 and bearer capability 2	398
9.3.17b.3	Cause	398
9.3.17b.4	Supported Codecs	398
9.3.18	Release	398
9.3.18.1	Release (network to mobile station direction).....	398
9.3.18.1.1	Cause	398
9.3.18.1.2	Second cause	398
9.3.18.1.3	Facility.....	399
9.3.18.1.4	User-user	399
9.3.18.2	Release (mobile station to network direction).....	399
9.3.18.2.1	Cause	399
9.3.18.2.2	Second cause	399
9.3.18.2.3	Facility.....	399
9.3.18.2.4	User-user	400
9.3.18.2.5	SS version.....	400
9.3.18a	Recall \$(CCBS)\$	400
9.3.18a.1	Recall Type	400
9.3.18a.2	Facility	400
9.3.19	Release complete	400
9.3.19.1	Release complete (network to mobile station direction)	400
9.3.19.1.1	Cause	401
9.3.19.1.2	Facility.....	401
9.3.19.1.3	User-user	401
9.3.19.2	Release complete (mobile station to network direction)	401
9.3.19.2.1	Cause	402
9.3.19.2.2	Facility.....	402
9.3.19.2.3	User-user	402
9.3.19.2.4	SS version.....	402
9.3.20	Retrieve.....	402
9.3.21	Retrieve Acknowledge.....	403
9.3.22	Retrieve Reject.....	403

9.3.23	Setup	404
9.3.23.1	Setup (mobile terminated call establishment)	404
9.3.23.1.1	BC repeat indicator.....	405
9.3.23.1.2	Bearer capability 1 and bearer capability 2	406
9.3.23.1.3	Facility.....	406
9.3.23.1.4	Progress indicator	406
9.3.23.1.4a	Called party BCD number	406
9.3.23.1.5	Called party subaddress	406
9.3.23.1.6	LLC repeat indicator.....	406
9.3.23.1.7	Low layer compatibility I	406
9.3.23.1.8	Low layer compatibility II	406
9.3.23.1.9	HLC repeat indicator	406
9.3.23.1.10	High layer compatibility i.....	406
9.3.23.1.11	High layer compatibility ii.....	407
9.3.23.1.12	User-user	407
9.3.23.1.13	Redirecting party BCD number	407
9.3.23.1.14	Redirecting party subaddress.....	407
9.3.23.1.15	Priority.....	407
9.3.23.1.16	Alert \$(Network Indication of Alerting in the MS)\$	407
9.3.23.1.17	Network Call Control Capabilities	407
9.3.23.1.18	Cause of No CLI.....	407
9.3.23.1.19	Backup bearer capability	407
9.3.23.2	Setup (mobile originating call establishment).....	407
9.3.23.2.1	BC repeat indicator.....	408
9.3.23.2.2	Facility.....	409
9.3.23.2.3	LLC repeat indicator.....	409
9.3.23.2.4	Low layer compatibility I	409
9.3.23.2.5	Low layer compatibility II.....	409
9.3.23.2.6	HLC repeat indicator	409
9.3.23.2.7	High layer compatibility i.....	409
9.3.23.2.8	High layer compatibility ii.....	409
9.3.23.2.9	User-user	409
9.3.23.2.10	SS version.....	409
9.3.23.2.11	CLIR suppression	409
9.3.23.2.12	CLIR invocation	410
9.3.23.2.13	CC Capabilities.....	410
9.3.23.2.14	Stream Identifier	410
9.3.23.2.15	Bearer capability 1 and bearer capability 2	410
9.3.23.2.16	Supported Codecs.....	410
9.3.23.2.17	Redial	410
9.3.23a	Start CC \$(CCBS)\$.....	410
9.3.23a.1	CC Capabilities	410
9.3.24	Start DTMF.....	411
9.3.25	Start DTMF Acknowledge.....	411
9.3.25.1	Keypad facility	411
9.3.26	Start DTMF reject.....	411
9.3.27	Status	412
9.3.27.1	Auxiliary states	412
9.3.28	Status enquiry	412
9.3.29	Stop DTMF.....	413
9.3.30	Stop DTMF acknowledge	413
9.3.31	User information	414
9.3.31.1	User-user	414
9.3.31.2	More data	414
9.4	GPRS Mobility Management Messages.....	414
9.4.1	Attach request	414
9.4.1.1	Old P-TMSI signature	416
9.4.1.2	Requested READY timer value	416
9.4.1.3	TMSI status	416
9.4.1.4	PS LCS Capability	416
9.4.1.5	UE network capability.....	416
9.4.1.6	Mobile station classmark 2.....	416

9.4.1.7	Mobile station classmark 3.....	416
9.4.1.8	Supported Codecs	416
9.4.1.9	Additional mobile identity	416
9.4.1.10	Additional old routing area identification	416
9.4.1.11	Voice domain preference and UE's usage setting.....	416
9.4.1.12	Device properties	417
9.4.1.13	P-TMSI type.....	417
9.4.1.14	MS network feature support.....	417
9.4.1.15	Old location area identification	417
9.4.1.16	Additional update type	417
9.4.1.17	TMSI based NRI container	417
9.4.1.18	T3324 value.....	417
9.4.1.19	T3312 extended value	417
9.4.1.20	Extended DRX parameters.....	417
9.4.2	Attach accept	417
9.4.2.1	P-TMSI signature.....	419
9.4.2.2	Negotiated READY timer value	419
9.4.2.3	Allocated P-TMSI	419
9.4.2.4	MS identity.....	419
9.4.2.5	GMM cause.....	419
9.4.2.6	T3302 value.....	419
9.4.2.7	Cell Notification (A/Gb mode only)	419
9.4.2.8	Equivalent PLMNs.....	419
9.4.2.9	Network feature support.....	419
9.4.2.10	Emergency Number List	419
9.4.2.11	Requested MS Information	419
9.4.2.12	T3319 value.....	419
9.4.2.13	T3323 value.....	419
9.4.2.14	T3312 extended value	420
9.4.2.15	Additional network feature support.....	420
9.4.2.16	T3324 value.....	420
9.4.2.17	Extended DRX parameters.....	420
9.4.2.18	User Plane integrity indicator.....	420
9.4.2.19	Replayed MS network capability	420
9.4.2.20	Replayed MS radio access capability	420
9.4.3	Attach complete	420
9.4.3.1	Inter RAT handover information.....	421
9.4.3.2	E-UTRAN inter RAT handover information	421
9.4.4	Attach reject.....	421
9.4.4.1	T3302 value.....	421
9.4.4.2	T3346 value.....	422
9.4.5	Detach request	422
9.4.5.1	Detach request (mobile terminated detach).....	422
9.4.5.1.1	GMM cause.....	422
9.4.5.2	Detach request (mobile originating detach)	422
9.4.5.2.1	P-TMSI.....	423
9.4.5.2.2	P-TMSI signature	423
9.4.6	Detach accept	423
9.4.6.1	Detach accept (mobile terminated detach).....	423
9.4.6.2	Detach accept (mobile originating detach).....	423
9.4.7	P-TMSI reallocation command	424
9.4.7.1	P-TMSI signature	424
9.4.8	P-TMSI reallocation complete	424
9.4.9	Authentication and ciphering request	425
9.4.9.1	Authentication Parameter RAND.....	425
9.4.9.2	GPRS ciphering key sequence number	425
9.4.9.3	Authentication Parameter AUTN.....	426
9.4.9.4	Replayed MS network capability	426
9.4.9.5	Integrity algorithm	426
9.4.9.6	Message authentication code.....	426
9.4.9.7	Replayed MS Radio Access Capability.....	426
9.4.10	Authentication and ciphering response	426

9.4.10.1	Authentication Response Parameter.....	427
9.4.10.2	IMEISV.....	427
9.4.10.3	Authentication Response Parameter (extension).....	427
9.4.10.4	Message authentication code.....	427
9.4.10a	Authentication and Ciphering Failure.....	427
9.4.10a.1	Authentication Failure parameter.....	427
9.4.11	Authentication and ciphering reject.....	427
9.4.12	Identity request	428
9.4.13	Identity response	428
9.4.14	Routing area update request.....	429
9.4.14.1	Old P-TMSI signature	432
9.4.14.2	Requested READY timer value	432
9.4.14.3	DRX parameter	432
9.4.14.4	TMSI status	432
9.4.14.5	P-TMSI (Iu mode only).....	432
9.4.14.6	MS network capability	432
9.4.14.7	PDP context status	432
9.4.14.8	PS LCS Capability	432
9.4.14.9	MBMS context status.....	432
9.4.14.10	Additional mobile identity	432
9.4.14.11	Additional old routing area identification	432
9.4.14.12	UE network capability.....	432
9.4.14.13	Mobile station classmark 2.....	432
9.4.14.14	Mobile station classmark 3.....	433
9.4.14.15	Supported Codecs	433
9.4.14.16	Voice domain preference and UE's usage setting.....	433
9.4.14.17	P-TMSI type.....	433
9.4.14.18	Device properties	433
9.4.14.19	MS network feature support.....	433
9.4.14.20	Old location area identification	433
9.4.14.21	Additional update type	433
9.4.14.22	TMSI based NRI container	433
9.4.14.23	T3324 value.....	433
9.4.14.24	T3312 extended value	433
9.4.14.25	Extended DRX parameters.....	433
9.4.15	Routing area update accept	434
9.4.15.1	P-TMSI signature	436
9.4.15.2	Allocated P-TMSI	436
9.4.15.3	MS identity.....	436
9.4.15.4	List of Receive N-PDU Numbers.....	436
9.4.15.5	Negotiated READY timer value	436
9.4.15.6	GMM cause.....	436
9.4.15.7	T3302 value.....	436
9.4.15.8	Cell Notification (A/Gb mode only)	436
9.4.15.9	Equivalent PLMNs.....	436
9.4.15.10	PDP context status	436
9.4.15.11	Network feature support.....	436
9.4.15.12	Emergency Number List	437
9.4.15.13	MBMS context status.....	437
9.4.15.14	Requested MS Information	437
9.4.15.15	T3319 value.....	437
9.4.15.16	T3323 value.....	437
9.4.15.17	T3312 extended value	437
9.4.15.18	Additional network feature support.....	437
9.4.15.19	T3324 value.....	437
9.4.15.20	Extended DRX parameters.....	437
9.4.15.21	User Plane integrity indicator.....	437
9.4.15.22	Replayed MS network capability	437
9.4.15.23	Replayed MS Radio Access Capability.....	438
9.4.16	Routing area update complete.....	438
9.4.16.1	List of Receive N-PDU Numbers.....	438
9.4.16.2	Inter RAT handover information.....	438

9.4.16.3	E-UTRAN inter RAT handover information	438
9.4.17	Routing area update reject	438
9.4.17.1	T3302 value.....	439
9.4.17.2	T3346 value.....	439
9.4.18	GMM Status.....	439
9.4.19	GMM Information	440
9.4.19.1	Full name for network.....	440
9.4.19.2	Short name for network.....	440
9.4.19.3	Local time zone	440
9.4.19.4	Universal time and local time zone	440
9.4.19.5	LSA Identity.....	441
9.4.19.6	Network Daylight Saving Time	441
9.4.20	Service Request (Iu mode only).....	441
9.4.20.1	PDP context status	441
9.4.20.2	MBMS context status	441
9.4.20.3	Uplink data status.....	441
9.4.20.4	Device properties	441
9.4.21	Service Accept (Iu mode only)	442
9.4.21.1	PDP context status	442
9.4.21.2	MBMS context status	442
9.4.22	Service Reject (Iu mode only)	442
9.4.22.1	T3346 value.....	442
9.5	GPRS Session Management Messages.....	443
9.5.1	Activate PDP context request	443
9.5.1.1	Access point name.....	443
9.5.1.2	Protocol configuration options	443
9.5.1.3	Request type	443
9.5.1.4	Device properties	443
9.5.1.5	NBIFOM container	444
9.5.2	Activate PDP context accept.....	444
9.5.2.1	PDP address	444
9.5.2.2	Protocol configuration options	444
9.5.2.3	Packet Flow Identifier	445
9.5.2.4	SM cause	445
9.5.2.5	Connectivity type	445
9.5.2.6	WLAN offload indication	445
9.5.2.7	NBIFOM container	445
9.5.3	Activate PDP context reject	445
9.5.3.1	Protocol configuration options	446
9.5.3.2	Back-off timer value	446
9.5.3.3	Re-attempt indicator.....	446
9.5.3.4	NBIFOM container	446
9.5.4	Activate Secondary PDP Context Request	446
9.5.4.1	TFT	447
9.5.4.2	Protocol configuration options	447
9.5.4.3	Device properties	447
9.5.4.4	NBIFOM container	447
9.5.5	Activate Secondary PDP Context Accept.....	447
9.5.5.1	Packet Flow Identifier	447
9.5.5.2	Protocol configuration options	448
9.5.5.3	WLAN offload indication	448
9.5.5.4	NBIFOM container	448
9.5.6	Activate Secondary PDP Context Reject	448
9.5.6.1	Protocol configuration options	448
9.5.6.2	Back-off timer value	448
9.5.6.3	Re-attempt indicator.....	448
9.5.6.4	NBIFOM container	449
9.5.7	Request PDP context activation.....	449
9.5.7.1	Protocol configuration options	449
9.5.7.2	NBIFOM container	449
9.5.8	Request PDP context activation reject	449
9.5.8.1	Protocol configuration options	450

9.5.8.2	NBIFOM container	450
9.5.9	Modify PDP context request (Network to MS direction)	450
9.5.9.1	PDP address	451
9.5.9.2	Packet Flow Identifier	451
9.5.9.3	Protocol configuration options	451
9.5.9.4	TFT	451
9.5.9.5	WLAN offload indication	451
9.5.9.6	NBIFOM container	451
9.5.10	Modify PDP context request (MS to network direction)	451
9.5.10.1	Requested LLC SAPI	452
9.5.10.2	Requested new QoS	452
9.5.10.3	New TFT	452
9.5.10.4	Protocol configuration options	452
9.5.10.5	Device properties	452
9.5.10.6	NBIFOM container	452
9.5.11	Modify PDP context accept (MS to network direction)	452
9.5.11.1	Protocol configuration options	453
9.5.11.2	NBIFOM container	453
9.5.12	Modify PDP context accept (Network to MS direction)	453
9.5.12.1	Negotiated QoS	454
9.5.12.2	Negotiated LLC SAPI	454
9.5.12.3	New radio priority	454
9.5.12.4	Packet Flow Identifier	454
9.5.12.5	Protocol configuration options	454
9.5.12.6	WLAN offload indication	454
9.5.12.7	NBIFOM container	454
9.5.13	Modify PDP Context Reject	454
9.5.13.1	Protocol configuration options	455
9.5.13.2	Back-off timer value	455
9.5.13.3	Re-attempt indicator	455
9.5.13.4	NBIFOM container	455
9.5.14	Deactivate PDP context request	455
9.5.14.1	Tear down indicator	456
9.5.14.2	Protocol configuration options	456
9.5.14.3	MBMS protocol configuration options	456
9.5.14.4	T3396 value	456
9.5.14.5	WLAN offload indication	456
9.5.14.6	Void	456
9.5.15	Deactivate PDP context accept	456
9.5.15.1	Protocol configuration options	457
9.5.15.2	MBMS protocol configuration options	457
9.5.15.3	Void	457
9.5.15a	Request Secondary PDP Context Activation	457
9.5.15a.1	TFT	458
9.5.15a.2	Protocol configuration options	458
9.5.15a.3	WLAN offload indication	458
9.5.15a.4	NBIFOM container	458
9.5.15b	Request Secondary PDP Context Activation Reject	458
9.5.15b.1	Protocol configuration options	459
9.5.15b.2	NBIFOM container	459
9.5.16	Void	459
9.5.16a	Notification	459
9.5.17	Void	460
9.5.18	Void	460
9.5.19	Void	460
9.5.20	Void	460
9.5.21	SM Status	460
9.5.22	Activate MBMS Context Request	460
9.5.22.1	MBMS protocol configuration options	461
9.5.22.2	Device properties	461
9.5.23	Activate MBMS Context Accept	461
9.5.23.1	MBMS protocol configuration options	462

9.5.24	Activate MBMS Context Reject	462
9.5.24.1	MBMS protocol configuration options	462
9.5.24.2	Back-off timer value	462
9.5.24.3	Re-attempt indicator	462
9.5.25	Request MBMS Context Activation	462
9.5.25.1	Linked NSAPI	463
9.5.25.2	MBMS protocol configuration options	463
9.5.26	Request MBMS Context Activation Reject	463
9.5.26.1	MBMS protocol configuration options	463
10	General message format and information elements coding	464
10.1	Overview	464
10.2	Protocol Discriminator	464
10.3	Skip indicator and transaction identifier	464
10.3.1	Skip indicator	464
10.3.2	Transaction identifier	466
10.4	Message Type	466
10.5	Other information elements	469
10.5.1	Common information elements	470
10.5.1.1	Cell identity	470
10.5.1.2	Ciphering Key Sequence Number	471
10.5.1.3	Location Area Identification	471
10.5.1.4	Mobile Identity	473
10.5.1.5	Mobile Station Classmark 1	478
10.5.1.6	Mobile Station Classmark 2	481
10.5.1.7	Mobile Station Classmark 3	484
10.5.1.8	Spare Half Octet	500
10.5.1.9	Descriptive group or broadcast call reference	500
10.5.1.10	Group Cipher Key Number	501
10.5.1.10a	PD and SAPI \$(CCBS)\$	502
10.5.1.11	Priority Level	503
10.5.1.12	Core Network System Information (Iu mode only)	503
10.5.1.12.1	CN Common GSM-MAP NAS system information	503
10.5.1.12.2	CS domain specific system information	504
10.5.1.12.3	PS domain specific system information	504
10.5.1.13	PLMN list	505
10.5.1.14	NAS container for PS HO	506
10.5.1.15	MS network feature support	507
10.5.2	Radio Resource management information elements	508
10.5.3	Mobility management information elements	508
10.5.3.1	Authentication parameter RAND	508
10.5.3.1.1	Authentication Parameter AUTN (UMTS and EPS authentication challenge)	508
10.5.3.2	Authentication Response parameter	509
10.5.3.2.1	Authentication Response Parameter (extension) (UMTS authentication challenge only)	510
10.5.3.2.2	Authentication Failure parameter (UMTS and EPS authentication challenge)	510
10.5.3.3	CM service type	511
10.5.3.4	Identity type	511
10.5.3.5	Location updating type	512
10.5.3.5a	Network Name	512
10.5.3.6	Reject cause	514
10.5.3.7	Follow-on Proceed	515
10.5.3.8	Time Zone	515
10.5.3.9	Time Zone and Time	516
10.5.3.10	CTS permission	517
10.5.3.11	LSA Identifier	518
10.5.3.12	Daylight Saving Time	518
10.5.3.13	Emergency Number List	519
10.5.3.14	Additional update parameters	520
10.5.3.15	Void	520
10.5.3.16	MM Timer	520
10.5.4	Call control information elements	521
10.5.4.1	Extensions of codesets	521

10.5.4.2	Locking shift procedure	522
10.5.4.3	Non-locking shift procedure.....	522
10.5.4.4	Auxiliary states	523
10.5.4.4a	Backup bearer capability.....	524
10.5.4.4a.1	Static conditions for the backup bearer capability IE contents	533
10.5.4.5	Bearer capability	533
10.5.4.5.1	Static conditions for the bearer capability IE contents	548
10.5.4.5a	Call Control Capabilities.....	548
10.5.4.6	Call state.....	549
10.5.4.7	Called party BCD number.....	550
10.5.4.8	Called party subaddress.....	552
10.5.4.9	Calling party BCD number	553
10.5.4.10	Calling party subaddress	554
10.5.4.11	Cause.....	555
10.5.4.11a	CLIR suppression.....	560
10.5.4.11b	CLIR invocation.....	561
10.5.4.12	Congestion level.....	561
10.5.4.13	Connected number	561
10.5.4.14	Connected subaddress	562
10.5.4.15	Facility	562
10.5.4.16	High layer compatibility	563
10.5.4.16.1	Static conditions for the high layer compatibility IE contents.....	564
10.5.4.17	Keypad facility	564
10.5.4.18	Low layer compatibility	564
10.5.4.19	More data	564
10.5.4.20	Notification indicator	565
10.5.4.21	Progress indicator.....	565
10.5.4.21a	Recall type \$(CCBS)\$	566
10.5.4.21b	Redirecting party BCD number.....	567
10.5.4.21c	Redirecting party subaddress.....	567
10.5.4.22	Repeat indicator	568
10.5.4.22a	Reverse call setup direction.....	568
10.5.4.22b	SETUP Container \$(CCBS)\$.....	569
10.5.4.23	Signal	569
10.5.4.24	SS Version Indicator	570
10.5.4.25	User-user	570
10.5.4.26	Alerting Pattern \$(NIA)\$	571
10.5.4.27	Allowed actions \$(CCBS)\$.....	572
10.5.4.28	Stream Identifier	573
10.5.4.29	Network Call Control Capabilities	573
10.5.4.30	Cause of No CLI	574
10.5.4.31	Void.....	574
10.5.4.32	Supported codec list	574
10.5.4.33	Service category	575
10.5.4.34	Redial	576
10.5.4.35	Network-initiated Service Upgrade indicator.....	576
10.5.5	GPRS mobility management information elements.....	577
10.5.5.0	Additional update type	577
10.5.5.1	Attach result	577
10.5.5.2	Attach type	577
10.5.5.3	Ciphering algorithm	578
10.5.5.3a	Integrity algorithm	579
10.5.5.4	TMSI status	579
10.5.5.5	Detach type	580
10.5.5.6	DRX parameter	580
10.5.5.7	Force to standby	582
10.5.5.8	P-TMSI signature	583
10.5.5.8a	P-TMSI signature 2	583
10.5.5.9	Identity type 2	584
10.5.5.10	IMEISV request	584
10.5.5.11	Receive N-PDU Numbers list	585
10.5.5.12	MS network capability	586

10.5.5.12a	MS Radio Access capability	590
10.5.5.13	Spare	609
10.5.5.14	GMM cause	609
10.5.5.15	Routing area identification	610
10.5.5.15a	Routing area identification 2	612
10.5.5.16	Spare	613
10.5.5.17	Update result	613
10.5.5.18	Update type	614
10.5.5.19	A&C reference number	614
10.5.5.20	Service type	615
10.5.5.21	Cell Notification	615
10.5.5.22	PS LCS Capability	616
10.5.5.23	Network feature support	617
10.5.5.23A	Additional network feature support	617
10.5.5.24	Inter RAT information container	618
10.5.5.25	Requested MS information	618
10.5.5.26	UE network capability	619
10.5.5.27	E-UTRAN inter RAT information container	619
10.5.5.28	Voice domain preference and UE's usage setting	620
10.5.5.29	P-TMSI type	620
10.5.5.30	Location Area Identification 2	621
10.5.5.31	Network resource identifier container	621
10.5.5.32	Extended DRX parameters	622
10.5.5.33	Message authentication code	626
10.5.5.34	User Plane integrity indicator	627
10.5.6	Session management information elements	627
10.5.6.1	Access point name	627
10.5.6.2	Network service access point identifier	628
10.5.6.3	Protocol configuration options	628
10.5.6.3.1	General	628
10.5.6.3.2	APN rate control parameters	636
10.5.6.4	Packet data protocol address	637
10.5.6.5	Quality of service	638
10.5.6.5A	Re-attempt indicator	648
10.5.6.6	SM cause	649
10.5.6.6A	SM cause 2	650
10.5.6.7	Linked TI	651
10.5.6.8	Spare	651
10.5.6.9	LLC service access point identifier	651
10.5.6.10	Tear down indicator	652
10.5.6.11	Packet Flow Identifier	652
10.5.6.12	Traffic Flow Template	653
10.5.6.13	Temporary Mobile Group Identity (TMGI)	660
10.5.6.14	MBMS bearer capabilities	660
10.5.6.15	MBMS protocol configuration options	661
10.5.6.16	Enhanced network service access point identifier	662
10.5.6.17	Request type	662
10.5.6.18	Notification indicator	663
10.5.6.19	Connectivity type	664
10.5.6.20	WLAN offload acceptability	664
10.5.6.21	NBIFOM container	665
10.5.7	GPRS Common information elements	665
10.5.7.1	PDP context status	665
10.5.7.2	Radio priority	666
10.5.7.3	GPRS Timer	667
10.5.7.4	GPRS Timer 2	667
10.5.7.4a	GPRS Timer 3	668
10.5.7.5	Radio priority 2	668
10.5.7.6	MBMS context status	669
10.5.7.7	Uplink data status	669
10.5.7.8	Device properties	670

11	List of system parameters.....	671
11.1	Timers and counters for radio resource management.....	671
11.2	Timers of mobility management	671
11.2.1	Timer T3240 and Timer T3241	674
11.2.2	Timers of GPRS mobility management	675
11.2.3	Timers of GPRS session management.....	687
11.3	Timers of circuit-switched call control.....	692

Annex A (informative):	Example of subaddress information element coding	694
-------------------------------	---	------------

Annex B (normative):	Compatibility checking.....	695
-----------------------------	------------------------------------	------------

B.1	Introduction	695
B.2	Calling side compatibility checking	695
B.2.1	Compatibility checking of the CM SERVICE REQUEST message	695
B.2.2	Compatibility/Subscription checking of the SETUP message	695
B.3	Called side compatibility checking	695
B.3.1	Compatibility checking with addressing information.....	696
B.3.2	Network-to-MS compatibility checking.....	696
B.3.3	User-to-User compatibility checking.....	696
B.4	High layer compatibility checking	696

Annex C (normative):	Low layer information coding principles.....	697
-----------------------------	---	------------

C.1	Purpose	697
C.2	Principles	697
C.2.1	Definition of types of information.....	697
C.2.2	Examination by network	697
C.2.3	Location of type I information	698
C.2.4	Location of types II and III information	698
C.2.5	Relationship between bearer capability and low layer compatibility information elements	698

Annex D (informative):	Examples of bearer capability information element coding	699
-------------------------------	---	------------

D.1	Coding for speech for a full rate support only mobile station	699
D.1.1	Mobile station to network direction	699
D.1.2	Network to mobile station direction	699
D.2	An example of a coding for modem access with V22-bis, 2,4 kbit/s, 8 bit no parity.....	700
D.2.1	Mobile station to network direction, data compression allowed	700
D.2.2	Network to mobile station direction, data compression possible	701
D.3	An example of a coding for group 3 facsimile (9,6 kbit/s, transparent).....	702
D.3.1	Mobile station to network direction	702
D.3.2	Network to mobile station direction	703

Annex E (informative):	Comparison between call control procedures specified in 3GPP TS 24.008 and ITU-T Recommendation Q.931	704
-------------------------------	--	------------

Annex F (informative):	A/Gb mode specific cause values for radio resource management	708
-------------------------------	--	------------

Annex G (informative):	3GPP specific cause values for mobility management.....	709
-------------------------------	--	------------

G.1	Causes related to MS identification.....	709
G.2	Cause related to subscription options	709
G.3	Causes related to PLMN specific network failures and congestion/Authentication Failures.....	710
G.4	Causes related to nature of request.....	710
G.5	Causes related to invalid messages	711
G.6	Additional cause codes for GMM	711

Annex H (informative): 3GPP specific cause values for call control.....	713
H.1 Normal class.....	713
H.1.1 Cause No. 1 "unassigned (unallocated) number"	713
H.1.2 Cause No. 3 "no route to destination"	713
H.1.3 Cause No. 6 "channel unacceptable"	713
H.1.4 Cause No. 8 "operator determined barring"	713
H.1.5 Cause No. 16 "normal call clearing"	713
H.1.6 Cause No. 17 "user busy"	713
H.1.7 Cause No. 18 "no user responding"	713
H.1.8 Cause No. 19 "user alerting, no answer"	713
H.1.9 Cause No. 21 "call rejected"	714
H.1.10 Cause No. 22 "number changed"	714
H.1.10a Cause No. 24 "call rejected due to feature at the destination"	714
H.1.11 Cause No. 25 "pre-emption"	714
H.1.12 Cause No. 26 "non-selected user clearing"	714
H.1.13 Cause No. 27 "destination out of order"	714
H.1.14 Cause No. 28 "invalid number format (incomplete number)"	714
H.1.15 Cause No. 29 "facility rejected"	714
H.1.16 Cause No. 30 "response to STATUS ENQUIRY"	714
H.1.17 Cause No. 31 "normal, unspecified"	714
H.2 Resource unavailable class.....	715
H.2.1 Cause No. 34 "no circuit/channel available"	715
H.2.2 Cause No. 38 "network out of order"	715
H.2.3 Cause No. 41 "temporary failure"	715
H.2.4 Cause No. 42 "switching equipment congestion"	715
H.2.5 Cause No. 43 "access information discarded"	715
H.2.6 Cause No. 44 "requested circuit/channel not available"	715
H.2.7 Cause No. 47 "resource unavailable, unspecified"	715
H.3 Service or option not available class	715
H.3.1 Cause No. 49 "quality of service unavailable"	715
H.3.2 Cause No. 50 "Requested facility not subscribed"	715
H.3.3 Cause No. 55 "Incoming calls barred within the CUG"	716
H.3.4 Cause No. 57 "bearer capability not authorized"	716
H.3.5 Cause No. 58 "bearer capability not presently available"	716
H.3.6 Cause No. 63 "service or option not available, unspecified"	716
H.3.7 Cause No. 68 "ACM equal to or greater than ACMmax"	716
H.4 Service or option not implemented class.....	716
H.4.1 Cause No. 65 "bearer service not implemented"	716
H.4.2 Cause No. 69 "Requested facility not implemented"	716
H.4.3 Cause No. 70 "only restricted digital information bearer capability is available"	716
H.4.4 Cause No. 79 "service or option not implemented, unspecified"	716
H.5 Invalid message (e.g., parameter out of range) class.....	717
H.5.1 Cause No. 81 "invalid transaction identifier value"	717
H.5.2 Cause No. 87 "user not member of CUG"	717
H.5.3 Cause No. 88 "incompatible destination"	717
H.5.4 Cause No. 91 "invalid transit network selection"	717
H.5.5 Cause No. 95 "semantically incorrect message"	717
H.6 Protocol error (e.g., unknown message) class	717
H.6.1 Cause No. 96 "invalid mandatory information"	717
H.6.2 Cause No. 97 "message type non-existent or not implemented"	717
H.6.3 Cause No. 98 "message type not compatible with protocol state"	717
H.6.4 Cause No. 99 "information element non-existent or not implemented"	718
H.6.5 Cause No. 100 "conditional IE error"	718
H.6.6 Cause No. 101 "message not compatible with protocol state"	718
H.6.7 Cause No. 102 "recovery on timer expiry"	718
H.6.8 Cause No. 111 "protocol error, unspecified"	718
H.7 Interworking class	718

H.7.1	Cause No. 127 "interworking, unspecified"	718
Annex I (informative):	GPRS specific cause values for GPRS Session Management.....	719
I.1	Causes related to nature of request.....	719
I.2	Causes related to invalid messages	721
I.3	Void.....	722
Annex J (informative):	Algorithm to encode frequency list information elements	723
Annex K (informative):	Default Codings of Information Elements.....	724
K.1	Common information elements.....	724
K.2	Radio Resource management information elements.....	724
K.3	Mobility management information elements.....	724
K.4	Call control information elements.....	725
Annex L (normative):	Establishment cause (Iu mode only).....	727
L.1	Mapping of NAS procedure to RRC establishment cause(Iu mode only).....	727
Annex M (normative):	Additional Requirements for backward compatibility with PCS 1900 for NA revision 0 ME.....	731
Annex N (normative):	Ranking of reject causes for Location Registration (MM and GMM) in a shared network	732
Annex O (normative):	3GPP capability exchange protocol.....	734
O.1	Scope	734
O.2	User-user protocol contents.....	734
O.3	Information element identifier.....	734
O.4	Information elements.....	735
O.4.1	Personal ME identifier.....	735
O.4.2	Radio environment capability.....	736
O.4.3	UE capability version	736
O.4.4	IM Status	737
O.5	Handling of unknown, unforeseen, and erroneous protocol data	738
O.5.1	General	738
O.5.2	Not supported IEs, unknown IEIs	738
O.5.3	Repeated IEs.....	738
O.5.4	Syntactically incorrect IEs.....	739
O.5.5	Semantically incorrect IEs.....	739
Annex P (normative):	Mobility management for IMS voice termination	740
P.1	Introduction	740
P.2	Activation of mobility management for IMS voice termination	740
P.3	Inter-system change between A/Gb mode and Iu mode.....	740
P.4	Inter-system change between A/Gb mode and S1 mode	741
P.5	Inter-system change between Iu mode and S1 mode	741
Annex Q (normative):	Application specific Congestion control for Data Communication (ACDC) (Iu mode only)	742
Annex R (informative):	Change History	743

History	779
---------------	-----

Foreword

This Technical Specification has been produced by the 3rd Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
 - 1 presented to TSG for information;
 - 2 presented to TSG for approval;
 - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

Introduction

The present document includes references to features which are not part of the Phase 2+ Release 96 of the GSM Technical specifications. All subclauses which were changed as a result of these features contain a marker (see table below) relevant to the particular feature.

The following table lists all features that were introduced after GSM Release 96.

Feature	Designator
BA Range IE handling	\$(impr-BA-range-handling)\$
Advanced Speech Call Item	\$(ASCI)\$
Call Completion Busy Subscriber	\$(CCBS)\$
Mobile Assisted Frequency Allocation	\$(MAFA)\$
Network Indication of Alerting in MS	\$(NIA)\$

1 Scope

The present document specifies the procedures used at the radio interface core network protocols within the 3rd generation mobile telecommunications system and the digital cellular telecommunications system.

It specifies the procedures used at the radio interface (Reference Point Um or Uu, see 3GPP TS 24.002 [15] or 3GPP TS 23.002 [127]) for Call Control (CC), Mobility Management (MM), and Session Management (SM).

When the notations for "further study" or "FS" or "FFS" are present in this TS they mean that the indicated text is not a normative portion of the present document.

These procedures are defined in terms of messages exchanged over the control channels of the radio interface. The control channels are described in 3GPP TS 44.003 [16] and 3GPP TS 25.301 [128].

The structured functions and procedures of this protocol and the relationship with other layers and entities are described in general terms in 3GPP TS 24.007 [20].

The present document specifies functions, procedures and information which apply to GERAN Iu mode. However, functionality related to GERAN Iu mode is neither maintained nor enhanced.

1.1 Scope of the Technical Specification

The procedures currently described in this TS are for the call control of circuit-switched connections, session management for GPRS services, mobility management and radio resource management for circuit-switched and GPRS services.

3GPP TS 24.010 [21] contains functional procedures for support of supplementary services.

3GPP TS 24.011 [22] contains functional procedures for support of point-to-point short message services.

3GPP TS 24.012 [23] contains functional description of short message - cell broadcast.

3GPP TS 44.060 [76] contains procedures for radio link control and medium access control (RLC/MAC) of packet data physical channels.

3GPP TS 44.071 [23a] contains functional descriptions and procedures for support of location services.

NOTE: "layer 3" includes the functions and protocols described in the present document. The terms "data link layer" and "layer 2" are used interchangeably to refer to the layer immediately below layer 3.

1.2 Application to the interface structures

The procedures defined in the present document apply to the interface structures defined in 3GPP TS 44.003 [16] and 3GPP TS 25.301 [128]. They use the functions and services provided by lower layers defined in 3GPP TS 44.005 [18] and 3GPP TS 44.006 [19] or 3GPP TS 25.331 [23c], 3GPP TS 25.322 [19b] and 3GPP TS 25.321 [19a].

3GPP TS 24.007 [20] gives the general description of layer 3 (A/Gb mode) and Non Access Stratum (Iu mode and S1 mode) including procedures, messages format and error handling.

1.3 Structure of layer 3 procedures

A building block method is used to describe the layer 3 procedures.

The basic building blocks are "elementary procedures" provided by the protocol control entities of the three sublayers, i.e. radio resource management, mobility management and connection management sublayer.

Complete layer 3 transactions consist of specific sequences of elementary procedures. The term "structured procedure" is used for these sequences.