

# ETSI TS 125 466 V14.2.0 (2017-10)



**Universal Mobile Telecommunications System (UMTS);  
UTRAN Iuant interface: Application part  
(3GPP TS 25.466 version 14.2.0 Release 14)**



---

Reference

RTS/TSGR-0325466ve20

---

Keywords

UMTS

***ETSI***

---

650 Route des Lucioles  
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C  
Association à but non lucratif enregistrée à la  
Sous-Préfecture de Grasse (06) N° 7803/88

---

***Important notice***

The present document can be downloaded from:  
<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the only prevailing document is the print of the Portable Document Format (PDF) version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.  
Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:  
<https://portal.etsi.org/People/CommitteeSupportStaff.aspx>

---

***Copyright Notification***

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.  
The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2017.  
All rights reserved.

**DECT™, PLUGTESTS™, UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members.  
**3GPP™** and **LTE™** are trademarks of ETSI registered for the benefit of its Members and  
of the 3GPP Organizational Partners.

**oneM2M** logo is protected for the benefit of its Members.  
**GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

---

## Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

---

## Foreword

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under  
<http://webapp.etsi.org/key/queryform.asp>.

---

## Modal verbs terminology

In the present document "shall", "shall not", "should", "should not", "may", "need not", "will", "will not", "can" and "cannot" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"must" and "must not" are NOT allowed in ETSI deliverables except when used in direct citation.

---

## Contents

Intellectual Property Rights .....	2
Foreword.....	2
Modal verbs terminology.....	2
Foreword.....	5
1    Scope .....	6
2    References .....	6
3    Definitions and abbreviations.....	6
3.1    Definitions .....	6
3.2    Abbreviations .....	8
4    General .....	8
4.1    Procedure specification principles.....	8
4.2    Forwards and backwards compatibility.....	8
4.3    Multi-antenna units.....	8
4.4    Integer representation .....	8
4.5    TMA Subunits .....	9
5    Services expected from signalling transport.....	9
5.1    Elementary procedure format .....	9
5.1.1    Initiating message .....	9
5.1.2    Response message .....	9
6    Control elementary procedures .....	10
6.1    State model.....	10
6.2    General procedure handling .....	10
6.2.1    Alarms .....	10
6.2.2    Procedure message interpretation .....	11
6.2.3    Parallel procedure handling .....	11
6.3    Overview of elementary procedures.....	12
6.4    Description of elementary procedures.....	14
6.5    Common elementary procedures .....	15
6.5.1    Reset Software .....	15
6.5.2    Get Alarm Status.....	16
6.5.3    Get Information .....	16
6.5.4    Clear Active Alarms .....	17
6.5.5    Alarm Subscribe .....	18
6.5.6    Self Test.....	18
6.5.7    Void .....	19
6.5.8    Void .....	19
6.5.9    Read User Data .....	19
6.5.10    Write User Data .....	20
6.5.11    Download Start .....	21
6.5.12    Download Application.....	21
6.5.13    Download End .....	22
6.5.14    Vendor specific procedure .....	23
6.6    Single-antenna elementary procedures .....	23
6.6.1    Calibrate.....	23
6.6.2    Send Configuration Data .....	24
6.6.3    Set Tilt .....	25
6.6.4    Get Tilt.....	26
6.6.5    Alarm Indication .....	26
6.6.6    Set Device Data .....	27
6.6.7    Get Device Data.....	27
6.7    Multi-antenna elementary procedures .....	28
6.7.1    Antenna Calibrate .....	28

6.7.2	Antenna Set Tilt .....	29
6.7.3	Antenna Get Tilt .....	30
6.7.4	Antenna Set Device Data .....	30
6.7.5	Antenna Get Device Data .....	31
6.7.6	Antenna Alarm Indication .....	32
6.7.7	Antenna Clear Active Alarms .....	32
6.7.8	Antenna Get Alarm Status .....	33
6.7.9	Antenna Get Number Of Antennas .....	34
6.7.10	Antenna Send Configuration Data .....	34
6.8	TMAAP Elementary procedures for TMA .....	35
6.8.1	TMA Set Mode .....	35
6.8.2	TMA Get Mode .....	36
6.8.3	TMA Get Supported Functions .....	36
6.8.4	TMA Set Gain .....	37
6.8.5	TMA Get Gain .....	38
6.8.6	TMA Set Device Data .....	39
6.8.7	TMA Get Device Data .....	40
6.8.8	TMA Alarm Indication .....	40
6.8.8.1	Further requirements .....	41
6.8.9	TMA Clear Active Alarms .....	41
6.8.10	TMA Get Alarm Status .....	42
6.8.11	TMA Get Number of Subunits .....	42
6.8.12	3GPP Clear Active Alarms and Get Alarm Status .....	43
6.8.13	TMA Get Supported Non-Linear Gain Values .....	43
7	Unknown elementary procedures .....	44
<b>Annex A (normative):      Return codes for secondary devices .....</b>		<b>45</b>
<b>Annex B (normative):      Assigned fields for additional data .....</b>		<b>46</b>
<b>Annex C (normative):      Procedure sequence for download of software to a secondary device.....</b>		<b>50</b>
<b>Annex D (informative):      Overview of elementary procedures.....</b>		<b>51</b>
<b>Annex E (informative):      I-frame and INFO-field format .....</b>		<b>52</b>
<b>Annex F (informative):      Change History .....</b>		<b>53</b>
History .....		54

---

## Foreword

This Technical Specification has been produced by the 3<sup>rd</sup> Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
  - 1 presented to TSG for information;
  - 2 presented to TSG for approval;
  - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

## 1 Scope

The present document specifies the *Remote Electrical Tilting Application Part (RETAP)* between the implementation specific O&M transport function and the RET Antenna Control unit function of the Node B/eNB. The document also specifies the *Tower Mounted Amplifier Application Part (TMAAP)* between the implementation specific O&M transport function and the TMA control function of the Node B/eNB. It defines the Iuant interface and its associated signaling procedures.

## 2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.

[1]	Void
[2]	Void
[3]	3GPP TS 25.462: "UTRAN Iuant Interface: Signalling Transport".
[4]	3GPP TS 25.461: "UTRAN Iuant Interface: Layer 1".

## 3 Definitions and abbreviations

### 3.1 Definitions

For the purposes of the present document, the following terms and definitions apply.

**Active alarm:** An alarm which has an alarm state that has been raised, but not cleared

**Alarm:** Persistent indication of a fault

**Alarm code:** A code that identifies a specific alarm. The alarm code set is a subset of the return code set. The alarm codes are listed in annex A of this TS

**Alarm state:** A condition or state in the existence of an alarm. Alarm states are raised and cleared

**ASCII character:** A character forming part of the International Reference Version of the 7-bit character set defined in ISO/IEC 646:1991

**Calibrate:** Exercise the antenna drive unit over its entire range of travel to ensure fault-free operation and synchronise the measured and actual beam tilt of the antenna

**Configuration data:** A stored table or function defining the relationship between the physical position of the drive and electrical beam tilt

**Data type:** A definition determining the value range and interpretation of a series of octets. The following specified data types are used in this TS: