

ETSI TS 124 008 V14.4.0 (2017-07)



**Digital cellular telecommunications system (Phase 2+) (GSM);
Universal Mobile Telecommunications System (UMTS);
LTE;
Mobile radio interface Layer 3 specification;
Core network protocols;
Stage 3
(3GPP TS 24.008 version 14.4.0 Release 14)**



Reference

RTS/TSGC-0124008ve40

Keywords

GSM,LTE,UMTS

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

The present document can be downloaded from:

<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the only prevailing document is the print of the Portable Document Format (PDF) version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSI/DeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://portal.etsi.org/People/CommitteeSupportStaff.aspx>

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2017.
All rights reserved.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members.
3GPP™ and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

oneM2M logo is protected for the benefit of its Members
GSM® and the GSM logo are trademarks registered and owned by the GSM Association.

Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Foreword

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Foreword.....	2
Modal verbs terminology.....	2
Foreword.....	28
Introduction	28
1 Scope	29
1.1 Scope of the Technical Specification	29
1.2 Application to the interface structures.....	29
1.3 Structure of layer 3 procedures.....	29
1.4 Test procedures	30
1.5 Use of logical channels in A/Gb mode.....	30
1.6 Overview of control procedures	30
1.6.1 List of procedures	30
1.7 Applicability of implementations	32
1.7.1 Voice Group Call Service (VGCS) and Voice Broadcast Service (VBS).....	32
1.7.2 General Packet Radio Service (GPRS)	32
1.7.2.1 Packet services in GSM (A/Gb mode only)	32
1.7.2.2 Packet services in Iu mode (Iu mode only)	33
1.8 Handling of NAS signalling low priority indication	33
1.9 Restrictions.....	34
2 References	34
2.1 Definitions and abbreviations.....	41
2.1.1 Random values.....	41
2.1.2 Vocabulary.....	41
3 Radio Resource management procedures.....	46
4 Elementary procedures for Mobility Management.....	46
4.1 General	46
4.1.1 MM and GMM procedures	47
4.1.1.1 Types of MM and GMM procedures	47
4.1.1.1.1 Integrity Checking of Signalling Messages in the Mobile Station (Iu mode only).....	48
4.1.1.1.1a Integrity protection for emergency call (Iu mode only).....	50
4.1.1.2 MM-GMM co-ordination for GPRS MS's	51
4.1.1.2.1 GPRS MS operating in mode A or B in a network that operates in mode I	51
4.1.1.2.2 GPRS MS operating in mode A or B in a network that operates in mode II	52
4.1.1.2A Coordination between GMM and EMM	52
4.1.1.3 Core Network System Information for MM (Iu mode only).....	52
4.1.1.4 Core Network System Information for GMM (Iu mode only).....	53
4.1.1.4.1 General	53
4.1.1.4.2 Control of Network Mode of Operation I.....	53
4.1.1.5 Access class control	53
4.1.1.6 Specific requirements for MS configured to use timer T3245	54
4.1.1.6A Specific requirements for the MS when receiving non-integrity protected reject messages	54
4.1.1.7 Handling of NAS level mobility management congestion control.....	59
4.1.1.8 Handling of security related parameters at switch on and switch off.....	60
4.1.1.9 Equivalent PLMNs list.....	60
4.1.1.10 Dedicated core network.....	61
4.1.2 MM sublayer states.....	61
4.1.2.1 MM sublayer states in the mobile station.....	61
4.1.2.1.1 Main states.....	61
4.1.2.1.2 Substates of the MM IDLE state	65
4.1.2.2 The update Status	67
4.1.2.3 MM sublayer states on the network side.....	67
4.1.3 GPRS mobility management (GMM) sublayer states.....	69

4.1.3.1	GMM states in the MS	69
4.1.3.1.1	Main states.....	69
4.1.3.1.2	Substates of state GMM-DEREGISTERED.....	70
4.1.3.1.3	Substates of state GMM-REGISTERED.....	70
4.1.3.2	GPRS update status.....	73
4.1.3.3	GMM mobility management states on the network side.....	73
4.1.3.3.1	Main States.....	74
4.1.3.3.2	Substates of state GMM-REGISTERED.....	74
4.2	Behaviour of the MS in MM Idle state, GMM-DEREGISTERED state and GMM-REGISTERED state.....	75
4.2.1	Primary Service State selection.....	75
4.2.1.1	Selection of the Service State after Power On.....	75
4.2.1.2	Other Cases.....	76
4.2.2	Detailed Description of the MS behaviour in MM IDLE State.....	76
4.2.2.1	Service State, NORMAL SERVICE.....	76
4.2.2.2	Service State, ATTEMPTING TO UPDATE.....	77
4.2.2.3	Service State, LIMITED SERVICE.....	77
4.2.2.4	Service State, NO IMSI.....	78
4.2.2.5	Service State, SEARCH FOR PLMN, NORMAL SERVICE.....	78
4.2.2.6	Service State, SEARCH FOR PLMN.....	79
4.2.2.7	Service State, RECEIVING GROUP CALL (NORMAL SERVICE).....	79
4.2.2.8	Service State, RECEIVING GROUP CALL (LIMITED SERVICE).....	79
4.2.2.9	Service State, eCALL INACTIVE.....	80
4.2.3	Service state when back to state MM IDLE from another state.....	80
4.2.4	Behaviour in state GMM-DEREGISTERED.....	81
4.2.4.1	Primary substate selection.....	81
4.2.4.1.1	Selection of the substate after power on or enabling the MS's GPRS capability.....	81
4.2.4.1.2	Other Cases.....	82
4.2.4.2	Detailed description of the MS behaviour in state GMM-DEREGISTERED.....	82
4.2.4.2.1	Substate, NORMAL-SERVICE.....	82
4.2.4.2.2	Substate, ATTEMPTING-TO-ATTACH.....	82
4.2.4.2.3	Substate, LIMITED-SERVICE.....	83
4.2.4.2.4	Substate, NO-IMSI.....	83
4.2.4.2.5	Substate, NO-CELL.....	83
4.2.4.2.6	Substate, PLMN-SEARCH.....	83
4.2.4.2.7	Substate, ATTACH-NEEDED.....	83
4.2.4.2.8	Substate, SUSPENDED (A/Gb mode only).....	83
4.2.4.3	Substate when back to state GMM-DEREGISTERED from another GMM state.....	83
4.2.5	Behaviour in state GMM-REGISTERED.....	84
4.2.5.1	Detailed description of the MS behaviour in state GMM-REGISTERED.....	84
4.2.5.1.1	Substate, NORMAL-SERVICE.....	84
4.2.5.1.2	Substate, SUSPENDED (A/Gb mode only).....	84
4.2.5.1.3	Substate, UPDATE-NEEDED.....	85
4.2.5.1.4	Substate, ATTEMPTING-TO-UPDATE.....	85
4.2.5.1.5	Substate, NO-CELL-AVAILABLE.....	85
4.2.5.1.6	Substate, LIMITED-SERVICE.....	86
4.2.5.1.7	Substate, ATTEMPTING-TO-UPDATE-MM.....	86
4.2.5.1.8	Substate, PLMN-SEARCH.....	86
4.3	MM common procedures.....	86
4.3.1	TMSI reallocation procedure.....	86
4.3.1.0	General.....	86
4.3.1.1	TMSI reallocation initiation by the network.....	87
4.3.1.2	TMSI reallocation completion by the mobile station.....	87
4.3.1.3	TMSI reallocation completion in the network.....	87
4.3.1.4	Abnormal cases in the mobile station.....	87
4.3.1.5	Abnormal cases on the network side.....	87
4.3.2	Authentication procedure.....	88
4.3.2a	Authentication procedure used for a UMTS authentication challenge.....	88
4.3.2b	Authentication Procedure used for a GSM authentication challenge.....	88
4.3.2.1	Authentication request by the network.....	89
4.3.2.2	Authentication response by the mobile station.....	89
4.3.2.3	Authentication processing in the network.....	90
4.3.2.3a	128-bit circuit-switched GSM ciphering key.....	90

4.3.2.4	Ciphering key sequence number	90
4.3.2.5	Authentication not accepted by the network	91
4.3.2.5.1	Authentication not accepted by the MS	92
4.3.2.6	Abnormal cases	92
4.3.2.6.1	MS behaviour towards a network that has failed the authentication procedure.....	95
4.3.2.7	Handling of keys at intersystem change from Iu mode to A/Gb mode	95
4.3.2.7a	Use of established security contexts.....	96
4.3.2.8	Handling of keys at intersystem change from A/Gb mode to Iu mode	97
4.3.2.9	Void.....	98
4.3.2.10	Derivation of keys at SRVCC or vSRVCC handover from S1 mode	98
4.3.2.10.0	General	98
4.3.2.10.1	PDN connection with integrity protection	98
4.3.2.10.2	PDN connection without integrity protection	98
4.3.2.11	Derivation of keys at SRVCC handover from Iu mode to Iu mode	98
4.3.2.11.1	PDN connection with integrity protection	98
4.3.2.11.2	PDN connection without integrity protection	99
4.3.2.12	Derivation of keys at SRVCC handover from Iu mode to A/Gb mode.....	100
4.3.2.12.1	PDN connection with integrity protection	100
4.3.2.12.2	PDN connection without integrity protection	101
4.3.2.13	Derivation of keys at CS to PS SRVCC handover from A/Gb mode to Iu mode	101
4.3.3	Identification procedure	103
4.3.3.0	General	103
4.3.3.1	Identity request by the network	103
4.3.3.2	Identification response by the mobile station	103
4.3.3.3	Abnormal cases in the mobile station.....	103
4.3.3.4	Abnormal cases on the network side	103
4.3.4	IMSI detach procedure.....	104
4.3.4.0	General	104
4.3.4.1	IMSI detach initiation by the mobile station	104
4.3.4.2	IMSI detach procedure in the network	105
4.3.4.3	IMSI detach completion by the mobile station.....	105
4.3.4.4	Abnormal cases	105
4.3.5	Abort procedure	105
4.3.5.1	Abort procedure initiation by the network	105
4.3.5.2	Abort procedure in the mobile station.....	106
4.3.6	MM information procedure.....	106
4.3.6.1	MM information procedure initiation by the network.....	106
4.3.6.2	MM information procedure in the mobile station	106
4.4	MM specific procedures	106
4.4.1	Location updating procedure	107
4.4.2	Periodic updating	108
4.4.3	IMSI attach procedure	109
4.4.4	Generic Location Updating procedure.....	110
4.4.4.1	Location updating initiation by the mobile station.....	110
4.4.4.1a	Network Request for Additional mobile station Capability Information	110
4.4.4.2	Identification request from the network	110
4.4.4.3	Authentication by the network	110
4.4.4.4	Security mode setting by the network	110
4.4.4.5	Location Update Attempt Counter	110
4.4.4.6	Location updating accepted by the network.....	111
4.4.4.7	Location updating not accepted by the network.....	113
4.4.4.8	Release of RR connection after location updating	115
4.4.4.9	Abnormal cases on the mobile station side	115
4.4.4.10	Abnormal cases on the network side.....	117
4.4.5	Void	118
4.4.6	Void	118
4.4.7	eCall inactivity procedure	118
4.5	Connection management sublayer service provision	118
4.5.1	MM connection establishment.....	119
4.5.1.1	MM connection establishment initiated by the mobile station.....	119
4.5.1.2	Abnormal cases	122
4.5.1.3	MM connection establishment initiated by the network	124

4.5.1.3.1	Mobile Terminating CM Activity.....	124
4.5.1.3.2	Mobile Originating CM Activity \$(CCBS)\$	125
4.5.1.3.3	Paging response in Iu mode (Iu mode only).....	126
4.5.1.3.4	Paging response for CS fallback.....	126
4.5.1.4	Abnormal cases.....	126
4.5.1.5	MM connection establishment for emergency calls.....	127
4.5.1.5a	MM connection establishment for emergency calls for CS fallback.....	127
4.5.1.6	Call re-establishment.....	128
4.5.1.6.1	Call re-establishment, initiation by the mobile station	128
4.5.1.6.2	Abnormal cases	130
4.5.1.7	Forced release during MO MM connection establishment	130
4.5.1.8	MM connection establishment due to SRVCC or vSRVCC handover	131
4.5.1.9	MM connection establishment due to Dual Radio Voice Call Continuity (DRVCC) access transfer	131
4.5.2	MM connection information transfer phase.....	131
4.5.2.1	Sending CM messages	132
4.5.2.2	Receiving CM messages	132
4.5.2.3	Abnormal cases.....	132
4.5.3	MM connection release.....	132
4.5.3.1	Release of associated RR connection.....	132
4.5.3.2	Uplink release in a voice group call.....	133
4.6	Receiving a MM STATUS message by a MM entity.....	133
4.7	Elementary mobility management procedures for GPRS services	133
4.7.1	General.....	133
4.7.1.1	Lower layer failure.....	133
4.7.1.2	Ciphering of messages (A/Gb mode only).....	133
4.7.1.2a	Integrity protection of layer 3 signalling messages (A/Gb mode only and when integrity protection is required).....	134
4.7.1.2a.1	General	134
4.7.1.2a.2	Integrity checking of GMM signalling messages in the MS	134
4.7.1.2a.3	Integrity checking of layer 3 signalling messages in the network.....	135
4.7.1.2a.4	Establishment of integrity protection of layer 3 signalling messages.....	135
4.7.1.2a.5	Optional establishment of integrity protection in the user plane	136
4.7.1.2a.6	Change of security keys.....	136
4.7.1.3	P-TMSI signature.....	137
4.7.1.4	Radio resource sublayer address handling	137
4.7.1.4.1	Radio resource sublayer address handling (A/Gb mode only).....	137
4.7.1.5	P-TMSI handling.....	138
4.7.1.5.1	P-TMSI handling in A/Gb mode	138
4.7.1.5.2	P-TMSI handling in Iu mode.....	139
4.7.1.5.3	Void.....	139
4.7.1.5.4	Void.....	139
4.7.1.6	Change of network mode of operation.....	139
4.7.1.6.1	Change of network mode of operation in A/Gb mode (A/Gb mode only)	139
4.7.1.6.2	Change of network mode of operation in Iu mode (Iu mode only)	140
4.7.1.6.3	Change of network mode of operation at Iu mode to A/Gb mode inter-system change.....	140
4.7.1.6.4	Change of network mode of operation at A/Gb mode to Iu mode inter-system change.....	141
4.7.1.7	Intersystem change between A/Gb mode and Iu mode.....	141
4.7.1.7a	Intersystem change from S1 mode to A/Gb mode or S1 mode to Iu mode with ISR activated	142
4.7.1.8	List of forbidden PLMNs for GPRS service	143
4.7.1.8a	Establishment of the PS signalling connection (Iu mode only).....	143
4.7.1.9	Release of the PS signalling connection (Iu mode only).....	144
4.7.1.10	Handling of 3GPP PS data off.....	144
4.7.2	GPRS Mobility management timers and UMTS PS signalling connection control.....	145
4.7.2.1	READY timer behaviour.....	145
4.7.2.1.1	READY timer behaviour (A/Gb mode only).....	145
4.7.2.1.2	Handling of READY timer in the MS in Iu mode and S1 mode	146
4.7.2.1.2a	Handling of READY timer in the network in Iu mode and S1 mode	146
4.7.2.2	Periodic routing area updating	147
4.7.2.3	PMM-IDLE mode and PMM-CONNECTED mode (Iu mode only)	149
4.7.2.4	Handling of <i>Force to standby</i> in Iu mode (Iu mode only).....	149
4.7.2.5	RA Update procedure for Signalling Connection Re-establishment (Iu mode only).....	149

4.7.2.6	Cell Update triggered by low layers.....	149
4.7.2.7	Handling of timer T3302.....	150
4.7.2.8	Handling of timer T3324 (A/Gb mode, Iu mode and S1 mode).....	150
4.7.2.9	Power saving mode.....	151
4.7.2.10	Extended idle-mode DRX cycle.....	152
4.7.2.11	Interaction between power saving mode and extended idle mode DRX cycle.....	152
4.7.2.12	Extended coverage for GSM.....	152
4.7.3	GPRS attach procedure.....	153
4.7.3.1	GPRS attach procedure for GPRS services.....	154
4.7.3.1.1	GPRS attach procedure initiation.....	155
4.7.3.1.2	GMM common procedure initiation.....	156
4.7.3.1.3	GPRS attach accepted by the network.....	156
4.7.3.1.4	GPRS attach not accepted by the network.....	160
4.7.3.1.4a	GPRS attach for emergency bearer services not accepted by the network (UTRAN Iu mode only).....	164
4.7.3.1.4b	Attach for initiating a PDN connection for emergency bearer services not accepted by the network (UTRAN Iu mode only).....	166
4.7.3.1.5	Abnormal cases in the MS.....	166
4.7.3.1.6	Abnormal cases on the network side.....	168
4.7.3.2	Combined GPRS attach procedure for GPRS and non-GPRS services.....	170
4.7.3.2.1	Combined GPRS attach procedure initiation.....	170
4.7.3.2.2	GMM Common procedure initiation.....	171
4.7.3.2.3	Combined GPRS attach accepted by the network.....	171
4.7.3.2.4	Combined GPRS attach not accepted by the network.....	173
4.7.3.2.5	Abnormal cases in the MS.....	177
4.7.3.2.6	Abnormal cases on the network side.....	178
4.7.4	GPRS detach procedure.....	178
4.7.4.0	General.....	178
4.7.4.1	MS initiated GPRS detach procedure.....	179
4.7.4.1.1	MS initiated GPRS detach procedure initiation.....	179
4.7.4.1.2	MS initiated GPRS detach procedure completion for GPRS services only.....	179
4.7.4.1.3	MS initiated combined GPRS detach procedure completion.....	179
4.7.4.1.4	Abnormal cases in the MS.....	180
4.7.4.1.5	Abnormal cases on the network side.....	182
4.7.4.2	Network initiated GPRS detach procedure.....	182
4.7.4.2.1	Network initiated GPRS detach procedure initiation.....	182
4.7.4.2.2	Network initiated GPRS detach procedure completion by the MS.....	182
4.7.4.2.3	Network initiated GPRS detach procedure completion by the network.....	187
4.7.4.2.4	Abnormal cases on the network side.....	187
4.7.5	Routing area updating procedure.....	188
4.7.5.1	Normal and periodic routing area updating procedure.....	190
4.7.5.1.1	Normal and periodic routing area updating procedure initiation.....	192
4.7.5.1.2	GMM Common procedure initiation.....	193
4.7.5.1.3	Normal and periodic routing area updating procedure accepted by the network.....	193
4.7.5.1.4	Normal and periodic routing area updating procedure not accepted by the network.....	200
4.7.5.1.4a	Routing area updating procedure for initiating a PDN connection for emergency bearer services not accepted by the network (UTRAN Iu mode only).....	206
4.7.5.1.5	Abnormal cases in the MS.....	206
4.7.5.1.6	Abnormal cases on the network side.....	210
4.7.5.2	Combined routing area updating procedure.....	212
4.7.5.2.0	General.....	212
4.7.5.2.1	Combined routing area updating procedure initiation.....	212
4.7.5.2.2	GMM Common procedure initiation.....	214
4.7.5.2.3	Combined routing area updating procedure accepted by the network.....	214
4.7.5.2.4	Combined routing area updating not accepted by the network.....	217
4.7.5.2.5	Abnormal cases in the MS.....	221
4.7.5.2.6	Abnormal cases on the network side.....	222
4.7.6	P-TMSI reallocation procedure.....	222
4.7.6.0	General.....	222
4.7.6.1	P-TMSI reallocation initiation by the network.....	223
4.7.6.2	P-TMSI reallocation completion by the MS.....	223
4.7.6.3	P-TMSI reallocation completion by the network.....	223

4.7.6.3A	Abnormal cases in the MS	223
4.7.6.4	Abnormal cases on the network side	223
4.7.7	Authentication and ciphering procedure	224
4.7.7a	Authentication and ciphering procedure used for UMTS authentication challenge	224
4.7.7b	Authentication and ciphering procedure used for GSM authentication challenge	225
4.7.7c	Change of the ciphering algorithm at PS Handover	226
4.7.7.1	Authentication and ciphering initiation by the network	226
4.7.7.2	Authentication and ciphering response by the MS	227
4.7.7.3	Authentication and ciphering completion by the network	230
4.7.7.3a	128-bit packet-switched GSM ciphering key	230
4.7.7.3b	128-bit packet-switched GSM integrity key (in A/Gb mode and only if MS supports integrity protection)	231
4.7.7.4	GPRS ciphering key sequence number	231
4.7.7.5	Authentication not accepted by the network	233
4.7.7.5.1	Authentication not accepted by the MS	233
4.7.7.6	Abnormal cases	234
4.7.7.6.1	MS behaviour towards a network that has failed the authentication procedure	238
4.7.7.7	Use of established security contexts	238
4.7.7.8	Handling of keys at intersystem change from Iu mode to A/Gb mode	239
4.7.7.9	Handling of keys at intersystem change from A/Gb mode to Iu mode	240
4.7.7.10	Handling of keys at intersystem change from S1 mode to Iu mode or A/Gb mode	240
4.7.8	Identification procedure	243
4.7.8.1	Identification initiation by the network	243
4.7.8.2	Identification response by the MS	243
4.7.8.3	Identification completion by the network	243
4.7.8.3a	Abnormal cases in the MS	243
4.7.8.4	Abnormal cases on the network side	243
4.7.9	Paging procedure	244
4.7.9.1	Paging for GPRS services	244
4.7.9.1.1	Paging for GPRS services using P-TMSI	244
4.7.9.1.2	Paging for GPRS services using IMSI	246
4.7.9.2	Paging for non-GPRS services	246
4.7.10	Receiving a GMM STATUS message by a GMM entity	246
4.7.11	Void	247
4.7.12	GMM Information procedure	247
4.7.12.1	GMM information procedure initiation by the network	247
4.7.12.2	GMM information procedure in the mobile station	247
4.7.13	Service Request procedure (Iu mode only)	247
4.7.13.1	Service Request procedure initiation	249
4.7.13.2	GMM common procedure initiation	249
4.7.13.3	Service request procedure accepted by the network	249
4.7.13.4	Service request procedure not accepted by the network	251
4.7.13.4a	Service request procedure for initiating a PDN connection for emergency bearer services not accepted by the network (UTRAN Iu mode only)	255
4.7.13.5	Abnormal cases in the MS	256
4.7.13.6	Abnormal cases on the network side	258
4.7.14	Void	259
5	Elementary procedures for circuit-switched Call Control	259
5.1	Overview	259
5.1.1	General	259
5.1.2	Call Control States	267
5.1.2.1	Call states at the mobile station side of the interface	267
5.1.2.1.1	Null (State U0)	267
5.1.2.1.2	MM Connection pending (U0.1)	267
5.1.2.1.2a	CC prompt present (U0.2) \$(CCBS)\$	267
5.1.2.1.2b	Wait for network information (U0.3) \$(CCBS)\$	267
5.1.2.1.2c	CC-Establishment present (U0.4) \$(CCBS)\$	268
5.1.2.1.2d	CC-Establishment confirmed (U0.5) \$(CCBS)\$	268
5.1.2.1.2e	Recall present (U0.6) \$(CCBS)\$	268
5.1.2.1.3	Call initiated (U1)	268
5.1.2.1.4	Mobile originating call proceeding (U3)	268

5.1.2.1.5	Call delivered (U4).....	268
5.1.2.1.6	Call present (U6).....	268
5.1.2.1.7	Call received (U7).....	268
5.1.2.1.8	Connect Request (U8).....	268
5.1.2.1.9	Mobile terminating call confirmed (U9).....	268
5.1.2.1.10	Active (U10).....	268
5.1.2.1.11	Disconnect request (U11).....	269
5.1.2.1.12	Disconnect indication (U12).....	269
5.1.2.1.13	Release request (U19).....	269
5.1.2.1.14	Mobile originating modify (U26).....	269
5.1.2.1.15	Mobile terminating modify (U27).....	269
5.1.2.2	Network call states.....	269
5.1.2.2.1	Null (State N0).....	269
5.1.2.2.2	MM connection pending (N0.1).....	269
5.1.2.2.2a	CC connection pending (N0.2) \$(CCBS)\$.....	269
5.1.2.2.2b	Network answer pending (N0.3) \$(CCBS)\$.....	269
5.1.2.2.2c	CC-Establishment present (N0.4) \$(CCBS)\$.....	269
5.1.2.2.2d	CC-Establishment confirmed (N0.5) \$(CCBS)\$.....	269
5.1.2.2.2e	Recall present (N0.6) \$(CCBS)\$.....	270
5.1.2.2.3	Call initiated (N1).....	270
5.1.2.2.4	Mobile originating call proceeding (N3).....	270
5.1.2.2.5	Call delivered (N4).....	270
5.1.2.2.6	Call present (N6).....	270
5.1.2.2.7	Call received (N7).....	270
5.1.2.2.8	Connect request (N8).....	270
5.1.2.2.9	Mobile terminating call confirmed (N9).....	270
5.1.2.2.10	Active (N10).....	270
5.1.2.2.11	Not used.....	270
5.1.2.2.12	Disconnect indication (N12).....	270
5.1.2.2.13	Release request (N19).....	270
5.1.2.2.14	Mobile originating modify (N26).....	271
5.1.2.2.15	Mobile terminating modify (N27).....	271
5.1.2.2.16	Connect Indication (N28).....	271
5.2	Call establishment procedures.....	271
5.2.1	Mobile originating call establishment.....	271
5.2.1.1	Call initiation.....	272
5.2.1.2	Receipt of a setup message.....	273
5.2.1.3	Receipt of a CALL PROCEEDING message.....	274
5.2.1.4	Notification of progressing mobile originated call.....	275
5.2.1.4.1	Notification of interworking in connection with mobile originated call establishment.....	275
5.2.1.4.2	Call progress in the PLMN/ISDN environment.....	275
5.2.1.5	Alerting.....	275
5.2.1.6	Call connected.....	276
5.2.1.7	Call rejection.....	277
5.2.1.8	Transit network selection.....	277
5.2.1.9	Traffic channel assignment at mobile originating call establishment.....	277
5.2.1.10	Call queuing at mobile originating call establishment.....	277
5.2.1.11	Speech Codec Selection.....	277
5.2.1.12	Cellular Text telephone Modem (CTM) selection.....	278
5.2.2	Mobile terminating call establishment.....	279
5.2.2.1	Call indication.....	279
5.2.2.2	Compatibility checking.....	279
5.2.2.3	Call confirmation.....	279
5.2.2.3.1	Response to SETUP.....	279
5.2.2.3.2	Receipt of CALL CONFIRMED and ALERTING by the network.....	280
5.2.2.3.3	Call failure procedures.....	281
5.2.2.3.4	Called mobile station clearing during mobile terminating call establishment.....	281
5.2.2.4	Notification of interworking in connection with mobile terminating call establishment.....	281
5.2.2.5	Call accept.....	282
5.2.2.6	Active indication.....	282
5.2.2.7	Traffic channel assignment at mobile terminating call establishment.....	282
5.2.2.8	Call queuing at mobile terminating call establishment.....	283

5.2.2.9	User connection attachment during a mobile terminating call	283
5.2.2.10	Speech Codec Selection	283
5.2.2.11	Cellular Text telephone Modem (CTM) selection	283
5.2.3	Network initiated MO call \$(CCBS)\$	283
5.2.3.1	Initiation	283
5.2.3.2	CC-Establishment present	284
5.2.3.2.1	Recall Alignment Procedure	285
5.2.3.3	CC-Establishment confirmation	286
5.2.3.4	Recall present	286
5.2.3.5	Traffic channel assignment during network initiated mobile originating call establishment	287
5.2.4	Call establishment for SRVCC or vSRVCC	287
5.2.4.1	General	287
5.2.4.2	Call activation for SRVCC	287
5.2.4.2a	Call activation for vSRVCC	288
5.2.4.2b	Multimedia CAT and vSRVCC handover	289
5.2.4.3	Traffic channel assignment and user connection attachment	289
5.2.4.4	State verification	290
5.3	Signalling procedures during the "active" state	290
5.3.1	User notification procedure	290
5.3.2	Call rearrangements	290
5.3.3	Codec Change Procedure	290
5.3.4	Support of Dual Services	290
5.3.4.1	Service Description	290
5.3.4.2	Call establishment	291
5.3.4.2.1	Mobile Originating Establishment	291
5.3.4.2.2	Mobile Terminating Establishment	292
5.3.4.3	Changing the Call Mode	292
5.3.4.3.1	Initiation of in-call modification	292
5.3.4.3.2	Successful completion of in-call modification	293
5.3.4.3.3	Change of the channel configuration	294
5.3.4.3.4	Failure of in-call modification	294
5.3.4.4	Abnormal procedures	294
5.3.5	User initiated service level up- and downgrading (A/Gb mode and GERAN Iu mode only)	295
5.3.5.1	Initiation of service level up- and downgrading	295
5.3.5.2	Successful completion of service level up- and downgrading	295
5.3.5.3	Rejection of service level up- and downgrading	296
5.3.5.4	Time-out recovery	296
5.3.6	Support of multimedia calls	296
5.3.6.1	Service description	296
5.3.6.2	Call establishment	296
5.3.6.2.1	Mobile originated multimedia call establishment	296
5.3.6.2.2	Mobile terminating multimedia call	297
5.3.6.2.2.1	Fallback to speech	298
5.3.6.3	In-call modification in the "active" state	298
5.3.6.3.1	Void	299
5.3.6.3.2	Void	299
5.3.6.3.3	Void	299
5.3.6.4	Multimedia CAT during the alerting phase of a mobile originated call	299
5.3.6.5	DTMF transmission during a multimedia call	300
5.3.6.6	vSRVCC handover to a circuit-switched multimedia call	300
5.4	Call clearing	300
5.4.1	Terminology	300
5.4.2	Exception conditions	300
5.4.3	Clearing initiated by the mobile station	301
5.4.3.1	Initiation of call clearing	301
5.4.3.2	Receipt of a DISCONNECT message from the mobile station	301
5.4.3.3	Receipt of a RELEASE message from the network	301
5.4.3.4	Receipt of a RELEASE COMPLETE message from the mobile station	301
5.4.3.5	Abnormal cases	301
5.4.4	Clearing initiated by the network	302
5.4.4.1	Clearing initiated by the network: mobile does not support "Prolonged Clearing Procedure"	302
5.4.4.1.1	Clearing when tones/announcements provided	302

5.4.4.1.2	Clearing when tones/announcements not provided	302
5.4.4.1.3	Completion of clearing	303
5.4.4.2	Clearing initiated by the network: mobile supports "Prolonged Clearing Procedure"	303
5.4.4.2.1	Clearing when tones/announcements provided and the network does not indicate that "CCBS activation is possible"	303
5.4.4.2.2	Clearing when the network indicates that "CCBS activation is possible"	304
5.4.4.2.3	Clearing when tones/announcements are not provided and the network does not indicate that "CCBS activation is possible"	305
5.4.4.2.4	Receipt of a RELEASE message from the mobile station	305
5.4.4.2.5	Completion of clearing	306
5.4.5	Call clearing for SRVCC from CS to PS	306
5.5	Miscellaneous procedures	306
5.5.1	In-band tones and announcements	306
5.5.2	Call collisions	307
5.5.3	Status procedures	307
5.5.3.1	Status enquiry procedure	307
5.5.3.2	Reception of a STATUS message by a CC entity	308
5.5.3.2.1	STATUS message with incompatible state	308
5.5.3.2.2	STATUS message with compatible state	308
5.5.4	Call re-establishment, mobile station side	308
5.5.4.1	Indication from the mobility management sublayer	308
5.5.4.2	Reaction of call control	308
5.5.4.3	Completion of re-establishment	309
5.5.4.4	Unsuccessful outcome	309
5.5.5	Call re-establishment, network side	309
5.5.5.1	State alignment	309
5.5.6	Progress	309
5.5.7	DTMF protocol control procedure	309
5.5.7.1	Start DTMF request by the mobile station	310
5.5.7.2	Start DTMF response by the network	310
5.5.7.3	Stop DTMF request by the mobile station	310
5.5.7.4	Stop DTMF response by the network	310
5.5.7.5	Sequencing of subsequent start DTMF requests by the mobile station	310
6	Support for packet services	311
6.1	GPRS Session management	311
6.1.1	General	311
6.1.2	Session management states	312
6.1.2.1	Session management states in the MS	312
6.1.2.1.1	PDP-INACTIVE	312
6.1.2.1.2	PDP-ACTIVE-PENDING	312
6.1.2.1.3	PDP-INACTIVE-PENDING	312
6.1.2.1.4	PDP-ACTIVE	312
6.1.2.1.5	PDP-MODIFY_PENDING	312
6.1.2.1.6	MBMS-ACTIVE-PENDING	312
6.1.2.1.7	MBMS-ACTIVE	312
6.1.2.2	Session management states on the network side	314
6.1.2.2.1	PDP-INACTIVE	314
6.1.2.2.2	PDP-ACTIVE-PENDING	314
6.1.2.2.3	PDP-INACTIVE-PENDING	314
6.1.2.2.4	PDP-ACTIVE	314
6.1.2.2.5	PDP-MODIFY-PENDING	314
6.1.2.2.6	MBMS-ACTIVE-PENDING	315
6.1.2.2.7	MBMS-INACTIVE-PENDING	315
6.1.2.2.8	MBMS-ACTIVE	315
6.1.2A	PDP address allocation	316
6.1.2A.1	General	316
6.1.2A.1.1	Interworking with PDN based on IP	316
6.1.2A.1.2	Interworking with PDN based on PPP	316
6.1.2A.2	IP address allocation via NAS signalling	317
6.1.3	Session Management procedures	317
6.1.3.0	General	317

6.1.3.1	PDP context activation.....	317
6.1.3.1.1	Successful PDP context activation initiated by the mobile station.....	318
6.1.3.1.2	Successful PDP context activation requested by the network.....	321
6.1.3.1.3	Unsuccessful PDP context activation initiated by the MS.....	321
6.1.3.1.3.1	General.....	321
6.1.3.1.3.2	Handling of network rejection due to SM cause #26.....	322
6.1.3.1.3.3	Handling of network rejection due to SM cause other than SM cause #26.....	324
6.1.3.1.3A	Void.....	327
6.1.3.1.4	Unsuccessful PDP context activation requested by the network.....	327
6.1.3.1.5	Abnormal cases.....	327
6.1.3.1.6	Handling Activate PDP context request for MS configured for dual priority.....	329
6.1.3.2	Secondary PDP Context Activation Procedure.....	330
6.1.3.2.1	Successful Secondary PDP Context Activation Procedure Initiated by the MS.....	330
6.1.3.2.1a	Successful Secondary PDP Context Activation Procedure Requested by the network.....	331
6.1.3.2.2	Unsuccessful Secondary PDP Context Activation Procedure initiated by the MS.....	332
6.1.3.2.2.1	General.....	332
6.1.3.2.2.2	Handling of network rejection due to SM cause #26.....	332
6.1.3.2.2.3	Handling of network rejection due to SM cause other than SM cause #26.....	334
6.1.3.2.2a	Unsuccessful secondary PDP context activation requested by the network.....	335
6.1.3.2.3	Abnormal cases.....	336
6.1.3.3	PDP context modification procedure.....	339
6.1.3.3.1	Network initiated PDP Context Modification.....	340
6.1.3.3.2	MS initiated PDP Context Modification accepted by the network.....	341
6.1.3.3.3	MS initiated PDP Context Modification not accepted by the network.....	342
6.1.3.3.3.1	General.....	342
6.1.3.3.3.2	Handling of network rejection due to SM cause #26.....	343
6.1.3.3.3.3	Handling of network rejection due to SM cause other than SM cause #26.....	344
6.1.3.3.3a	Network initiated PDP Context Modification not accepted by the MS.....	345
6.1.3.3.4	Abnormal cases.....	346
6.1.3.4	PDP context deactivation procedure.....	351
6.1.3.4.1	PDP context deactivation initiated by the MS.....	351
6.1.3.4.2	PDP context deactivation initiated by the network.....	352
6.1.3.4.3	Abnormal cases.....	354
6.1.3.4a	Void.....	355
6.1.3.5	Void.....	355
6.1.3.5a	Notification procedure.....	355
6.1.3.5a.1	General.....	355
6.1.3.5a.2	Notification procedure initiation by the network.....	355
6.1.3.5a.3	Notification procedure in the MS.....	356
6.1.3.6	Receiving a SM STATUS message by a SM entity.....	356
6.1.3.7	Protocol configuration options.....	357
6.1.3.8	MBMS context activation.....	357
6.1.3.8.1	Successful MBMS context activation.....	358
6.1.3.8.2	Unsuccessful MBMS context activation requested by the MS.....	358
6.1.3.8.2.1	General.....	358
6.1.3.8.2.2	Handling of network rejection due to SM cause #26.....	358
6.1.3.8.2.3	Handling of network rejection due to SM cause other than SM cause #26.....	359
6.1.3.8.3	Unsuccessful MBMS context activation requested by the network.....	360
6.1.3.8.4	Abnormal cases.....	361
6.1.3.9	MBMS context deactivation.....	361
6.1.3.9.1	MBMS context deactivation initiated by the network.....	362
6.1.3.9.2	Abnormal cases.....	362
6.1.3.10	MBMS protocol configuration options.....	362
6.1.3.11	Handling of APN based congestion control.....	362
6.1.3.11A	Handling of group specific session management congestion control.....	363
6.1.3.12	Handling session management request for MS configured for dual priority.....	363
6.1.3.13	Handling of network rejection not due to APN based congestion control.....	364
6.1.3.14	Handling of WLAN offload control.....	364
6.2	void.....	364
6.3	Coordination between SM and GMM for supporting ISR.....	364
6.4	MSISDN notification procedure.....	365

7	Examples of structured procedures	365
8	Handling of unknown, unforeseen, and erroneous protocol data	365
8.1	General	365
8.2	Message too short	366
8.3	Unknown or unforeseen transaction identifier	366
8.3.1	Call Control	366
8.3.2	Session Management	367
8.4	Unknown or unforeseen message type	368
8.5	Non-semantic mandatory information element errors	368
8.5.1	Radio resource management	369
8.5.2	Mobility management	369
8.5.3	Call control	369
8.5.4	GMM mobility management	369
8.5.5	Session management	369
8.6	Unknown and unforeseen IEs in the non-imperative message part	370
8.6.1	IEs unknown in the message	370
8.6.2	Out of sequence IEs	370
8.6.3	Repeated IEs	370
8.7	Non-imperative message part errors	370
8.7.1	Syntactically incorrect optional IEs	370
8.7.2	Conditional IE errors	370
8.8	Messages with semantically incorrect contents	371
9	Message functional definitions and contents	371
9.1	Messages for Radio Resources management	372
9.2	Messages for mobility management	372
9.2.1	Authentication reject	373
9.2.2	Authentication request	374
9.2.2.1	Authentication Parameter AUTN	374
9.2.3	Authentication response	374
9.2.3.1	Authentication Response Parameter	375
9.2.3.2	Authentication Response Parameter (extension)	375
9.2.3a	Authentication Failure	375
9.2.3a.1	Authentication Failure parameter	375
9.2.4	CM Re-establishment request	376
9.2.4.1	Location area identification	376
9.2.4.2	Mobile Station Classmark	376
9.2.4.3	Device properties	376
9.2.5	CM service accept	376
9.2.5a	CM service prompt \$(CCBS)\$	377
9.2.6	CM service reject	377
9.2.6.1	T3246 value	378
9.2.7	CM service abort	378
9.2.8	Abort	378
9.2.9	CM service request	379
9.2.9.1	Mobile Station Classmark	379
9.2.9.2	Priority	379
9.2.9.3	Additional update parameters	379
9.2.9.4	Device properties	380
9.2.10	Identity request	380
9.2.11	Identity response	380
9.2.12	IMSI detach indication	381
9.2.12.1	Mobile Station Classmark	381
9.2.13	Location updating accept	381
9.2.13.1	Follow on proceed	382
9.2.13.2	CTS permission	382
9.2.13.3	Equivalent PLMNs	382
9.2.13.4	Emergency Number List	382
9.2.13.5	Per MS T3212	382
9.2.14	Location updating reject	382
9.2.14.1	T3246 value	383

9.2.15	Location updating request.....	383
9.2.15.1	Location area identification.....	384
9.2.15.2	Mobile Station Classmark.....	384
9.2.15.3	Mobile Station Classmark for Iu mode.....	384
9.2.15.4	Additional update parameters.....	384
9.2.15.5	Device properties.....	384
9.2.15.6	MS network feature support.....	384
9.2.15a	MM information.....	384
9.2.15a.1	Full name for network.....	385
9.2.15a.2	Short name for network.....	385
9.2.15a.3	Local time zone.....	385
9.2.15a.4	Universal time and local time zone.....	385
9.2.15a.5	LSA Identity.....	385
9.2.15a.6	Network Daylight Saving Time.....	385
9.2.16	MM Status.....	385
9.2.17	TMSI reallocation command.....	386
9.2.18	TMSI reallocation complete.....	386
9.2.19	MM Null.....	386
9.3	Messages for circuit-switched call control.....	387
9.3.1	Alerting.....	388
9.3.1.1	Alerting (network to mobile station direction).....	388
9.3.1.1.1	Facility.....	388
9.3.1.1.2	Progress indicator.....	388
9.3.1.1.3	User-user.....	388
9.3.1.2	Alerting (mobile station to network direction).....	388
9.3.1.2.1	Facility.....	389
9.3.1.2.2	User-user.....	389
9.3.1.2.3	SS version.....	389
9.3.2	Call confirmed.....	389
9.3.2.1	Repeat indicator.....	390
9.3.2.2	Bearer capability 1 and bearer capability 2.....	390
9.3.2.3	Cause.....	391
9.3.2.4	CC Capabilities.....	391
9.3.2.5	Stream Identifier.....	391
9.3.2.6	Supported Codecs.....	391
9.3.3	Call proceeding.....	391
9.3.3.1	Repeat indicator.....	391
9.3.3.2	Bearer capability 1 and bearer capability 2.....	392
9.3.3.3	Facility.....	392
9.3.3.4	Progress Indicator.....	392
9.3.3.5	Priority granted.....	392
9.3.3.6	Network Call Control Capabilities.....	392
9.3.4	Congestion control.....	392
9.3.4.1	Cause.....	393
9.3.5	Connect.....	393
9.3.5.1	Connect (network to mobile station direction).....	393
9.3.5.1.1	Facility.....	393
9.3.5.1.2	Progress indicator.....	393
9.3.5.1.3	User-user.....	393
9.3.5.2	Connect (mobile station to network direction).....	393
9.3.5.2.1	Facility.....	394
9.3.5.2.2	User-user.....	394
9.3.5.2.3	SS version.....	394
9.3.5.2.4	Stream Identifier.....	394
9.3.6	Connect acknowledge.....	394
9.3.7	Disconnect.....	395
9.3.7.1	Disconnect (network to mobile station direction).....	395
9.3.7.1.1	Facility.....	395
9.3.7.1.2	Progress indicator.....	395
9.3.7.1.3	User-user.....	395
9.3.7.1.4	Allowed actions \$(CCBS)\$.....	395
9.3.7.2	Disconnect (mobile station to network direction).....	396

9.3.7.2.1	Facility.....	396
9.3.7.2.2	User-user	396
9.3.7.2.3	SS version.....	396
9.3.8	Emergency setup.....	396
9.3.8.1	Bearer capability	397
9.3.8.2	Stream Identifier	397
9.3.8.3	Supported Codecs	397
9.3.8.4	Emergency category.....	397
9.3.9	Facility	397
9.3.9.1	Facility (network to mobile station direction).....	397
9.3.9.2	Facility (mobile station to network direction).....	398
9.3.9.2.1	SS version.....	398
9.3.10	Hold	399
9.3.11	Hold Acknowledge	399
9.3.12	Hold Reject.....	399
9.3.13	Modify	400
9.3.13.1	Low layer compatibility	400
9.3.13.2	High layer compatibility	400
9.3.13.3	Reverse call setup direction.....	400
9.3.13.4	Void.....	401
9.3.13.5	Network-initiated Service Upgrade indicator.....	401
9.3.14	Modify complete.....	401
9.3.14.1	Low layer compatibility	401
9.3.14.2	High layer compatibility	401
9.3.14.3	Reverse call setup direction.....	401
9.3.15	Modify reject	401
9.3.15.1	Low layer compatibility	402
9.3.15.2	High layer compatibility	402
9.3.16	Notify.....	402
9.3.17	Progress	402
9.3.17.1	User-user	403
9.3.17.2	Progress indicator.....	403
9.3.17a	CC-Establishment \$(CCBS)\$	403
9.3.17a.1	Void.....	404
9.3.17a.2	Setup container.....	404
9.3.17b	CC-Establishment confirmed \$(CCBS)\$	404
9.3.17b.1	Repeat indicator	404
9.3.17b.2	Bearer capability 1 and bearer capability 2	405
9.3.17b.3	Cause.....	405
9.3.17b.4	Supported Codecs	405
9.3.18	Release.....	405
9.3.18.1	Release (network to mobile station direction).....	405
9.3.18.1.1	Cause	405
9.3.18.1.2	Second cause	405
9.3.18.1.3	Facility.....	406
9.3.18.1.4	User-user	406
9.3.18.2	Release (mobile station to network direction).....	406
9.3.18.2.1	Cause	406
9.3.18.2.2	Second cause	406
9.3.18.2.3	Facility.....	406
9.3.18.2.4	User-user	407
9.3.18.2.5	SS version.....	407
9.3.18a	Recall \$(CCBS)\$	407
9.3.18a.1	Recall Type	407
9.3.18a.2	Facility	407
9.3.19	Release complete	407
9.3.19.1	Release complete (network to mobile station direction).....	407
9.3.19.1.1	Cause	408
9.3.19.1.2	Facility.....	408
9.3.19.1.3	User-user	408
9.3.19.2	Release complete (mobile station to network direction)	408
9.3.19.2.1	Cause	409

9.3.19.2.2	Facility.....	409
9.3.19.2.3	User-user	409
9.3.19.2.4	SS version.....	409
9.3.20	Retrieve.....	409
9.3.21	Retrieve Acknowledge.....	410
9.3.22	Retrieve Reject.....	410
9.3.23	Setup	411
9.3.23.1	Setup (mobile terminated call establishment)	411
9.3.23.1.1	BC repeat indicator.....	412
9.3.23.1.2	Bearer capability 1 and bearer capability 2	413
9.3.23.1.3	Facility.....	413
9.3.23.1.4	Progress indicator	413
9.3.23.1.4a	Called party BCD number	413
9.3.23.1.5	Called party subaddress	413
9.3.23.1.6	LLC repeat indicator.....	413
9.3.23.1.7	Low layer compatibility I	413
9.3.23.1.8	Low layer compatibility II.....	413
9.3.23.1.9	HLC repeat indicator	413
9.3.23.1.10	High layer compatibility i.....	413
9.3.23.1.11	High layer compatibility ii.....	414
9.3.23.1.12	User-user	414
9.3.23.1.13	Redirecting party BCD number.....	414
9.3.23.1.14	Redirecting party subaddress	414
9.3.23.1.15	Priority.....	414
9.3.23.1.16	Alert \$(Network Indication of Alerting in the MS)\$	414
9.3.23.1.17	Network Call Control Capabilities	414
9.3.23.1.18	Cause of No CLI.....	414
9.3.23.1.19	Backup bearer capability	414
9.3.23.2	Setup (mobile originating call establishment).....	414
9.3.23.2.1	BC repeat indicator.....	415
9.3.23.2.2	Facility.....	416
9.3.23.2.3	LLC repeat indicator.....	416
9.3.23.2.4	Low layer compatibility I	416
9.3.23.2.5	Low layer compatibility II.....	416
9.3.23.2.6	HLC repeat indicator	416
9.3.23.2.7	High layer compatibility i.....	416
9.3.23.2.8	High layer compatibility ii.....	416
9.3.23.2.9	User-user	416
9.3.23.2.10	SS version.....	416
9.3.23.2.11	CLIR suppression	416
9.3.23.2.12	CLIR invocation	417
9.3.23.2.13	CC Capabilities.....	417
9.3.23.2.14	Stream Identifier	417
9.3.23.2.15	Bearer capability 1 and bearer capability 2	417
9.3.23.2.16	Supported Codecs.....	417
9.3.23.2.17	Redial	417
9.3.23a	Start CC \$(CCBS)\$.....	417
9.3.23a.1	CC Capabilities	417
9.3.24	Start DTMF.....	418
9.3.25	Start DTMF Acknowledge.....	418
9.3.25.1	Keypad facility.....	418
9.3.26	Start DTMF reject.....	418
9.3.27	Status	419
9.3.27.1	Auxiliary states	419
9.3.28	Status enquiry	419
9.3.29	Stop DTMF.....	420
9.3.30	Stop DTMF acknowledge.....	420
9.3.31	User information.....	421
9.3.31.1	User-user	421
9.3.31.2	More data	421
9.4	GPRS Mobility Management Messages.....	421
9.4.1	Attach request.....	421

9.4.1.1	Old P-TMSI signature	423
9.4.1.2	Requested READY timer value	423
9.4.1.3	TMSI status	423
9.4.1.4	PS LCS Capability	423
9.4.1.5	UE network capability	423
9.4.1.6	Mobile station classmark 2	423
9.4.1.7	Mobile station classmark 3	423
9.4.1.8	Supported Codecs	423
9.4.1.9	Additional mobile identity	423
9.4.1.10	Additional old routing area identification	423
9.4.1.11	Voice domain preference and UE's usage setting	423
9.4.1.12	Device properties	424
9.4.1.13	P-TMSI type	424
9.4.1.14	MS network feature support	424
9.4.1.15	Old location area identification	424
9.4.1.16	Additional update type	424
9.4.1.17	TMSI based NRI container	424
9.4.1.18	T3324 value	424
9.4.1.19	T3312 extended value	424
9.4.1.20	Extended DRX parameters	424
9.4.2	Attach accept	424
9.4.2.1	P-TMSI signature	427
9.4.2.2	Negotiated READY timer value	427
9.4.2.3	Allocated P-TMSI	427
9.4.2.4	MS identity	427
9.4.2.5	GMM cause	427
9.4.2.6	T3302 value	427
9.4.2.7	Cell Notification (A/Gb mode only)	427
9.4.2.8	Equivalent PLMNs	427
9.4.2.9	Network feature support	427
9.4.2.10	Emergency Number List	427
9.4.2.11	Requested MS Information	427
9.4.2.12	T3319 value	427
9.4.2.13	T3323 value	427
9.4.2.14	T3312 extended value	428
9.4.2.15	Additional network feature support	428
9.4.2.16	T3324 value	428
9.4.2.17	Extended DRX parameters	428
9.4.2.18	User Plane integrity indicator	428
9.4.2.19	Replayed MS network capability	428
9.4.2.20	Replayed MS radio access capability	428
9.4.2.21	DCN-ID	428
9.4.2.22	PLMN identity of the CN operator	428
9.4.2.23	Non-3GPP NW provided policies	428
9.4.3	Attach complete	428
9.4.3.1	Inter RAT handover information	429
9.4.3.2	E-UTRAN inter RAT handover information	429
9.4.4	Attach reject	429
9.4.4.1	T3302 value	429
9.4.4.2	T3346 value	430
9.4.5	Detach request	430
9.4.5.1	Detach request (mobile terminated detach)	430
9.4.5.1.1	GMM cause	430
9.4.5.2	Detach request (mobile originating detach)	430
9.4.5.2.1	P-TMSI	431
9.4.5.2.2	P-TMSI signature	431
9.4.6	Detach accept	431
9.4.6.1	Detach accept (mobile terminated detach)	431
9.4.6.2	Detach accept (mobile originating detach)	431
9.4.7	P-TMSI reallocation command	432
9.4.7.1	P-TMSI signature	432
9.4.7.2	DCN-ID	432

9.4.8	P-TMSI reallocation complete	432
9.4.9	Authentication and ciphering request	433
9.4.9.1	Authentication Parameter RAND	433
9.4.9.2	GPRS ciphering key sequence number	434
9.4.9.3	Authentication Parameter AUTN	434
9.4.9.4	Replayed MS network capability	434
9.4.9.5	Integrity algorithm	434
9.4.9.6	Message authentication code	434
9.4.9.7	Replayed MS Radio Access Capability	434
9.4.10	Authentication and ciphering response	434
9.4.10.1	Authentication Response Parameter	435
9.4.10.2	IMEISV	435
9.4.10.3	Authentication Response Parameter (extension)	435
9.4.10.4	Message authentication code	435
9.4.10a	Authentication and Ciphering Failure	435
9.4.10a.1	Authentication Failure parameter	436
9.4.11	Authentication and ciphering reject	436
9.4.12	Identity request	436
9.4.13	Identity response	437
9.4.14	Routing area update request	437
9.4.14.1	Old P-TMSI signature	440
9.4.14.2	Requested READY timer value	440
9.4.14.3	DRX parameter	440
9.4.14.4	TMSI status	440
9.4.14.5	P-TMSI (Iu mode only)	440
9.4.14.6	MS network capability	440
9.4.14.7	PDP context status	440
9.4.14.8	PS LCS Capability	440
9.4.14.9	MBMS context status	440
9.4.14.10	Additional mobile identity	440
9.4.14.11	Additional old routing area identification	440
9.4.14.12	UE network capability	440
9.4.14.13	Mobile station classmark 2	440
9.4.14.14	Mobile station classmark 3	441
9.4.14.15	Supported Codecs	441
9.4.14.16	Voice domain preference and UE's usage setting	441
9.4.14.17	P-TMSI type	441
9.4.14.18	Device properties	441
9.4.14.19	MS network feature support	441
9.4.14.20	Old location area identification	441
9.4.14.21	Additional update type	441
9.4.14.22	TMSI based NRI container	441
9.4.14.23	T3324 value	441
9.4.14.24	T3312 extended value	441
9.4.14.25	Extended DRX parameters	441
9.4.15	Routing area update accept	442
9.4.15.1	P-TMSI signature	445
9.4.15.2	Allocated P-TMSI	445
9.4.15.3	MS identity	445
9.4.15.4	List of Receive N-PDU Numbers	445
9.4.15.5	Negotiated READY timer value	445
9.4.15.6	GMM cause	445
9.4.15.7	T3302 value	445
9.4.15.8	Cell Notification (A/Gb mode only)	445
9.4.15.9	Equivalent PLMNs	445
9.4.15.10	PDP context status	445
9.4.15.11	Network feature support	446
9.4.15.12	Emergency Number List	446
9.4.15.13	MBMS context status	446
9.4.15.14	Requested MS Information	446
9.4.15.15	T3319 value	446
9.4.15.16	T3323 value	446

9.4.15.17	T3312 extended value	446
9.4.15.18	Additional network feature support.....	446
9.4.15.19	T3324 value.....	446
9.4.15.20	Extended DRX parameters.....	446
9.4.15.21	User Plane integrity indicator.....	446
9.4.15.22	Replayed MS network capability	447
9.4.15.23	Replayed MS Radio Access Capability.....	447
9.4.15.24	DCN-ID.....	447
9.4.15.25	PLMN identity of the CN operator	447
9.4.15.26	Non-3GPP NW provided policies	447
9.4.16	Routing area update complete.....	447
9.4.16.1	List of Receive N-PDU Numbers.....	448
9.4.16.2	Inter RAT handover information.....	448
9.4.16.3	E-UTRAN inter RAT handover information	448
9.4.17	Routing area update reject	448
9.4.17.1	T3302 value.....	448
9.4.17.2	T3346 value.....	448
9.4.18	GMM Status.....	449
9.4.19	GMM Information	449
9.4.19.1	Full name for network.....	449
9.4.19.2	Short name for network.....	450
9.4.19.3	Local time zone	450
9.4.19.4	Universal time and local time zone	450
9.4.19.5	LSA Identity.....	450
9.4.19.6	Network Daylight Saving Time	450
9.4.20	Service Request (Iu mode only).....	450
9.4.20.1	PDP context status	451
9.4.20.2	MBMS context status	451
9.4.20.3	Uplink data status.....	451
9.4.20.4	Device properties	451
9.4.21	Service Accept (Iu mode only).....	451
9.4.21.1	PDP context status	452
9.4.21.2	MBMS context status	452
9.4.22	Service Reject (Iu mode only)	452
9.4.22.1	T3346 value.....	452
9.5	GPRS Session Management Messages.....	452
9.5.1	Activate PDP context request	452
9.5.1.1	Access point name.....	453
9.5.1.2	Protocol configuration options	453
9.5.1.3	Request type.....	453
9.5.1.4	Device properties	453
9.5.1.5	NBIFOM container	454
9.5.1.6	Extended protocol configuration options	454
9.5.2	Activate PDP context accept.....	454
9.5.2.1	PDP address	454
9.5.2.2	Protocol configuration options	455
9.5.2.3	Packet Flow Identifier	455
9.5.2.4	SM cause	455
9.5.2.5	Connectivity type	455
9.5.2.6	WLAN offload indication	455
9.5.2.7	NBIFOM container	455
9.5.2.8	Extended protocol configuration options	455
9.5.3	Activate PDP context reject	455
9.5.3.1	Protocol configuration options	456
9.5.3.2	Back-off timer value	456
9.5.3.3	Re-attempt indicator.....	456
9.5.3.4	NBIFOM container	456
9.5.3.5	Extended protocol configuration options	456
9.5.4	Activate Secondary PDP Context Request	456
9.5.4.1	TFT	457
9.5.4.2	Protocol configuration options	457
9.5.4.3	Device properties	457

9.5.4.4	NBIFOM container	457
9.5.4.5	Extended protocol configuration options	457
9.5.5	Activate Secondary PDP Context Accept	458
9.5.5.1	Packet Flow Identifier	458
9.5.5.2	Protocol configuration options	458
9.5.5.3	WLAN offload indication	459
9.5.5.4	NBIFOM container	459
9.5.5.5	Extended protocol configuration options	459
9.5.6	Activate Secondary PDP Context Reject	459
9.5.6.1	Protocol configuration options	459
9.5.6.2	Back-off timer value	459
9.5.6.3	Re-attempt indicator	460
9.5.6.4	NBIFOM container	460
9.5.6.5	Extended protocol configuration options	460
9.5.7	Request PDP context activation	460
9.5.7.1	Protocol configuration options	460
9.5.7.2	NBIFOM container	460
9.5.7.3	Extended protocol configuration options	461
9.5.8	Request PDP context activation reject	461
9.5.8.1	Protocol configuration options	461
9.5.8.2	NBIFOM container	461
9.5.8.3	Extended protocol configuration options	461
9.5.9	Modify PDP context request (Network to MS direction)	461
9.5.9.1	PDP address	462
9.5.9.2	Packet Flow Identifier	462
9.5.9.3	Protocol configuration options	462
9.5.9.4	TFT	463
9.5.9.5	WLAN offload indication	463
9.5.9.6	NBIFOM container	463
9.5.9.7	Extended protocol configuration options	463
9.5.10	Modify PDP context request (MS to network direction)	463
9.5.10.1	Requested LLC SAPI	464
9.5.10.2	Requested new QoS	464
9.5.10.3	New TFT	464
9.5.10.4	Protocol configuration options	464
9.5.10.5	Device properties	464
9.5.10.6	NBIFOM container	464
9.5.10.7	Extended protocol configuration options	464
9.5.11	Modify PDP context accept (MS to network direction)	464
9.5.11.1	Protocol configuration options	465
9.5.11.2	NBIFOM container	465
9.5.11.3	Extended protocol configuration options	465
9.5.12	Modify PDP context accept (Network to MS direction)	465
9.5.12.1	Negotiated QoS	466
9.5.12.2	Negotiated LLC SAPI	466
9.5.12.3	New radio priority	466
9.5.12.4	Packet Flow Identifier	466
9.5.12.5	Protocol configuration options	466
9.5.12.6	WLAN offload indication	466
9.5.12.7	NBIFOM container	467
9.5.12.8	Extended protocol configuration options	467
9.5.13	Modify PDP Context Reject	467
9.5.13.1	Protocol configuration options	467
9.5.13.2	Back-off timer value	467
9.5.13.3	Re-attempt indicator	467
9.5.13.4	NBIFOM container	468
9.5.13.5	Extended protocol configuration options	468
9.5.14	Deactivate PDP context request	468
9.5.14.1	Tear down indicator	468
9.5.14.2	Protocol configuration options	468
9.5.14.3	MBMS protocol configuration options	469
9.5.14.4	T3396 value	469

9.5.14.5	WLAN offload indication	469
9.5.14.6	Void.....	469
9.5.14.7	Extended protocol configuration options	469
9.5.15	Deactivate PDP context accept.....	469
9.5.15.1	Protocol configuration options	469
9.5.15.2	MBMS protocol configuration options	470
9.5.15.3	Void.....	470
9.5.15.4	Extended protocol configuration options	470
9.5.15a	Request Secondary PDP Context Activation	470
9.5.15a.1	TFT	470
9.5.15a.2	Protocol configuration options	471
9.5.15a.3	WLAN offload indication	471
9.5.15a.4	NBIFOM container	471
9.5.15a.5	Extended protocol configuration options	471
9.5.15b	Request Secondary PDP Context Activation Reject.....	471
9.5.15b.1	Protocol configuration options	471
9.5.15b.2	NBIFOM container	471
9.5.15b.3	Extended protocol configuration options	472
9.5.16	Void.....	472
9.5.16a	Notification	472
9.5.17	Void	472
9.5.18	Void	472
9.5.19	Void	472
9.5.20	Void	472
9.5.21	SM Status.....	472
9.5.22	Activate MBMS Context Request	473
9.5.22.1	MBMS protocol configuration options	473
9.5.22.2	Device properties	473
9.5.23	Activate MBMS Context Accept.....	474
9.5.23.1	MBMS protocol configuration options	474
9.5.24	Activate MBMS Context Reject	474
9.5.24.1	MBMS protocol configuration options	475
9.5.24.2	Back-off timer value	475
9.5.24.3	Re-attempt indicator.....	475
9.5.25	Request MBMS Context Activation	475
9.5.25.1	Linked NSAPI.....	475
9.5.25.2	MBMS protocol configuration options	475
9.5.26	Request MBMS Context Activation Reject.....	475
9.5.26.1	MBMS protocol configuration options	476
10	General message format and information elements coding.....	476
10.1	Overview	476
10.2	Protocol Discriminator	477
10.3	Skip indicator and transaction identifier.....	477
10.3.1	Skip indicator.....	477
10.3.2	Transaction identifier.....	478
10.4	Message Type.....	478
10.5	Other information elements.....	482
10.5.1	Common information elements.....	483
10.5.1.1	Cell identity.....	483
10.5.1.2	Ciphering Key Sequence Number.....	484
10.5.1.3	Location Area Identification	484
10.5.1.4	Mobile Identity.....	486
10.5.1.5	Mobile Station Classmark 1	491
10.5.1.6	Mobile Station Classmark 2	494
10.5.1.7	Mobile Station Classmark 3	497
10.5.1.8	Spare Half Octet.....	513
10.5.1.9	Descriptive group or broadcast call reference	513
10.5.1.10	Group Cipher Key Number	514
10.5.1.10a	PD and SAPI \$(CCBS)\$	515
10.5.1.11	Priority Level	516
10.5.1.12	Core Network System Information (Iu mode only)	516

10.5.1.12.1	CN Common GSM-MAP NAS system information	516
10.5.1.12.2	CS domain specific system information	517
10.5.1.12.3	PS domain specific system information	517
10.5.1.13	PLMN list.....	518
10.5.1.14	NAS container for PS HO	519
10.5.1.15	MS network feature support.....	520
10.5.2	Radio Resource management information elements.....	521
10.5.3	Mobility management information elements.....	521
10.5.3.1	Authentication parameter RAND.....	521
10.5.3.1.1	Authentication Parameter AUTN (UMTS and EPS authentication challenge)	521
10.5.3.2	Authentication Response parameter.....	522
10.5.3.2.1	Authentication Response Parameter (extension) (UMTS authentication challenge only).....	523
10.5.3.2.2	Authentication Failure parameter (UMTS and EPS authentication challenge)	523
10.5.3.3	CM service type	524
10.5.3.4	Identity type	524
10.5.3.5	Location updating type.....	525
10.5.3.5a	Network Name	525
10.5.3.6	Reject cause.....	527
10.5.3.7	Follow-on Proceed	528
10.5.3.8	Time Zone	528
10.5.3.9	Time Zone and Time	529
10.5.3.10	CTS permission	530
10.5.3.11	LSA Identifier	531
10.5.3.12	Daylight Saving Time	531
10.5.3.13	Emergency Number List	532
10.5.3.14	Additional update parameters.....	533
10.5.3.15	Void.....	533
10.5.3.16	MM Timer.....	533
10.5.4	Call control information elements	534
10.5.4.1	Extensions of codesets	534
10.5.4.2	Locking shift procedure	535
10.5.4.3	Non-locking shift procedure.....	535
10.5.4.4	Auxiliary states	536
10.5.4.4a	Backup bearer capability.....	537
10.5.4.4a.1	Static conditions for the backup bearer capability IE contents.....	546
10.5.4.5	Bearer capability	546
10.5.4.5.1	Static conditions for the bearer capability IE contents	561
10.5.4.5a	Call Control Capabilities.....	561
10.5.4.6	Call state.....	562
10.5.4.7	Called party BCD number.....	563
10.5.4.8	Called party subaddress.....	565
10.5.4.9	Calling party BCD number	566
10.5.4.10	Calling party subaddress	567
10.5.4.11	Cause.....	568
10.5.4.11a	CLIR suppression.....	573
10.5.4.11b	CLIR invocation.....	574
10.5.4.12	Congestion level.....	574
10.5.4.13	Connected number	574
10.5.4.14	Connected subaddress	575
10.5.4.15	Facility	575
10.5.4.16	High layer compatibility	576
10.5.4.16.1	Static conditions for the high layer compatibility IE contents.....	577
10.5.4.17	Keypad facility	577
10.5.4.18	Low layer compatibility	577
10.5.4.19	More data	577
10.5.4.20	Notification indicator	578
10.5.4.21	Progress indicator.....	578
10.5.4.21a	Recall type \$(CCBS)\$	579
10.5.4.21b	Redirecting party BCD number.....	580
10.5.4.21c	Redirecting party subaddress.....	580
10.5.4.22	Repeat indicator	581
10.5.4.22a	Reverse call setup direction.....	581

10.5.4.22b	SETUP Container \$(CCBS)\$	582
10.5.4.23	Signal	582
10.5.4.24	SS Version Indicator	583
10.5.4.25	User-user	583
10.5.4.26	Alerting Pattern \$(NIA)\$	584
10.5.4.27	Allowed actions \$(CCBS)\$	585
10.5.4.28	Stream Identifier	586
10.5.4.29	Network Call Control Capabilities	586
10.5.4.30	Cause of No CLI	587
10.5.4.31	Void	587
10.5.4.32	Supported codec list	587
10.5.4.33	Service category	588
10.5.4.34	Redial	589
10.5.4.35	Network-initiated Service Upgrade indicator	589
10.5.5	GPRS mobility management information elements	590
10.5.5.0	Additional update type	590
10.5.5.1	Attach result	590
10.5.5.2	Attach type	590
10.5.5.3	Ciphering algorithm	591
10.5.5.3a	Integrity algorithm	592
10.5.5.4	TMSI status	592
10.5.5.5	Detach type	593
10.5.5.6	DRX parameter	593
10.5.5.7	Force to standby	595
10.5.5.8	P-TMSI signature	596
10.5.5.8a	P-TMSI signature 2	596
10.5.5.9	Identity type 2	597
10.5.5.10	IMEISV request	597
10.5.5.11	Receive N-PDU Numbers list	598
10.5.5.12	MS network capability	599
10.5.5.12a	MS Radio Access capability	603
10.5.5.13	Spare	622
10.5.5.14	GMM cause	622
10.5.5.15	Routing area identification	623
10.5.5.15a	Routing area identification 2	625
10.5.5.16	Spare	626
10.5.5.17	Update result	626
10.5.5.18	Update type	627
10.5.5.19	A&C reference number	627
10.5.5.20	Service type	628
10.5.5.21	Cell Notification	628
10.5.5.22	PS LCS Capability	629
10.5.5.23	Network feature support	630
10.5.5.23A	Additional network feature support	630
10.5.5.24	Inter RAT information container	631
10.5.5.25	Requested MS information	632
10.5.5.26	UE network capability	632
10.5.5.27	E-UTRAN inter RAT information container	632
10.5.5.28	Voice domain preference and UE's usage setting	633
10.5.5.29	P-TMSI type	634
10.5.5.30	Location Area Identification 2	634
10.5.5.31	Network resource identifier container	634
10.5.5.32	Extended DRX parameters	635
10.5.5.33	Message authentication code	639
10.5.5.34	User Plane integrity indicator	640
10.5.5.35	DCN-ID	640
10.5.5.36	PLMN identity of the CN operator	641
10.5.5.37	Non-3GPP NW provided policies	642
10.5.6	Session management information elements	642
10.5.6.1	Access point name	642
10.5.6.2	Network service access point identifier	643
10.5.6.3	Protocol configuration options	643

10.5.6.3.1	General	643
10.5.6.3.2	APN rate control parameters	652
10.5.6.3A	Extended protocol configuration options	652
10.5.6.4	Packet data protocol address	653
10.5.6.5	Quality of service	654
10.5.6.5A	Re-attempt indicator	664
10.5.6.6	SM cause	665
10.5.6.6A	SM cause 2	666
10.5.6.7	Linked TI	667
10.5.6.8	Spare	667
10.5.6.9	LLC service access point identifier	667
10.5.6.10	Tear down indicator	668
10.5.6.11	Packet Flow Identifier	668
10.5.6.12	Traffic Flow Template	669
10.5.6.13	Temporary Mobile Group Identity (TMGI)	676
10.5.6.14	MBMS bearer capabilities	677
10.5.6.15	MBMS protocol configuration options	677
10.5.6.16	Enhanced network service access point identifier	678
10.5.6.17	Request type	679
10.5.6.18	Notification indicator	680
10.5.6.19	Connectivity type	680
10.5.6.20	WLAN offload acceptability	681
10.5.6.21	NBIFOM container	682
10.5.7	GPRS Common information elements	682
10.5.7.1	PDP context status	682
10.5.7.2	Radio priority	683
10.5.7.3	GPRS Timer	683
10.5.7.4	GPRS Timer 2	684
10.5.7.4a	GPRS Timer 3	684
10.5.7.5	Radio priority 2	685
10.5.7.6	MBMS context status	686
10.5.7.7	Uplink data status	686
10.5.7.8	Device properties	687
11	List of system parameters	688
11.1	Timers and counters for radio resource management	688
11.2	Timers of mobility management	688
11.2.1	Timer T3240 and Timer T3241	691
11.2.2	Timers of GPRS mobility management	692
11.2.3	Timers of GPRS session management	704
11.3	Timers of circuit-switched call control	709
Annex A (informative):	Example of subaddress information element coding	711
Annex B (normative):	Compatibility checking	712
B.1	Introduction	712
B.2	Calling side compatibility checking	712
B.2.1	Compatibility checking of the CM SERVICE REQUEST message	712
B.2.2	Compatibility/Subscription checking of the SETUP message	712
B.3	Called side compatibility checking	712
B.3.1	Compatibility checking with addressing information	713
B.3.2	Network-to-MS compatibility checking	713
B.3.3	User-to-User compatibility checking	713
B.4	High layer compatibility checking	713
Annex C (normative):	Low layer information coding principles	714
C.1	Purpose	714
C.2	Principles	714
C.2.1	Definition of types of information	714

C.2.2	Examination by network	714
C.2.3	Location of type I information	715
C.2.4	Location of types II and III information	715
C.2.5	Relationship between bearer capability and low layer compatibility information elements	715
Annex D (informative): Examples of bearer capability information element coding		716
D.1	Coding for speech for a full rate support only mobile station	716
D.1.1	Mobile station to network direction	716
D.1.2	Network to mobile station direction	716
D.2	An example of a coding for modem access with V22-bis, 2,4 kbit/s, 8 bit no parity	717
D.2.1	Mobile station to network direction, data compression allowed	717
D.2.2	Network to mobile station direction, data compression possible	718
D.3	An example of a coding for group 3 facsimile (9,6 kbit/s, transparent)	719
D.3.1	Mobile station to network direction	719
D.3.2	Network to mobile station direction	720
Annex E (informative): Comparison between call control procedures specified in 3GPP TS 24.008 and ITU-T Recommendation Q.931		721
Annex F (informative): A/Gb mode specific cause values for radio resource management		725
Annex G (informative): 3GPP specific cause values for mobility management		726
G.1	Causes related to MS identification	726
G.2	Cause related to subscription options	726
G.3	Causes related to PLMN specific network failures and congestion/Authentication Failures	727
G.4	Causes related to nature of request	727
G.5	Causes related to invalid messages	728
G.6	Additional cause codes for GMM	728
Annex H (informative): 3GPP specific cause values for call control		730
H.1	Normal class	730
H.1.1	Cause No. 1 "unassigned (unallocated) number"	730
H.1.2	Cause No. 3 "no route to destination"	730
H.1.3	Cause No. 6 "channel unacceptable"	730
H.1.4	Cause No. 8 "operator determined barring"	730
H.1.4a	Cause No. 13 "call completed elsewhere"	730
H.1.5	Cause No.16 "normal call clearing"	730
H.1.6	Cause No.17 "user busy"	730
H.1.7	Cause No. 18 "no user responding"	730
H.1.8	Cause No. 19 "user alerting, no answer"	731
H.1.9	Cause No. 21 "call rejected"	731
H.1.10	Cause No. 22 "number changed"	731
H.1.10a Cause No. 24 "call rejected due to feature at the destination"	731
H.1.11	Cause No. 25 "pre-emption"	731
H.1.12	Cause No. 26 "non-selected user clearing"	731
H.1.13	Cause No. 27 "destination out of order"	731
H.1.14	Cause No. 28 "invalid number format (incomplete number)"	731
H.1.15	Cause No. 29 "facility rejected"	731
H.1.16	Cause No. 30 "response to STATUS ENQUIRY"	731
H.1.17	Cause No. 31 "normal, unspecified"	732
H.2	Resource unavailable class	732
H.2.1	Cause No. 34 "no circuit/channel available"	732
H.2.2	Cause No. 38 "network out of order"	732

H.2.3	Cause No. 41 "temporary failure"	732
H.2.4	Cause No. 42 "switching equipment congestion"	732
H.2.5	Cause No. 43 "access information discarded"	732
H.2.6	Cause No. 44 "requested circuit/channel not available"	732
H.2.7	Cause No. 47 "resource unavailable, unspecified"	732
H.3	Service or option not available class	732
H.3.1	Cause No. 49 "quality of service unavailable"	732
H.3.2	Cause No. 50 "Requested facility not subscribed"	733
H.3.3	Cause No. 55 "Incoming calls barred within the CUG"	733
H.3.4	Cause No. 57 "bearer capability not authorized"	733
H.3.5	Cause No. 58 "bearer capability not presently available"	733
H.3.6	Cause No. 63 "service or option not available, unspecified"	733
H.3.7	Cause No. 68 "ACM equal to or greater than ACMmax"	733
H.4	Service or option not implemented class	733
H.4.1	Cause No. 65 "bearer service not implemented"	733
H.4.2	Cause No. 69 "Requested facility not implemented"	733
H.4.3	Cause No. 70 "only restricted digital information bearer capability is available"	733
H.4.4	Cause No. 79 "service or option not implemented, unspecified"	734
H.5	Invalid message (e.g., parameter out of range) class	734
H.5.1	Cause No. 81 "invalid transaction identifier value"	734
H.5.2	Cause No. 87 "user not member of CUG"	734
H.5.3	Cause No. 88 "incompatible destination"	734
H.5.4	Cause No. 91 "invalid transit network selection"	734
H.5.5	Cause No. 95 "semantically incorrect message"	734
H.6	Protocol error (e.g., unknown message) class	734
H.6.1	Cause No. 96 "invalid mandatory information"	734
H.6.2	Cause No. 97 "message type non-existent or not implemented"	734
H.6.3	Cause No. 98 "message type not compatible with protocol state"	735
H.6.4	Cause No. 99 "information element non-existent or not implemented"	735
H.6.5	Cause No. 100 "conditional IE error"	735
H.6.6	Cause No. 101 "message not compatible with protocol state"	735
H.6.7	Cause No. 102 "recovery on timer expiry"	735
H.6.8	Cause No. 111 "protocol error, unspecified"	735
H.7	Interworking class	735
H.7.1	Cause No. 127 "interworking, unspecified"	735
Annex I (informative): GPRS specific cause values for GPRS Session Management.....		736
I.1	Causes related to nature of request	736
I.2	Causes related to invalid messages	739
I.3	Void	739
Annex J (informative): Algorithm to encode frequency list information elements		740
Annex K (informative): Default Codings of Information Elements		741
K.1	Common information elements	741
K.2	Radio Resource management information elements	741
K.3	Mobility management information elements	741
K.4	Call control information elements	742
Annex L (normative): Establishment cause (Iu mode only).....		744
L.1	Mapping of NAS procedure to RRC establishment cause(Iu mode only)	744
Annex M (normative): Additional Requirements for backward compatibility with PCS 1900 for NA revision 0 ME.....		748

Annex N (normative):	Ranking of reject causes for Location Registration (MM and GMM) in a shared network	749
Annex O (normative):	3GPP capability exchange protocol.....	751
O.1	Scope	751
O.2	User-user protocol contents.....	751
O.3	Information element identifier.....	751
O.4	Information elements.....	752
O.4.1	Personal ME identifier.....	752
O.4.2	Radio environment capability.....	753
O.4.3	UE capability version	753
O.4.4	IM Status	754
O.5	Handling of unknown, unforeseen, and erroneous protocol data	755
O.5.1	General	755
O.5.2	Not supported IEs, unknown IEs	755
O.5.3	Repeated IEs.....	755
O.5.4	Syntactically incorrect IEs.....	756
O.5.5	Semantically incorrect IEs.....	756
Annex P (normative):	Mobility management for IMS voice termination	757
P.1	Introduction	757
P.2	Activation of mobility management for IMS voice termination	757
P.3	Inter-system change between A/Gb mode and Iu mode.....	757
P.4	Inter-system change between A/Gb mode and S1 mode.....	758
P.5	Inter-system change between Iu mode and S1 mode	758
Annex Q (normative):	Application specific Congestion control for Data Communication (ACDC) (Iu mode only)	759
Annex R (informative):	Change History	760
History		797

Foreword

This Technical Specification has been produced by the 3rd Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
 - 1 presented to TSG for information;
 - 2 presented to TSG for approval;
 - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

Introduction

The present document includes references to features which are not part of the Phase 2+ Release 96 of the GSM Technical specifications. All subclauses which were changed as a result of these features contain a marker (see table below) relevant to the particular feature.

The following table lists all features that were introduced after GSM Release 96.

Feature	Designator
BA Range IE handling	\$(impr-BA-range-handling)\$
Advanced Speech Call Item	\$(ASCI)\$
Call Completion Busy Subscriber	\$(CCBS)\$
Mobile Assisted Frequency Allocation	\$(MAFA)\$
Network Indication of Alerting in MS	\$(NIA)\$

1 Scope

The present document specifies the procedures used at the radio interface core network protocols within the 3rd generation mobile telecommunications system and the digital cellular telecommunications system.

It specifies the procedures used at the radio interface (Reference Point Um or Uu, see 3GPP TS 24.002 [15] or 3GPP TS 23.002 [127]) for Call Control (CC), Mobility Management (MM), and Session Management (SM).

When the notations for "further study" or "FS" or "FFS" are present in this TS they mean that the indicated text is not a normative portion of the present document.

These procedures are defined in terms of messages exchanged over the control channels of the radio interface. The control channels are described in 3GPP TS 44.003 [16] and 3GPP TS 25.301 [128].

The structured functions and procedures of this protocol and the relationship with other layers and entities are described in general terms in 3GPP TS 24.007 [20].

The present document specifies functions, procedures and information which apply to GERAN Iu mode. However, functionality related to GERAN Iu mode is neither maintained nor enhanced.

1.1 Scope of the Technical Specification

The procedures currently described in this TS are for the call control of circuit-switched connections, session management for GPRS services, mobility management and radio resource management for circuit-switched and GPRS services.

3GPP TS 24.010 [21] contains functional procedures for support of supplementary services.

3GPP TS 24.011 [22] contains functional procedures for support of point-to-point short message services.

3GPP TS 24.012 [23] contains functional description of short message - cell broadcast.

3GPP TS 44.060 [76] contains procedures for radio link control and medium access control (RLC/MAC) of packet data physical channels.

3GPP TS 44.071 [23a] contains functional descriptions and procedures for support of location services.

NOTE: "layer 3" includes the functions and protocols described in the present document. The terms "data link layer" and "layer 2" are used interchangeably to refer to the layer immediately below layer 3.

1.2 Application to the interface structures

The procedures defined in the present document apply to the interface structures defined in 3GPP TS 44.003 [16] and 3GPP TS 25.301 [128]. They use the functions and services provided by lower layers defined in 3GPP TS 44.005 [18] and 3GPP TS 44.006 [19] or 3GPP TS 25.331 [23c], 3GPP TS 25.322 [19b] and 3GPP TS 25.321 [19a].

3GPP TS 24.007 [20] gives the general description of layer 3 (A/Gb mode) and Non Access Stratum (Iu mode and S1 mode) including procedures, messages format and error handling.

1.3 Structure of layer 3 procedures

A building block method is used to describe the layer 3 procedures.

The basic building blocks are "elementary procedures" provided by the protocol control entities of the three sublayers, i.e. radio resource management, mobility management and connection management sublayer.

Complete layer 3 transactions consist of specific sequences of elementary procedures. The term "structured procedure" is used for these sequences.