

ETSI TS 136 508 V13.2.0 (2017-03)



**LTE;
Evolved Universal Terrestrial Radio Access (E-UTRA) and
Evolved Packet Core (EPC);
Common test environments for User Equipment (UE)
conformance testing
(3GPP TS 36.508 version 13.2.0 Release 13)**



Reference

RTS/TSGR-0536508vd20

Keywords

LTE

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

The present document can be downloaded from:
<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the only prevailing document is the print of the Portable Document Format (PDF) version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.
Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:
<https://portal.etsi.org/People/CommitteeSupportStaff.aspx>

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.
The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2017.
All rights reserved.

DECT™, PLUGTESTS™, UMTS™ and the ETSI logo are Trade Marks of ETSI registered for the benefit of its Members.
3GPP™ and **LTE™** are Trade Marks of ETSI registered for the benefit of its Members and
of the 3GPP Organizational Partners.
GSM® and the GSM logo are Trade Marks registered and owned by the GSM Association.

Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Foreword

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under
<http://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "shall", "shall not", "should", "should not", "may", "need not", "will", "will not", "can" and "cannot" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"must" and "must not" are NOT allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Foreword.....	2
Modal verbs terminology.....	2
Foreword.....	24
Introduction	24
1 Scope	25
2 References	25
3 Definitions, symbols and abbreviations	28
3.1 Definitions	28
3.2 Symbols.....	28
3.3 Abbreviations	28
4 Common test environment	29
4.1 Environmental conditions.....	29
4.1.1 Temperature.....	29
4.1.2 Voltage.....	29
4.2 Common requirements of test equipment.....	30
4.2.1 General functional requirements.....	30
4.2.2 Minimum functional requirements	30
4.2.2.1 Supported Cell Configuration	30
4.2.2.1.1 Supported Channels.....	31
4.2.2.2 Support of T_{cell} timing offset	32
4.2.2.3 Supported Sidelink Configuration.....	32
4.2.2.3.1 Supported Sidelink Channels.....	32
4.3 Reference test conditions.....	33
4.3.1 Test frequencies	33
4.3.1.1 FDD Mode Test frequencies	37
4.3.1.1.1 FDD reference test frequencies for operating band 1	37
4.3.1.1.1A FDD reference test frequencies for CA in operating band 1	37
4.3.1.1.2 FDD reference test frequencies for operating band 2	38
4.3.1.1.2A FDD reference test frequencies for CA in operating band 2.....	38
4.3.1.1.3 FDD reference test frequencies for operating band 3	40
4.3.1.1.3A FDD reference test frequencies for CA in operating band 3.....	40
4.3.1.1.4 FDD reference test frequencies for operating band 4	41
4.3.1.1.4A FDD reference test frequencies for CA in operating band 4.....	42
4.3.1.1.5 FDD reference test frequencies for operating band 5	43
4.3.1.1.5A FDD reference test frequencies for CA in operating band 5.....	43
4.3.1.1.6 FDD reference test frequencies for operating band 6	44
4.3.1.1.7 FDD reference test frequencies for operating band 7	44
4.3.1.1.7A FDD reference test frequencies for CA in operating band 7.....	45
4.3.1.1.8 FDD reference test frequencies for operating band 8	46
4.3.1.1.8A FDD reference test frequencies for CA in operating band 8.....	47
4.3.1.1.9 FDD reference test frequencies for operating band 9	47
4.3.1.1.10 FDD reference test frequencies for operating band 10	47
4.3.1.1.11 FDD reference test frequencies for operating band 11	48
4.3.1.1.12 FDD reference test frequencies for operating band 12	48
4.3.1.1.12A FDD reference test frequencies for CA in operating band 12.....	48
4.3.1.1.13 FDD reference test frequencies for operating band 13	48
4.3.1.1.14 FDD reference test frequencies for operating band 14	49
4.3.1.1.15 FDD reference test frequencies for operating band 15	49
4.3.1.1.16 FDD reference test frequencies for operating band 16	49
4.3.1.1.17 FDD reference test frequencies for operating band 17	49
4.3.1.1.18 FDD reference test frequencies for operating band 18	49
4.3.1.1.19 FDD reference test frequencies for operating band 19	50

4.3.1.1.20	FDD reference test frequencies for operating band 20	50
4.3.1.1.21	FDD reference test frequencies for operating band 21	50
4.3.1.1.22	FDD reference test frequencies for operating band 22	51
4.3.1.1.23	FDD reference test frequencies for operating band 23	51
4.3.1.1.23A	FDD reference test frequencies for CA in operating band 23.....	51
4.3.1.1.24	FDD reference test frequencies for operating band 24	52
4.3.1.1.25	FDD reference test frequencies for operating band 25	52
4.3.1.1.25A	FDD reference test frequencies for CA in operating band 25.....	53
4.3.1.1.26	FDD reference test frequencies for operating band 26	53
4.3.1.1.27	FDD reference test frequencies for operating band 27	54
4.3.1.1.27A	FDD reference test frequencies for CA in operating band 27.....	54
4.3.1.1.28	FDD reference test frequencies for operating band 28	55
4.3.1.1.29	FDD reference test frequencies for CA in operating band 29.....	56
4.3.1.1.31	FDD reference test frequencies for operating band 31	56
4.3.1.1.32	FDD reference test frequencies for CA in operating band 32.....	56
4.3.1.1.33 to 4.3.1.1.64	Void.....	57
4.3.1.1.65	FDD reference test frequencies for operating band 65	57
4.3.1.1.66	FDD reference test frequencies for operating band 66	57
4.3.1.1.66A	FDD reference test frequencies for CA in operating band 66.....	58
4.3.1.1.67	FDD reference test frequencies for CA in operating band 67.....	61
4.3.1.2	TDD Mode Test frequencies	62
4.3.1.2.1	TDD reference test frequencies for Operating Band 33	62
4.3.1.2.2	TDD reference test frequencies for Operating Band 34	62
4.3.1.2.3	TDD reference test frequencies for Operating Band 35	62
4.3.1.2.4	TDD reference test frequencies for Operating Band 36	63
4.3.1.2.5	TDD reference test frequencies for Operating Band 37	63
4.3.1.2.6	TDD reference test frequencies for Operating Band 38	63
4.3.1.2.6A	TDD reference test frequencies for CA in operating band 38	64
4.3.1.2.7	TDD reference test frequencies for Operating Band 39	64
4.3.1.2.7A	TDD reference test frequencies for CA in Operating Band 39.....	65
4.3.1.2.8	TDD reference test frequencies for Operating Band 40	65
4.3.1.2.8A	TDD reference test frequencies for CA in operating band 40	66
4.3.1.2.9	TDD reference test frequencies for Operating Band 41	67
4.3.1.2.9A	TDD reference test frequencies for CA in operating band 41	67
4.3.1.2.10	TDD reference test frequencies for Operating Band 42	79
4.3.1.2.10A	TDD reference test frequencies for CA in operating band 42	79
4.3.1.2.11	TDD reference test frequencies for Operating Band 43	85
4.3.1.2.12	TDD reference test frequencies for Operating Band 44	86
4.3.1.2.13	TDD reference test frequencies for Operating Band 45	86
4.3.1.2.14	TDD reference test frequencies for Operating Band 46	86
4.3.1.3	HRPD Test frequencies	87
4.3.1.3.1	HRPD test frequencies for Band Class 0	87
4.3.1.3.2	HRPD test frequencies for Band Class 1	87
4.3.1.3.3	HRPD test frequencies for Band Class 3	87
4.3.1.3.4	HRPD test frequencies for Band Class 4	87
4.3.1.3.5	HRPD test frequencies for Band Class 6	87
4.3.1.3.6	HRPD test frequencies for Band Class 10	88
4.3.1.3.7	HRPD test frequencies for Band Class 15	88
4.3.1.4	1xRTT Test frequencies	88
4.3.1.4.1	1xRTT test frequencies for Band Class 0	88
4.3.1.4.2	1xRTT test frequencies for Band Class 1	88
4.3.1.4.3	1xRTT test frequencies for Band Class 3	88
4.3.1.4.4	1xRTT test frequencies for Band Class 4	89
4.3.1.4.5	1xRTT test frequencies for Band Class 6	89
4.3.1.4.6	1xRTT test frequencies for Band Class 10	89
4.3.1.4.7	1xRTT test frequencies for Band Class 15	89
4.3.1.5	MFBI Test frequencies	89
4.3.1.5.1	MFBI Test frequencies for operation band 2 overlapping with band 25	89
4.3.1.5.2	MFBI Test frequencies for operation band 3 overlapping with band 9	90
4.3.1.5.3	MFBI Test frequencies for operation band 4 overlapping with band 10	90
4.3.1.5.4	MFBI Test frequencies for operation band 5 overlapping with band 18	90
4.3.1.5.5	MFBI Test frequencies for operation band 5 overlapping with band 19	91

4.3.1.5.6	MFBI Test frequencies for operation band 5 overlapping with band 26	91
4.3.1.5.7	MFBI Test frequencies for operation band 9 overlapping with band 3	91
4.3.1.5.8	MFBI Test frequencies for operation band 10 overlapping with band 4	91
4.3.1.5.9	MFBI Test frequencies for operation band 12 overlapping with band 17	91
4.3.1.5.10	MFBI Test frequencies for operation band 17 overlapping with band 12	92
4.3.1.5.11	MFBI Test frequencies for operation band 18 overlapping with band 5	92
4.3.1.5.12	MFBI Test frequencies for operation band 18 overlapping with band 26	92
4.3.1.5.13	MFBI Test frequencies for operation band 18 overlapping with band 27	92
4.3.1.5.14	MFBI Test frequencies for operation band 19 overlapping with band 5	92
4.3.1.5.15	MFBI Test frequencies for operation band 19 overlapping with band 26	92
4.3.1.5.16	MFBI Test frequencies for operation band 25 overlapping with band 2	93
4.3.1.5.17	MFBI Test frequencies for operation band 26 overlapping with band 5	93
4.3.1.5.18	MFBI Test frequencies for operation band 26 overlapping with band 18	93
4.3.1.5.19	MFBI Test frequencies for operation band 26 overlapping with band 19	94
4.3.1.5.20	MFBI Test frequencies for operation band 26 overlapping with band 27	94
4.3.1.5.21	MFBI Test frequencies for operation band 27 overlapping with band 18	95
4.3.1.5.22	MFBI Test frequencies for operation band 27 overlapping with band 26	95
4.3.1.5.23	MFBI Test frequencies for operation band 33 overlapping with band 39	95
4.3.1.5.24	MFBI Test frequencies for operation band 38 overlapping with band 41	95
4.3.1.5.25	MFBI Test frequencies for operation band 39 overlapping with band 33	95
4.3.1.5.26	MFBI Test frequencies for operation band 41 overlapping with band 38	96
4.3.1.6	WLAN Test frequencies	96
4.3.1.6.1	WLAN Test frequencies for 2.4 GHz ISM Band	96
4.3.1.6.2	WLAN Test frequencies for 5 GHz ISM Band	96
4.3.2	Radio conditions	96
4.3.2.1	Normal propagation condition	96
4.3.3	Physical channel allocations	96
4.3.3.1	Antennas	96
4.3.3.2	Downlink physical channels and physical signals.....	97
4.3.3.3	Mapping of downlink physical channels and signals to physical resources.....	97
4.3.3.4	Uplink physical channels and physical signals	104
4.3.3.5	Mapping of uplink physical channels and signals to physical resources.....	104
4.3.4	Signal levels.....	104
4.3.4.1	Downlink signal levels	104
4.3.4.2	Uplink signal levels.....	105
4.3.5	Standard test signals.....	105
4.3.5.1	Downlink test signals	105
4.3.5.2	Uplink test signals	105
4.3.6	Physical layer parameters	105
4.3.6.1	Downlink physical layer parameters	105
4.3.6.1.1	Physical layer parameters for DCI format 0	105
4.3.6.1.2	Physical layer parameters for DCI format 1	106
4.3.6.1.3	Physical layer parameters for DCI format 1A	106
4.3.6.1.3A	Physical layer parameters for DCI format 1B	107
4.3.6.1.4	Physical layer parameters for DCI format 1C	107
4.3.6.1.5	Physical layer parameters for DCI format 2	108
4.3.6.1.6	Physical layer parameters for DCI format 2A	109
4.3.6.1.7	Physical layer parameters for DCI format 5	109
4.3.6.1.8	Physical layer parameters for DCI format 6-0A	109
4.3.6.1.9	Physical layer parameters for DCI format 6-0B	111
4.3.6.1.10	Physical layer parameters for DCI format 6-1A	112
4.3.6.1.11	Physical layer parameters for DCI format 6-1B	114
4.3.6.1.12	Physical layer parameters for DCI format 6-2	115
4.4	Reference system configurations.....	115
4.4.1	Simulated network scenarios	115
4.4.1.1	Single cell network scenarios	115
4.4.1.2	E-UTRA single mode multi cell network scenarios.....	115
4.4.1.3	E-UTRA dual mode multi cell network scenarios	116
4.4.1.4	3GPP Inter-RAT network scenarios.....	116
4.4.1.5	3GPP2 Inter-RAT network scenarios.....	116
4.4.1.6	WLAN Inter-RAT network scenarios	116
4.4.2	Simulated cells.....	116

4.4.3	Common parameters for simulated E-UTRA cells	119
4.4.3.1	Common configurations of system information blocks	119
4.4.3.1.1	Combinations of system information blocks	119
4.4.3.1.2	Scheduling of system information blocks.....	123
4.4.3.2	Common contents of system information messages	128
-	<i>MasterInformationBlock</i>	128
-	<i>SystemInformation</i>	129
-	<i>SystemInformation-BR-r13</i>	129
-	<i>SystemInformationBlockType1</i>	131
-	<i>SystemInformationBlockType1-BR-r13</i>	134
4.4.3.3	Common contents of system information blocks	138
-	<i>SystemInformationBlockType2</i>	138
-	<i>SystemInformationBlockType3</i>	139
-	<i>SystemInformationBlockType4</i>	140
-	<i>SystemInformationBlockType5</i>	140
-	<i>SystemInformationBlockType6</i>	144
-	<i>SystemInformationBlockType7</i>	146
-	<i>SystemInformationBlockType8</i>	147
-	<i>SystemInformationBlockType9</i>	150
-	<i>SystemInformationBlockType10</i>	150
-	<i>SystemInformationBlockType11</i>	152
-	<i>SystemInformationBlockType12</i>	154
-	<i>SystemInformationBlockType13</i>	155
-	<i>SystemInformationBlockType14</i>	155
-	<i>SystemInformationBlockType15</i>	156
-	<i>SystemInformationBlockType17</i>	157
-	<i>SystemInformationBlockType18</i>	157
-	<i>SystemInformationBlockType19</i>	165
-	<i>SystemInformationBlockType20</i>	170
4.4.3.4	Channel-bandwidth-dependent parameters in system information blocks	170
4.4.4	Common parameters for simulated UTRA cells	171
4.4.4.1	Common contents of system information blocks for UTRA cells	172
-	System Information Block type 19.....	172
4.4.4.2	UTRA SIB scheduling for inter EUTRA - UTRA test.....	174
4.4.4.3	UTRA SIB scheduling for inter EUTRA – UTRA - GERAN test	174
4.4.5	Common parameters for simulated GERAN cells	175
4.4.6	Common parameters for simulated CDMA2000 cells.....	178
4.4.7	Default parameters specific for simulated cells	178
4.4.7.1	Common contents of HRPD Overhead messages	178
4.4.7.2	Common contents of 1XRTT Overhead messages	183
4.4.7.2.1	Configuration sequence number	183
4.4.7.2.2	Over Head messages.....	184
4.4.8	Common parameters for simulated WLAN AP's	193
4.5	Generic procedures.....	193
4.5.1	UE test states.....	194
4.5.2	UE Registration (State 2).....	199
4.5.2.1	Initial conditions	200
4.5.2.2	Definition of system information messages	200
4.5.2.3	Procedure	201
4.5.2.4	Specific message contents.....	204
4.5.2A	UE Registration, UE Test Mode Activated (State 2A)	205
4.5.2A.1	Initial conditions	206
4.5.2A.2	Definition of system information messages	206
4.5.2A.3	Procedure	207
4.5.2A.4	Specific message contents.....	210
4.5.2AA	UE Registration in cell supporting BL/CE UE (State 2-CE)	210
4.5.2AA.1	Initial conditions	210
4.5.2AA.2	Definition of system information messages	210
4.5.2AA.3	Procedure	211
4.5.2AA.4	Specific message contents.....	211
4.5.2AB	UE Registration, UE Test Mode Activated in cell supporting BL/CE UE (State 2A-CE).....	211
4.5.2AB.1	Initial conditions	211

4.5.2AB.2	Definition of system information messages	211
4.5.2AB.3	Procedure	212
4.5.2AB.4	Specific message contents	212
4.5.2B	UE Registration, pre-registration on HRPD (State 2B)	212
4.5.2B.1	Initial conditions	212
4.5.2B.2	Definition of system information messages	212
4.5.2B.3	Procedure	213
4.5.2B.4	Specific message contents	218
4.5.2C	UE Registration, pre-registration on 1xRTT (State 2C)	219
4.5.2C.1	Initial conditions	219
4.5.2C.2	Definition of system information messages	219
4.5.2C.3	Procedure	221
4.5.2C.4	Specific message contents	221
4.5.2D	UE Registration, 2 PDN for RAN Assisted WLAN Interworking (State 2)	227
4.5.2D.1	Initial conditions	227
4.5.2D.2	Definition of system information messages	227
4.5.2D.3	Procedure	228
4.5.2D.4	Specific message contents	228
4.5.3	Generic Radio Bearer Establishment (State 3)	230
4.5.3.1	Initial conditions	230
4.5.3.2	Definition of system information messages	230
4.5.3.3	Procedure	231
4.5.3.4	Specific message contents	233
4.5.3A	Generic Radio Bearer Establishment, UE Test Mode Activated (State 3A)	233
4.5.3A.1	Initial conditions	233
4.5.3A.2	Definition of system information messages	233
4.5.3A.3	Procedure	234
4.5.3A.4	Specific message contents	234
4.5.3AA	Generic Radio Bearer Establishment (State 3-CE)	234
4.5.3AA.1	Initial conditions	234
4.5.3AA.2	Definition of system information messages	234
4.5.3AA.3	Procedure	234
4.5.3AA.4	Specific message contents	234
4.5.3AB	Generic Radio Bearer Establishment, UE Test Mode Activated (State 3A-CE)	234
4.5.3AB.1	Initial conditions	234
4.5.3AB.2	Definition of system information messages	235
4.5.3AB.3	Procedure	235
4.5.3AB.4	Specific message contents	235
4.5.3B	Generic Radio Bearer Establishment, pre-registered on HRPD (State 3B)	235
4.5.3B.1	Initial conditions	235
4.5.3B.2	Definition of system information messages	235
4.5.3B.3	Procedure	235
4.5.3B.4	Specific message contents	235
4.5.3C	Generic Radio Bearer Establishment, pre-registered on 1xRTT (State 3C)	236
4.5.3C.1	Initial conditions	236
4.5.3C.2	Definition of system information messages	236
4.5.3C.3	Procedure	236
4.5.3C.4	Specific message contents	236
4.5.3D	Generic Radio Bearer Establishment for RAN Assisted WLAN Interworking (State 3)	236
4.5.3D.1	Initial conditions	236
4.5.3D.2	Definition of system information messages	236
4.5.3D.3	Procedure	237
4.5.3D.4	Specific message contents	237
4.5.3E	Control plane CIoT connection request (State 3-CP)	237
4.5.3E.1	Initial conditions	237
4.5.3E.2	Definition of system information messages	237
4.5.3E.3	Procedure	238
4.5.3E.4	Specific message contents	238
4.5.3F	User plane CIoT connection request (State 3-UP)	238
4.5.3F.1	Initial conditions	238
4.5.3F.2	Definition of system information messages	238
4.5.3F.3	Procedure	239

4.5.3F.4	Specific message contents	239
4.5.4	Loopback Activation (State 4)	239
4.5.4.1	Initial conditions	239
4.5.4.2	Definition of system information messages	239
4.5.4.3	Procedure	239
4.5.4.4	Specific message contents	240
4.5.4A	Loopback Activation in cell supporting BL/CE UE (State 4-CE)	240
4.5.4A.1	Initial conditions	240
4.5.4A.2	Definition of system information messages	240
4.5.4A.3	Procedure	240
4.5.4A.4	Specific message contents	240
4.5.5	HRPD registration (State H2)	240
4.5.5.1	Initial conditions	240
4.5.5.2	Definition of system information messages	241
4.5.5.3	Procedure	241
4.5.5.4	Specific message contents	241
4.5.5A	HRPD registration, pre-registration on E-UTRAN (State H2A)	241
4.5.5A.1	Initial conditions	241
4.5.5A.2	Definition of system information messages	241
4.5.5A.3	Procedure	241
4.5.5A.4	Specific message contents	241
4.5.6	HRPD session establishment (State H3)	241
4.5.6.1	Initial conditions	241
4.5.6.2	Definition of system information messages	242
4.5.6.3	Procedure	242
4.5.6.4	Specific message contents	242
4.5.6A	HRPD session establishment, pre-registered on E-UTRAN (State H3A)	242
4.5.6A.1	Initial conditions	242
4.5.6A.2	Definition of system information messages	242
4.5.6A.3	Procedure	242
4.5.6A.4	Specific message contents	242
4.5.7	Out of Coverage (State 5)	242
4.5.7.1	Initial conditions	242
4.5.7.2	Definition of system information messages	243
4.5.7.3	Procedure	243
4.5A	Other generic procedures	243
4.5A.1	Procedure for IP address allocation in the U-plane	243
4.5A.2	Tracking area updating procedure	243
4.5A.3	Procedure for IMS signalling	244
4.5A.3A	Procedure for IMS Signalling over UTRA	245
4.5A.3A.1	Initial conditions	245
4.5A.3A.2	Procedure	246
4.5A.3A.3	Specific message contents	247
4.5A.3B	Procedure for preventing IMS Signalling over GERAN	249
4.5A.3B.1	Initial conditions	249
4.5A.3B.2	Procedure	250
4.5A.3A.3	Specific message contents	250
4.5A.4	Generic Test Procedure for IMS Emergency call establishment in EUTRA: Normal Service	251
4.5A.4.1	Initial conditions	251
4.5A.4.2	Definition of system information messages	251
4.5A.4.3	Procedure	251
4.5A.4.4	Specific message contents	254
4.5A.5	Generic Test Procedure for IMS Emergency call establishment in EUTRA: Limited Service	255
4.5A.5.1	Initial conditions	255
4.5A.5.2	Definition of system information messages	255
4.5A.5.3	Procedure	256
4.5A.5.4	Specific message contents	259
4.5A.6	Generic Test Procedure for IMS MO speech call establishment in E-UTRA	261
4.5A.6.1	Initial conditions	261
4.5A.6.2	Definition of system information messages	261
4.5A.6.3	Procedure	262
4.5A.6.4	Specific message contents	263

4.5A.7	Generic Test Procedure for IMS MT Speech call establishment in E-UTRA	263
4.5A.7.1	Initial conditions	263
4.5A.7.2	Definition of system information messages	263
4.5A.7.3	Procedure	264
4.5A.7.4	Specific message contents	264
4.5A.8	Generic Test Procedure for IMS MO video call establishment in E-UTRA	265
4.5A.8.1	Initial conditions	265
4.5A.8.2	Definition of system information messages	265
4.5A.8.3	Procedure	266
4.5A.8.4	Specific message contents	267
4.5A.9	Generic Test Procedure for IMS MT video call establishment in E-UTRA	267
4.5A.9.1	Initial conditions	267
4.5A.9.2	Definition of system information messages	267
4.5A.9.3	Procedure	268
4.5A.9.4	Specific message contents	268
4.5A.10	Generic Test Procedure for IMS MO speech and aSRVCC in E-UTRA	269
4.5A.10.1	Initial conditions	269
4.5A.10.2	Definition of system information messages	269
4.5A.10.3	Procedure	270
4.5A.10.4	Specific message contents	271
4.5A.11	Generic Test Procedure for IMS MO add video establishment in E-UTRA	271
4.5A.11.1	Initial conditions	271
4.5A.11.2	Definition of system information messages	271
4.5A.11.3	Procedure	271
4.5A.11.4	Specific message contents	272
4.5A.12	Generic Test Procedure for IMS MT add video establishment in E-UTRA	272
4.5A.12.1	Initial conditions	272
4.5A.12.2	Definition of system information messages	272
4.5A.12.3	Procedure	272
4.5A.12.4	Specific message contents	273
4.5A.14	Generic Test Procedure for IMS XCAP establishment in EUTRA	273
4.5A.14.1	Initial conditions	273
4.5A.14.2	Definition of system information messages	273
4.5A.14.3	Procedure	274
4.5A.14.4	Specific message contents	274
4.5A.15	Generic Test Procedure for EPS Bearer Deactivation	274
4.5A.15.1	Initial conditions	274
4.5A.15.2	Definition of system information messages	274
4.5A.15.3	Procedure	275
4.5A.15.4	Specific message contents	275
4.5A.16	Generic Test Procedure to establish additional PDN connectivity	275
4.5A.16.1	Initial conditions	276
4.5A.16.2	Definition of system information messages	276
4.5A.16.3	Procedure	276
4.5A.16.4	Specific message contents	276
4.5A.17	Generic Test Procedure for user initiated release of additional PDN connectivity	277
4.5A.17.1	Initial conditions	277
4.5A.17.2	Definition of system information messages	277
4.5A.17.3	Procedure	278
4.5A.17.4	Specific message contents	278
4.5A.18	Generic Test Procedure for network initiated release of additional PDN connectivity	279
4.5A.18.1	Initial conditions	279
4.5A.18.2	Definition of system information messages	280
4.5A.18.3	Procedure	280
4.5A.18.4	Specific message contents	280
4.5A.19	Generic Test Procedure for IMS MO speech call establishment in E-UTRA / EVS	281
4.5A.19.1	Initial conditions	281
4.5A.19.2	Definition of system information messages	281
4.5A.19.3	Procedure	281
4.5A.19.4	Specific message contents	282
4.5A.20	Generic Test Procedure for IMS MT speech call establishment in E-UTRA / EVS	282
4.5A.20.1	Initial conditions	282

4.5A.20.2	Definition of system information messages	282
4.5A.20.3	Procedure	282
4.5A.20.4	Specific message contents	282
4.5A.21	Generic Test Procedure for IMS MO Customized Alerting Tones and speech establishment in E-UTRA	282
4.5A.21.1	Initial conditions	282
4.5A.21.2	Definition of system information messages	283
4.5A.21.3	Procedure	283
4.5A.21.4	Specific message contents	283
4.5A.22	Communication with the ProSe Function: Initial Access	283
4.5A.22.1	Initial conditions	283
4.5A.22.2	Definition of system information messages	283
4.5A.22.3	Procedure	283
4.5A.22.4	Specific message contents	286
4.5A.22A	Communication with the ProSe Function: Subsequent Access	286
4.5A.22A.1	Initial conditions	286
4.5A.22A.2	Definition of system information messages	286
4.5A.22A.3	Procedure	286
4.5A.22A.4	Specific message contents	287
4.5A.23	Generic Test Procedure for IMS call establishment in EPC / WLAN	287
4.5A.23.1	Initial conditions	287
4.5A.23.2	Definition of system information messages	287
4.5A.23.3	Procedure	288
4.5A.23.4	Specific message contents	288
4.6	Default RRC message and information elements contents	288
4.6.1	Contents of RRC messages	288
-	<i>CounterCheck</i>	288
-	<i>CounterCheckResponse</i>	289
-	<i>CSFBParametersRequestCDMA2000</i>	289
-	<i>CSFBParametersResponseCDMA2000</i>	289
-	<i>DLInformationTransfer</i>	290
-	<i>HandoverFromEUTRAPreparationRequest</i>	290
-	<i>LoggedMeasurementConfiguration</i>	291
-	<i>MasterInformationBlock-SL</i>	292
-	<i>MBMSCountingRequest</i>	292
-	<i>MBMSCountingResponse</i>	293
-	<i>MBMSInterestIndication</i>	293
-	<i>MBSFNAreaConfiguration</i>	294
-	<i>MeasurementReport</i>	294
-	<i>MobilityFromEUTRACmd</i>	295
-	<i>Paging</i>	295
-	<i>RRCConnectionReconfiguration</i>	296
-	<i>RRCConnectionReconfiguration (SideLink)</i>	300
-	<i>RRCConnectionReconfigurationComplete</i>	307
-	<i>RRCConnectionReestablishment</i>	307
-	<i>RRCConnectionReestablishmentComplete</i>	308
-	<i>RRCConnectionReestablishmentReject</i>	308
-	<i>RRCConnectionReestablishmentRequest</i>	308
-	<i>RRCConnectionReject</i>	309
-	<i>RRCConnectionRelease</i>	309
-	<i>RRCConnectionRequest</i>	309
-	<i>RRCConnectionSetup</i>	310
-	<i>RRCConnectionSetupComplete</i>	310
-	<i>SCPTMConfiguration</i>	311
-	<i>SecurityModeCommand</i>	311
-	<i>SecurityModeComplete</i>	312
-	<i>SecurityModeFailure</i>	312
-	<i>SidelinkUEInformation</i>	313
-	<i>UECapabilityEnquiry</i>	313
-	<i>UECapabilityInformation</i>	314
-	<i>UEInformationRequest</i>	321
-	<i>UEInformationResponse</i>	322

-	<i>ULHandoverPreparationTransfer</i>	322
-	<i>ULInformationTransfer</i>	323
-	<i>UEAssistanceInformation</i>	323
4.6.2	System information blocks	323
4.6.3	Radio resource control information elements	324
-	BCCH-Config-DEFAULT	324
-	CellSelectionInfoCE-r13-DEFAULT	324
-	CQI-ReportAperiodic-r10-DEFAULT	324
-	CQI-ReportConfig-DEFAULT	325
-	CQI-ReportConfig-r10-DEFAULT	325
-	CQI-ReportConfig-v1130-eIMTA	329
-	CQI-ReportConfig-v1250-DEFAULT	331
-	CQI-ReportConfigSCell-r10-DEFAULT	332
-	CQI-ReportPeriodic-r10-DEFAULT	332
-	CSI-RS-ConfigNZP-r11-DEFAULT	333
-	CSI-RS-ConfigZP-r11-DEFAULT	333
-	DMRS-Config-r11-DEFAULT	334
-	DRB-ToAddModList-RECONFIG	334
-	EPDCCH-Config-r11-DEFAULT	335
-	EPDCCH-Config-r11-eIMTA	338
-	FreqHoppingParameters-r13-DEFAULT	340
-	PCCH-Config-DEFAULT	340
-	PCCH-Config-v1310-DEFAULT	341
-	PHICH-Config-DEFAULT	341
-	PDSCH-ConfigCommon-DEFAULT	341
-	PDSCH-ConfigCommon-v1310-DEFAULT	342
-	PDSCH-ConfigDedicated-DEFAULT	342
-	PDSCH-ConfigDedicated-v1130-DEFAULT	343
-	PhysicalConfigDedicatedSCell-r10-DEFAULT	344
-	PhysicalConfigDedicatedSCell-r10-eIMTA	345
-	PRACH-Config-DEFAULT	346
-	PRACH-Config-v1310-DEFAULT	347
-	PRACH-ConfigSIB-DEFAULT	348
-	PRACH-ConfigSIB-v1310-DEFAULT	349
-	PUCCH-ConfigCommon-DEFAULT	353
-	PUCCH-ConfigCommon-v1310-DEFAULT	353
-	PUCCH-ConfigDedicated-DEFAULT	354
-	PUCCH-ConfigDedicated-v1020-DEFAULT	355
-	PUCCH-ConfigDedicated-v1130-DEFAULT	356
-	PUCCH-ConfigDedicated-v1250-DEFAULT	356
-	PUCCH-ConfigDedicated-r13-DEFAULT	357
-	PUSCH-ConfigCommon-DEFAULT	358
-	PUSCH-ConfigCommon-v1310-DEFAULT	358
-	PUSCH-ConfigDedicated-DEFAULT	359
-	PUSCH-ConfigDedicated-v1130-DEFAULT	359
-	PUSCH-ConfigDedicated-v1250-DEFAULT	359
-	PUSCH-ConfigDedicated-v1310-DEFAULT	360
-	RACH-ConfigCommon-DEFAULT	361
-	Rach-ConfigDedicated-DEFAULT	364
-	RadioResourceConfigCommon-DEFAULT	365
-	RadioResourceConfigCommonSCell-r10-DEFAULT	367
-	RadioResourceConfigCommonSIB-DEFAULT	368
-	RadioResourceConfigDedicated-SRB1	369
-	RadioResourceConfigDedicated-SRB2-DRB(n,m)	370
-	RadioResourceConfigDedicated-DRB(n,m)	371
-	RadioResourceConfigDedicated-HO-TO-EUTRA(n,m)	372
-	RadioResourceConfigDedicated-AM-DRB-ADD(bid)	373
-	RadioResourceConfigDedicated-UM-DRB-ADD(bid)	373
-	RadioResourceConfigDedicated- DRB-REL(bid)	374
-	RadioResourceConfigDedicated-HO	374
-	RadioResourceConfigDedicatedSCell-r10-DEFAULT	374
-	RadioResourceConfigDedicated-SCell_AddMod	375

-	RadioResourceConfigDedicated-DC	375
-	RLC-Config-DRB-AM-RECONFIG	376
-	RLC-Config-DRB-UM-RECONFIG	376
-	RLC-Config-SRB-AM-RECONFIG	376
-	SCellToAddMod-r10-DEFAULT	377
-	SCellToRelease-r10-DEFAULT	377
-	SCG-Configuration-r12-DEFAULT	378
-	SchedulingRequest-Config-DEFAULT	381
-	SoundingRS-UL-ConfigCommon-DEFAULT	382
-	SoundingRS-UL-ConfigDedicated-DEFAULT	382
-	SoundingRS-UL-ConfigDedicatedAperiodic-r10-DEFAULT	383
-	SRB-ToAddModList-RECONFIG	383
-	TDD-Config-DEFAULT	383
-	TPC-PDCCH-Config-DEFAULT	384
-	UplinkPowerControlCommon-DEFAULT	384
-	UplinkPowerControlCommonSCell-r10-DEFAULT	385
-	UplinkPowerControlCommon-v1020-DEFAULT	385
-	UplinkPowerControlDedicated-DEFAULT	385
-	UplinkPowerControlDedicated-v1020-DEFAULT	386
-	UplinkPowerControlDedicated-v1130-DEFAULT	386
-	UplinkPowerControlDedicated-v1250-DEFAULT	386
-	UplinkPowerControlDedicatedSCell-r10-DEFAULT	387
-	RadioResourceConfigDedicated-DRB-Mod	387
-	RadioResourceConfigDedicated-PCell-PATTERN	387
-	OtherConfig-r9	388
-	WLAN-OffloadConfig-r12	389
-	EIMTA-MainConfig-r12-DEFAULT	390
-	EIMTA-MainConfigServCell-r12-DEFAULT	390
4.6.4	Security control information elements	391
-	SecurityConfigHO-DEFAULT	391
-	SecurityConfigSMC-DEFAULT	391
4.6.5	Mobility control information elements	392
-	MobilityControlInfo-HO	392
4.6.6	Measurement information elements	393
-	MeasConfig-DEFAULT	393
-	MeasGapConfig-GP1	393
-	MeasDS-Config-DEFAULT	394
-	MeasCSI-RS-Config-DEFAULT	394
-	MeasGapConfig-GP2	395
-	MeasObjectCDMA2000-GENERIC	395
-	ReportConfigToAddModList_DEFAULT	396
-	MeasIdToAddModList_DEFAULT	396
-	MeasObjectEUTRA-GENERIC	397
-	MeasObjectGERAN-GENERIC	398
-	MeasObjectUTRA-GENERIC	398
-	QuantityConfig-DEFAULT	399
-	ReportConfigEUTRA-A1	400
-	ReportConfigEUTRA-A2	400
-	ReportConfigEUTRA-A3	401
-	ReportConfigEUTRA-A4	402
-	ReportConfigEUTRA-A5	403
-	ReportConfigEUTRA-A6	404
-	ReportConfigEUTRA-PERIODICAL	404
-	ReportConfigInterRAT-B1-GERAN	405
-	ReportConfigInterRAT-B1-UTRA	406
-	ReportConfigInterRAT-B2-CDMA2000	407
-	ReportConfigInterRAT-B2-GERAN	408
-	ReportConfigInterRAT-B2-UTRA	409
-	ReportConfigInterRAT-PERIODICAL	410
-	ReportConfigEUTRA-C1	410
-	ReportConfigEUTRA-C2	411
-	ReportConfigEUTRA-PERIODICAL-CSI-RS	412

4.6.7	Other information elements	412
-	RRC-TransactionIdentifier-DL	412
-	RRC-TransactionIdentifier-UL	412
4.6.8	Channel-bandwidth-dependent parameters	412
4.7	Default NAS message and information element contents	413
4.7.1	Security protected NAS messages	413
4.7.2	Contents of EMM messages	415
-	ATTACH ACCEPT	415
-	ATTACH COMPLETE	418
-	ATTACH REJECT	418
-	ATTACH REQUEST	419
-	AUTHENTICATION FAILURE	420
-	AUTHENTICATION REJECT	420
-	AUTHENTICATION REQUEST	421
-	AUTHENTICATION RESPONSE	421
-	CS SERVICE NOTIFICATION	422
-	CONTROL PLANE SERVICE REQUEST	423
-	DETACH ACCEPT (UE originating detach)	423
-	DETACH ACCEPT (UE terminated detach)	424
-	DETACH REQUEST (UE originating detach)	424
-	DETACH REQUEST (UE terminated detach)	425
-	DOWNLINK NAS TRANSPORT	425
-	EMM INFORMATION	426
-	EMM STATUS	426
-	EXTENDED SERVICE REQUEST	427
-	GUTI REALLOCATION COMMAND	427
-	GUTI REALLOCATION COMPLETE	428
-	IDENTITY REQUEST	428
-	IDENTITY RESPONSE	428
-	SECURITY MODE COMMAND	429
-	SECURITY MODE COMPLETE	430
-	SECURITY MODE REJECT	430
-	SERVICE ACCEPT	430
-	SERVICE REJECT	431
-	SERVICE REQUEST	431
-	TRACKING AREA UPDATE ACCEPT	432
-	TRACKING AREA UPDATE COMPLETE	435
-	TRACKING AREA UPDATE REJECT	435
-	TRACKING AREA UPDATE REQUEST	436
-	UPLINK NAS TRANSPORT	437
4.7.3	Contents of ESM messages	437
-	ACTIVATE DEDICATED EPS BEARER CONTEXT ACCEPT	437
-	ACTIVATE DEDICATED EPS BEARER CONTEXT REJECT	438
-	ACTIVATE DEDICATED EPS BEARER CONTEXT REQUEST	439
-	ACTIVATE DEFAULT EPS BEARER CONTEXT ACCEPT	440
-	ACTIVATE DEFAULT EPS BEARER CONTEXT REJECT	440
-	ACTIVATE DEFAULT EPS BEARER CONTEXT REQUEST	441
-	BEARER RESOURCE ALLOCATION REJECT	446
-	BEARER RESOURCE ALLOCATION REQUEST	446
-	BEARER RESOURCE MODIFICATION REJECT	447
-	BEARER RESOURCE MODIFICATION REQUEST	448
-	DEACTIVATE EPS BEARER CONTEXT ACCEPT	449
-	DEACTIVATE EPS BEARER CONTEXT REQUEST	449
-	ESM DATA TRANSPORT	450
-	ESM DUMMY MESSAGE	450
-	ESM INFORMATION REQUEST	451
-	ESM INFORMATION RESPONSE	451
-	ESM STATUS	452
-	MODIFY EPS BEARER CONTEXT ACCEPT	452
-	MODIFY EPS BEARER CONTEXT REJECT	453
-	MODIFY EPS BEARER CONTEXT REQUEST	454
-	NOTIFICATION	455

-	PDN CONNECTIVITY REJECT	455
-	PDN CONNECTIVITY REQUEST	456
-	PDN DISCONNECT REJECT	457
-	PDN DISCONNECT REQUEST	457
4.7A	Default TC message and information element contents	457
-	ACTIVATE TEST MODE	458
-	ACTIVATE TEST MODE COMPLETE	458
-	CLOSE UE TEST LOOP	459
-	CLOSE UE TEST LOOP COMPLETE	461
-	DEACTIVATE TEST MODE	461
-	DEACTIVATE TEST MODE COMPLETE	462
-	OPEN UE TEST LOOP	462
-	OPEN UE TEST LOOP COMPLETE	462
-	UE TEST LOOP MODE C MBMS PACKET COUNTER REQUEST	462
-	UE TEST LOOP MODE C MBMS PACKET COUNTER RESPONSE	463
-	UE TEST LOOP PROSE PACKET COUNTER REQUEST	463
-	UE TEST LOOP PROSE PACKET COUNTER RESPONSE	463
-	UE TEST LOOP MODE F SCPTM PACKET COUNTER REQUEST	464
-	UE TEST LOOP MODE F SCPTM PACKET COUNTER RESPONSE	464
4.7B	Default UTRA message and information element contents	465
4.7B.1	UTRA RRC messages	465
-	HANDOVER TO UTRAN COMMAND	465
-	HANDOVER FROM UTRAN COMMAND	477
-	MEASUREMENT CONTROL	477
-	MEASUREMENT REPORT	479
-	PHYSICAL CHANNEL RECONFIGURATION	480
-	PHYSICAL CHANNEL RECONFIGURATION COMPLETE	481
-	RRC CONNECTION REQUEST	482
-	SECURITY MODE COMMAND	483
-	SECURITY MODE COMPLETE	483
-	UTRAN MOBILITY INFORMATION	483
-	UTRAN MOBILITY INFORMATION CONFIRM	483
4.7B.2	UTRA NAS messages	483
4.7C	Default DS-MIPv6 message and information element contents	493
4.7C.1	IKEv2 messages	493
-	IKEv2 IKE_SA_INIT Request	493
-	IKE_SA_INIT Response	496
-	IKE_AUTH_Request	497
-	IKE_AUTH Response	500
4.7C.2	Messages used to perform DS-MIPv6 registration and deregistration	504
-	Router Advertisement	504
-	Binding Update	505
-	Binding Acknowledgement	506
-	Binding Revocation Indication	507
-	Binding Revocation Acknowledgement	508
4.7D	Default GERAN message and information element contents	509
4.7D.1	GPRS message	509
-	PS HANDOVER COMMAND	509
4.7E	Default HTTP messages for communication with the ProSe Function	510
-	HTTP Request	510
-	HTTP Response	510
4.7F	Default ProSe messages	510
4.7F.1	ProSe discovery messages	510
-	DISCOVERY_REQUEST	510
-	DISCOVERY_RESPONSE	511
-	MATCH_REPORT	515
-	MATCH_REPORT_ACK	516
-	PC5_DISCOVERY	517
4.7F.2	Messages transmitted over the PC3ch interface	518
-	USAGE_INFORMATION_REPORT_LIST	518
-	USAGE_INFORMATION_REPORT_LIST_RESPONSE	520
4.7F.3	ProSe Direct Communication Messages	521

-	KEY_REQUEST	521
-	KEY_RESPONSE	522
-	MIKEY Key Delivery Message	523
-	MIKEY Verification Message	525
4.7G	Default IKEv2 message and information element contents	526
-	IKE_SA_INIT request	526
-	IKE_SA_INIT response	528
-	IKE_AUTH_request	528
-	IKE_AUTH response	529
4.7H	Default TLS message and information element contents	529
-	ClientHello	530
-	ServerHello	530
-	ServerKeyExchange	530
-	ServerHelloDone	530
-	ClientKeyExchange	530
-	ChangeCipherSpec	531
-	Finished	531
4.8	Reference radio bearer configurations	532
4.8.1	General	532
4.8.2	SRB and DRB parameters and combinations	532
4.8.2.1	SRB and DRB parameters	532
4.8.2.1.1	SRB configurations	532
4.8.2.1.2	DRB PDCP configurations	532
4.8.2.1.3	DRB RLC configurations	533
4.8.2.1.4	DRB Logical Channel configurations	534
4.8.2.1.5	MAC configurations	535
4.8.2.1.6	Physical Layer configurations	538
4.8.2.1.7	DRB configurations	548
4.8.2.2	SRB and DRB combinations	548
4.8.2.2.1	Combinations on DL-SCH and UL-SCH	548
4.8.3	UTRA reference radio parameters and combinations	548
4.8.4	GERAN reference PDP context parameters	549
4.9	Common test USIM, CSIM and ISIM parameters	549
4.9.1	General	549
4.9.1.1	Definitions	549
4.9.1.2	Definition of the test algorithm for authentication	549
4.9.1.2.1	Authentication and key derivation in the test USIM, CSIM and ISIM and SS	549
4.9.1.2.2	Generation of re-synchronization parameters in the USIM, CSIM and ISIM	549
4.9.1.2.3	Using the authentication test algorithm for UE conformance testing	549
4.9.2	Default parameters for the test USIM, CSIM and ISIM	549
4.9.3	Default settings for the Elementary Files (EFs)	549
4.9.3.1	Modified contents of the USIM Elementary Files and additional USIM Elements files at the DF ProSe level	550
4.9.3.2	Modified contents of the CSIM Elementary Files	555
5	Test environment for RF test	567
5.1	Requirements of test equipment	567
5.2	RF Reference system configurations	567
5.2.1	Common parameters for simulated E-UTRA cells	567
5.2.1.1	Combinations of system information blocks	567
5.2.1.2	Scheduling of system information blocks	568
5.2.1.3	Common contents of system information messages	568
5.2A	Generic RF procedures	569
5.2A.1	UE RF test states	570
5.2A.1A	Registered, Idle Mode, UE Test Mode Activated (State 2A-RF)	571
5.2A.1A.1	Initial conditions	571
5.2A.1A.2	Definition of system information messages	571
5.2A.1A.3	Procedure	572
5.2A.1A.4	Specific message contents	573
5.2A.1AA	Registered, Idle Mode, UE Test Mode Activated in cell supporting BL/CE UE (State 2A-RF-CE)	575
5.2A.1AA.1	Initial conditions	575
5.2A.1AA.2	Definition of system information messages	575

5.2A.1AA.3	Procedure	575
5.2A.1AA.4	Specific message contents	576
5.2A.2	Generic Default Radio Bearer Establishment, UE Test Mode Activated (State 3A-RF)	576
5.2A.2.1	Initial conditions	576
5.2A.2.2	Definition of system information messages	576
5.2A.2.3	Procedure	576
5.2A.2.4	Specific message contents	577
5.2A.2A	DC MCG/SCG Dedicated RB established, UE Test Mode Activate (State 3A-RF-DC1)	577
5.2A.2A.1	Initial conditions	577
5.2A.2A.2	Definition of system information messages	577
5.2A.2A.3	Procedure	577
5.2A.2A.4	Specific message contents	577
5.2A.2AA	Generic Default Radio Bearer Establishment, UE Test Mode Activated in cell supporting BL/CE UE (State 3A-RF-CE)	578
5.2A.2AA.1	Initial conditions	578
5.2A.2AA.2	Definition of system information messages	578
5.2A.2AA.3	Procedure	578
5.2A.2AA.4	Specific message contents	579
5.2A.2B	DC Split Default RB established, UE Test Mode Activate (State 3A-RF-DC2)	579
5.2A.2B.1	Initial conditions	579
5.2A.2B.2	Definition of system information messages	579
5.2A.2B.3	Procedure	579
5.2A.2B.4	Specific message contents	579
5.2A.3	Loopback Activation without looped data (State 4A-RF)	580
5.2A.3.1	Initial conditions	580
5.2A.3.2	Definition of system information messages	580
5.2A.3.3	Procedure	580
5.2A.3.4	Specific message contents	580
5.2A.3A	DC MCG/SCG DRBs Loopback Activation without looped data (State 4A-RF-DC1)	581
5.2A.3A.1	Initial conditions	581
5.2A.3A.2	Definition of system information messages	581
5.2A.3A.3	Procedure	581
5.2A.3A.4	Specific message contents	581
5.2A.3AA	Loopback Activation without looped data in cell supporting BL/CE UE (State 4A-RF-CE)	581
5.2A.3AA.1	Initial conditions	582
5.2A.3AA.2	Definition of system information messages	582
5.2A.3AA.3	Procedure	582
5.2A.3AA.4	Specific message contents	582
5.2A.3B	DC Split DRB Loopback Activation without looped data (State 4A-RF-DC2)	582
5.2A.3B.1	Initial conditions	582
5.2A.3B.2	Definition of system information messages	583
5.2A.3B.3	Procedure	583
5.2A.3B.4	Specific message contents	583
5.2A.4	Procedure to configure SCC	583
5.2A.4.1.	Specific message contents	583
5.2A.4.1.1	Exceptions for all CA tests	583
5.2A.4.1.2	Exceptions for UL CA tests	584
5.2A.5	Exceptions for feICIC tests	585
5.2A.5.1	Specific message contents	585
5.2A.5.1.1	Neighbour cell info for all feICIC test cases	585
5.2A.6	Exceptions for NAICS tests	586
5.2A.6.1	NAICS specific RRC Connection reconfiguration procedure	586
5.2A.6.1.1	Procedure	586
5.2A.6.1.1.1	Specific message contents	586
5.2A.6.2	Specific message contents	586
5.2A.6.2.1	RRCConnectionReconfiguration for setting up and releasing NAICS configuration in NAICS test cases	587
5.2A.7	Procedure to retrieve additional UE Capabilities for Rel-11 and higher UEs that support frequencyBandRetrieval_r11	588
5.2A.7.1	Initial conditions	588
5.2A.7.2	Definition of system information messages	589
5.2A.7.3	Procedure	589

5.2A.7.4	Specific message contents.....	589
5.3	Default RRC message and information elements contents.....	589
5.3.1	Radio resource control information elements	589
5.4	Default NAS message and information elements contents.....	591
5.5	Reference radio bearer configurations.....	591
5.5.1	SRB and DRB parameters	591
5.5.1.1	MAC configurations.....	591
5.5.1.2	Physical Layer configurations.....	592
5.5.1.3	SRB and DRB combinations.....	592
5.5.1.3.1	Combinations on DL-SCH and UL-SCH	592
6	Test environment for Signalling test	593
6.1	Requirements of test equipment	593
6.2	Reference test conditions.....	593
6.2.1	Physical channel allocations	593
6.2.1.1	Antennas	593
6.2.1.2	Downlink physical channels and physical signals.....	593
6.2.1.3	Mapping of downlink physical channels and signals to physical resources.....	594
6.2.1.4	Uplink physical channels and physical signals	594
6.2.1.5	Mapping of uplink physical channels and signals to physical resources.....	594
6.2.2	Signal levels.....	594
6.2.2.1	Downlink signal levels.....	594
6.2.2.2	Measurement accuracy and side conditions	595
6.2.2.3	Uplink signal levels.....	596
6.2.3	Default test frequencies	597
6.2.3.1	Test frequencies for signalling test.....	597
6.2.3.2	Test frequencies for CA signalling test	600
6.2.3.3	Test frequencies for ProSe signalling test	609
6.2.3.4	Test frequencies for MFBI frequency band priority adjustment signalling test	610
6.3	Reference system configurations.....	610
6.3.1	Default parameter specific for simulated cells.....	611
6.3.1.1	Intra-frequency neighbouring cell list in SIB4 for E-UTRA cells	611
6.3.1.2	Inter-frequency carrier frequency list in SIB5 for E-UTRA cells	611
6.3.1.3	UTRA carrier frequency list in SIB6 for E-UTRA cells	612
6.3.1.4	GERAN carrier frequency group list in SIB7 for E-UTRA cells	612
6.3.1.5	CDMA2000 HRPD carrier frequency list in SIB8 for E-UTRA cells	613
6.3.1.6	CDMA2000 1xRTT carrier frequency list in SIB8 for E-UTRA cells	613
6.3.1.7	E-UTRA carrier frequency list in SIB19 for UTRA cells	613
6.3.2	Default configurations for NAS test cases	614
6.3.2.1	Simulated network scenarios for NAS test cases	614
6.3.2.2	Simulated NAS cells	614
6.3.2.3	Broadcast system information	615
6.3.2.3.1	Intra-frequency neighbouring cell list in SIB4 for E-UTRA NAS cells	615
6.3.2.3.2	Inter-frequency carrier frequency list in SIB5 for E-UTRA NAS cells.....	616
6.3.3	Cell configurations.....	616
6.3.3.1	Full cell configuration	617
6.3.3.2	Minimum uplink cell configuration	617
6.3.3.3	Broadcast only cell configuration	617
6.3.3.3A	Virtual cell configuration	617
6.3.3.4	Application of different cell configurations	617
6.3.4	SCell configurations	618
6.4	Generic procedures.....	618
6.4.1	Initial UE states and setup procedures	618
6.4.1.1	Initial UE states and setup procedures	618
6.4.1.2	Dedicated Bearer Establishment (to state 5)	619
6.4.1.2.1	Initial conditions.....	619
6.4.1.2.2	Definition of system information messages.....	620
6.4.1.2.3	Procedure.....	620
6.4.1.2.4	Specific message contents	620
6.4.1.2A	DC MCG/SCG Dedicated Bearer Establishment (to state 5A)	620
6.4.1.2A.1	Initial conditions.....	620
6.4.1.2A.2	Definition of system information messages.....	620

6.4.1.2A.3	Procedure	620
6.4.1.2A.4	Specific message contents	621
6.4.1.2B	DC Split Dedicated Bearer Establishment (to state 5B)	621
6.4.1.2B.1	Initial conditions	621
6.4.1.2B.2	Definition of system information messages	621
6.4.1.2B.3	Procedure	621
6.4.1.2B.4	Specific message contents	622
6.4.1.3	Loopback Activation (to state 6)	622
6.4.1.3.1	Initial conditions	622
6.4.1.3.2	Definition of system information messages	622
6.4.1.3.3	Procedure	623
6.4.1.3.4	Specific message contents	623
6.4.1.3A	DC MCG/SCG DRB Loopback Activation (to state 6A)	623
6.4.1.3A.1	Initial conditions	623
6.4.1.3A.2	Definition of system information messages	623
6.4.1.3A.3	Procedure	623
6.4.1.3A.4	Specific message contents	623
6.4.1.3B	DC Split DRB Loopback Activation (to state 6B)	623
6.4.1.3B.1	Initial conditions	623
6.4.1.3B.2	Definition of system information messages	624
6.4.1.3B.3	Procedure	624
6.4.1.3B.4	Specific message contents	624
6.4.2	Test procedures	624
6.4.2.1	Introduction	624
6.4.2.2	Test procedure to check RRC_IDLE state	624
6.4.2.3	Test procedure to check RRC_CONNECTED state	625
6.4.2.4	Test procedure Paging (for NAS testing)	625
6.4.2.5	Test procedure for no response to paging (for NAS testing)	625
6.4.2.6	Test procedure to check that a dedicated EPS bearer context is active (for NAS testing)	626
6.4.2.7	Test procedure to check that UE is camped on a new E-UTRAN cell	626
6.4.2.7A	Test procedure to check that UE is camped on E-UTRAN cell upon mobility from another RAT	627
6.4.2.8	Test procedure to check that UE is camped on a new UTRAN cell	630
6.4.2.9	Test procedure to check that UE is camped on a new GERAN cell	631
6.4.2.10	Test procedure to check that UE performs tracking area updating procedure without ISR and security reconfiguration after successful completion of handover from UTRA	632
6.4.3	Reference test procedures for TTCN development	634
6.4.3.1	UE triggered establishment of a dedicated EPS bearer context	635
6.4.3.2	UE triggered establishment of a default EPS bearer context associated with an additional PDN	636
6.4.3.3	UE triggered modification of an EPS bearer context	638
6.4.3.4	UE triggered deletion of an EPS bearer context	639
6.4.3.5	UE triggered CS call	640
6.4.3.6	UE triggered MO SMS over SGs	641
6.4.3.7	CS fallback to UTRAN procedures (LAI of UTRAN cell same as the LAI received in combined Attach procedure in EUTRA cell)	641
6.4.3.7.1	CS fallback to UTRAN with redirection / MT call (PS bearers not established)	642
6.4.3.7.2	CS fallback to UTRAN with redirection / MO call (PS bearers not established)	643
6.4.3.7.3	CS fallback to UTRAN with redirection / MT call (PS bearer established)	644
6.4.3.7.4	CS fallback to UTRAN with redirection / MO call (PS bearer established)	644
6.4.3.7.5	CS fallback to UTRAN with Handover / MT call	645
6.4.3.7.5.1	Specific message contents	646
6.4.3.7.6	CS fallback to UTRAN with Handover / MO call	647
6.4.3.7.6.1	Specific message contents	648
6.4.3.7.7	CS fallback to UTRAN with Handover / emergency call	649
6.4.3.7.7.1	Specific message contents	650
6.4.3.8	CS fallback to GERAN procedures (LAI of GERAN cell same as the LAI received in combined Attach procedure in EUTRA cell)	650
6.4.3.8.1	CS fallback to GERAN with redirection or CCO / MT call (DTM not supported)	651
6.4.3.8.2	CS fallback to GERAN with redirection or CCO / MO call (DTM not supported)	652
6.4.3.8.3	CS fallback to GERAN with PS Handover / MT call (EDTM not supported)	652
6.4.3.8.4	CS fallback to GERAN with PS Handover / MO call (EDTM not supported)	652
6.4.3.8.5	CS fallback to GERAN with PS Handover / MT call (EDTM supported)	652
6.4.3.9	SRVCC Handover to UTRA	652

6.4.3.9.1	Specific message contents	653
6.4.3.10	Offload to WLAN	653
6.4.3.10.1	Specific message contents	654
6.4.3.11	Offload from WLAN.....	654
6.4.3.11.1	Specific message contents	655
6.4.3.12	Check UE does not offload to WLAN	655
6.4.3.12.1	Specific message contents	655
6.4.3.13	Check UE does not Offload to E-UTRAN	655
6.4.3.14	Procedure for UE initiated detach at non-switch-off	656
6.4.3.14.1	Specific message contents	656
6.4.3A	Test case postambles.....	656
6.4.3A.1	Introduction	656
6.4.3A.2	Reference end states.....	656
6.5	Default RRC message and information element contents	659
6.5.1	Measurement information elements.....	659
-	MeasConfig-DEFAULT	659
-	MeasGapConfig-GP1	660
-	MeasGapConfig-GP2	660
6.6	Default NAS message and information element contents	660
6.6.1	Reference default EPS bearer contexts	660
6.6.2	Reference dedicated EPS bearer contexts	661
6.6A	Default SMS over SGs message and information element contents.....	666
6.6A.1	CM-sublayer messages	666
-	CP-ACK.....	666
-	CP-DATA	666
6.6A.2	Short Message Relay Layer (SM-RL) messages	667
-	RP-ACK RPDU	667
-	RP-DATA RPDU.....	667
6.6A.3	Short Message Transfer Layer (SM-TL) messages	668
-	SMS-DELIVER	668
-	SMS-SUBMIT	668
6.6B	Reference radio bearer configurations.....	669
6.6B.1	SRB and DRB parameters and combinations	669
6.6B.1.1	SRB and DRB parameters.....	669
6.6B.1.1.1	Physical Layer configurations	669
6.7	Timer Tolerances.....	669
6.8	SideLink reference configuration	670
6.8.1	Reference configuration for Direct Communication.....	670
6.8.1.1	ProSe Direct Communication <i>Preconfiguration</i> for out-of-network coverage operation	670
7	Test environment for RRM tests	673
7.1	Requirements of <i>test</i> equipment	673
7.2	RRM Reference system configurations.....	673
7.2.1	Common parameters for simulated E-UTRA cells	673
7.2.1.1	Combinations of system information blocks.....	673
7.2.1.2	Scheduling of system information blocks	673
7.2.1.3	Common contents of system information messages	673
7.2.2	Common parameters for simulated GERAN cells	675
7.2.2.1	Mapping of GERAN cells	675
7.2A	Generic RRM procedures.....	676
7.2A.1	UE RRM test states.....	676
7.2A.2	UE Registration, UE Test Mode Activated (State 2A-RF)	676
7.2A.2A	UE Registration, UE Test Mode Activated in cell supporting BL/CE UE (State 2A-RF-CE)	676
7.2A.3	Generic Default Radio Bearer Establishment, UE Test Mode Activated (State 3A-RF).....	677
7.2A.3A	DC MCG/SCG Dedicated RB established, UE Test Mode Activated (State 3A-RF-DC1).....	677
7.2A.3AA	Generic Default Radio Bearer Establishment, UE Test Mode Activated in cell supporting BL/CE UE (State 3A-RF-CE)	677
7.2A.3B	DC Split Default RB established, UE Test Mode Activated (State 3A-RF-DC2)	677
7.2A.4	Generic Default Radio Bearer Establishment, UE Test Mode Activated, pre-registration on HRPD (State 3B-RF).....	677
7.2A.4.1	Initial conditions	677
7.2A.4.2	Definition of system information messages	677

7.2A.4.3	Procedure	677
7.2A.4.4	Specific message contents	677
7.2A.5	Procedure to configure SCC	678
7.2A.6	Exceptions for feICIC tests.....	678
7.2B	Other generic RRM procedures.....	678
7.2B.1	Tracking area updating procedure.....	678
7.3	Default RRC message and information elements contents.....	680
7.3.1	Contents of RRC messages	680
7.3.2	Radio resource control information elements	680
7.3.3	Measurement information elements.....	681
7.3A	Default UTRA message and information element contents	681
7.3A.1	UTRA RRC messages	681
7.4	Default NAS message and information elements contents.....	682
7.5	Reference radio bearer configurations.....	682
7.5.1	SRB and DRB parameters	682
7.5.1.1	MAC configurations.....	682
8	NB-IoT test environment.....	683
8.1	NB-IoT Common test environment.....	683
8.1.1	NB-IoT Environmental conditions	683
8.1.2	NB-IoT Common requirements of test equipment.....	683
8.1.3	NB-IoT Reference test conditions	683
8.1.3.1	NB-IoT Test frequencies	683
8.1.3.1.1	NB-IoT FDD Mode Test frequencies	684
8.1.3.2	NB-IoT Radio conditions	692
8.1.3.2.1	NB-IoT Normal propagation condition	692
8.1.3.3	NB-IoT Physical channel allocations	692
8.1.3.3.1	NB-IoT Antennas	692
8.1.3.3.2	NB-IoT Downlink physical channels and physical signals	692
8.1.3.3.3	NB-IoT Mapping of downlink physical channels and signals to physical resources.....	693
8.1.3.3.4	NB-IoT Uplink physical channels and physical signals	695
8.1.3.3.5	NB-IoT Mapping of uplink physical channels and signals to physical resources	695
8.1.3.4	NB-IoT Signal levels.....	695
8.1.3.4.1	NB-IoT Downlink signal levels.....	695
8.1.3.4.2	NB-IoT Uplink signal levels.....	695
8.1.3.5	NB-IoT Standard test signals	696
8.1.3.5.1	NB-IoT Downlink test signals	696
8.1.3.5.2	NB-IoT Uplink test signals.....	696
8.1.3.6	NB-IoT Physical layer parameters	696
8.1.3.6.1	NB-IoT Downlink physical layer parameters	696
8.1.4	NB-IoT Reference system configurations.....	697
8.1.4.1	NB-IoT Simulated network scenarios	697
8.1.4.1.1	NB-IoT Single cell network scenarios.....	698
8.1.4.1.2	NB-IoT single mode multi cell network scenarios	698
8.1.4.2	NB-IoT Simulated cells.....	698
8.1.4.3	NB-IoT Common parameters for simulated cells	701
8.1.4.3.1	NB-IoT Common configurations of system information blocks	702
8.1.4.3.1.1	NB-IoT Combinations of system information blocks	702
8.1.4.3.1.2	NB-IoT Scheduling of system information blocks	702
8.1.4.3.2	NB-IoT Common contents of system information messages	703
-	MasterInformationBlock-NB.....	703
-	SystemInformation-NB	703
-	SystemInformationBlockType1-NB.....	705
8.1.4.3.3	NB-IoT Common contents of system information blocks	706
-	SystemInformationBlockType2-NB.....	706
-	SystemInformationBlockType3-NB.....	707
-	SystemInformationBlockType4-NB.....	707
-	SystemInformationBlockType5-NB.....	708
-	SystemInformationBlockType14-NB.....	709
-	SystemInformationBlockType16-NB.....	710
8.1.5	NB-IoT Generic procedures.....	710
8.1.5.0	General	710

8.1.5.1	NB-IoT UE test states	710
8.1.5.2	NB-IoT UE Attach, Connected mode (State 2-NB)	711
8.1.5.2.0	General	711
8.1.5.2.1	Initial conditions	712
8.1.5.2.2	Definition of system information messages	712
8.1.5.2.3	Procedure	713
8.1.5.2.4	Specific message contents	715
8.1.5.2A	NB-IoT UE Attach, Connected mode, UE Test Mode Activated (State 2A-NB)	715
8.1.5.2A.0	General	715
8.1.5.2A.1	Initial conditions	715
8.1.5.2A.2	Definition of system information messages	716
8.1.5.2A.3	Procedure	716
8.1.5.2A.4	Specific message contents	716
8.1.5.2B	NB-IoT UE Attach, Connected Mode, UE Test Loopback Activated (State 2B-NB)	716
8.1.5.2B.1	Initial conditions	716
8.1.5.2B.2	Definition of system information messages	716
8.1.5.2B.3	Procedure	717
8.1.5.2B.4	Specific message contents	717
8.1.5.3	NB-IoT UE Registered, Idle Mode (State 3-NB)	717
8.1.5.3.1	Initial conditions	717
8.1.5.3.2	Definition of system information messages	718
8.1.5.3.3	Procedure	718
8.1.5.3.4	Specific message contents	718
8.1.5.3A	NB-IoT UE Registered, Idle Mode, UE Test Mode Activated (State 3A-NB)	718
8.1.5.3A.1	Initial conditions	718
8.1.5.3A.2	Definition of system information messages	718
8.1.5.3A.3	Procedure	719
8.1.5.3A.4	Specific message contents	719
8.1.5.4	Void	719
8.1.5A	Other generic procedures	719
8.1.5A.1	Procedure for IP address allocation in the CP CIoT	719
8.1.5A.2	Test procedure to check UE response to Paging for Control Plane CIoT MT access	720
8.1.5A.2.1	Initial conditions	720
8.1.5A.2.2	Definition of system information messages	720
8.1.5A.2.3	Procedure	721
8.1.5A.2.4	Specific message contents	722
8.1.5A.3	Test procedure to check UE initiation of Control Plane CIoT MO user data transfer non-SMS transport	722
8.1.5A.3.1	Initial conditions	722
8.1.5A.3.2	Definition of system information messages	723
8.1.5A.3.3	Procedure	724
8.1.5A.3.4	Specific message contents	725
8.1.5A.3A	Test procedure to check UE initiation of Control Plane CIoT MO user data transfer SMS transport	726
8.1.5A.3A.1	Initial conditions	726
8.1.5A.3A.2	Definition of system information messages	726
8.1.5A.3A.3	Procedure	727
8.1.5A.3A.4	Specific message contents	728
8.1.5A.4	Test procedure to check release of PDN connectivity before leaving RRC-CONNECTED for attach without PDN	729
8.1.5A.4.1	Initial conditions	729
8.1.5A.4.2	Definition of system information messages	729
8.1.5A.4.3	Procedure	730
8.1.5A.4.4	Specific message contents	730
8.1.5A.5	Test procedure to check that NB-IoT UE is camped on a new NB-IOT cell	730
8.1.6	NB-IoT Default RRC message and information elements contents	731
8.1.6.1	NB-IoT Contents of RRC messages	731
-	<i>DLInformationTransfer-NB</i>	731
-	<i>Paging-NB</i>	732
-	<i>RRCConnectionReconfiguration-NB</i>	732
-	<i>RRCConnectionReconfigurationComplete-NB</i>	733
-	<i>RRCConnectionReestablishment-NB</i>	733

-	<i>RRConnectionReestablishmentComplete-NB</i>	733
-	<i>RRConnectionReestablishmentRequest-NB</i>	734
-	<i>RRConnectionReject-NB</i>	734
-	<i>RRConnectionRelease-NB</i>	735
-	<i>RRConnectionRequest-NB</i>	735
-	<i>RRConnectionResume-NB</i>	736
-	<i>RRConnectionResumeComplete-NB</i>	736
-	<i>RRConnectionResumeRequest-NB</i>	737
-	<i>RRConnectionSetup-NB</i>	737
-	<i>RRConnectionSetupComplete-NB</i>	738
-	<i>UECapabilityEnquiry-NB</i>	738
-	<i>UECapabilityInformation-NB</i>	739
-	<i>ULInformationTransfer-NB</i>	740
8.1.6.2	NB-IoT System information blocks	740
8.1.6.3	NB-IoT Radio resource control information elements	740
-	BCCH-Config-NB-DEFAULT	740
-	PCCH-Config-NB-DEFAULT	740
-	NPDCCCH-ConfigDedicated-NB-DEFAULT	741
-	NPDSCH-ConfigCommon-NB-DEFAULT	741
-	NPRACH-ConfigSIB-NB-DEFAULT	741
-	NPUSCH-ConfigCommon-NB-DEFAULT	742
-	NPUSCH-ConfigDedicated-NB-DEFAULT	742
-	RACH-ConfigCommon-NB-DEFAULT	742
-	RadioResourceConfigCommonSIB-NB-DEFAULT	743
-	RadioResourceConfigDedicated-NB-SRB	743
-	RadioResourceConfigDedicated-NB-DRB(n)	744
-	RadioResourceConfigDedicated-NB-DRB-ADD(bid)	744
-	RadioResourceConfigDedicated-NB-DRB-REL(bid)	744
-	RLC-Config-NB-SRB-RECONFIG	745
-	SRB-ToAddModList-NB-RECONFIG	745
-	UplinkPowerControlCommon-NB-DEFAULT	745
-	UplinkPowerControlDedicated-NB-DEFAULT	745
-	RadioResourceConfigDedicated-NB-DRB-Mod	746
8.1.6.4	NB-IoT Security control information elements	746
8.1.6.5	NB-IoT Other information elements	746
-	RRC-TransactionIdentifier-DL	746
-	RRC-TransactionIdentifier-UL	746
8.1.7	NB-IoT Default NAS message and information element contents	746
8.1.7A	NB-IoT Default TC message and information element contents	746
8.1.8	NB-IoT Reference radio bearer configurations	747
8.1.8.1	General	747
8.1.8.2	NB-IoT SRB and DRB parameters and combinations	747
8.1.8.2.1	NB-IoT SRB and DRB parameters	747
8.1.9	NB-IoT Common test USIM parameters	749
8.1.9.1	General	749
8.2	NB-IoT Test environment for RF test	749
8.2.1	NB-IoT Requirements of test equipment	749
8.2.2	NB-IoT RF Reference system configurations	750
8.2.2.1	NB-IoT Common parameters for simulated E-UTRA cells	750
8.2.2.1.1	NB-IoT Combinations of system information blocks	750
8.2.2.1.2	NB-IoT Scheduling of system information blocks	750
8.2.2.1.3	NB-IoT Common contents of system information messages	750
8.2.2A	NB-IoT Generic RF procedures	750
8.2.3	NB-IoT Default RRC message and information elements contents	750
8.2.3.1	NB-IoT Radio resource control information elements	750
8.2.4	NB-IoT Default NAS message and information elements contents	750
8.2.5	NB-IoT Reference radio bearer configurations	750
8.2.5.1	NB-IoT SRB and DRB parameters	750
8.3	NB-IoT Test environment for Signalling test	751
8.3.1	NB-IoT Requirements of test equipment	751
8.3.2	NB-IoT Reference test conditions	751
8.3.2.1	NB-IoT Physical channel allocations	751

8.3.2.2	NB-IoT Signal levels.....	751
8.3.2.2.1	NB-IoT Downlink signal levels.....	751
8.3.2.3	NB-IoT Default test frequencies	752
8.3.2.3.1	NB-IoT Test frequencies for signalling test	752
8.3.3	NB-IoT Reference system configurations.....	753
8.3.3.1	NB-IoT Default parameters specific for simulated cells	753
8.3.3.1.1	Intra-frequency neighbouring cell list in SIB4-NB for NB-IoT cells.....	753
8.3.3.1.2	Inter-frequency carrier frequency list in SIB5-NB for NB-IoT cells.....	754
8.3.3.2	NB-IoT Default configurations for NAS test cases.....	755
8.3.3.3	NB-IoT Cell configurations	755
8.3.4	NB-IoT Generic signalling procedures	755
8.3.4.1	NB-IoT Initial UE states and setup procedures	755
8.3.4.2	NB-IoT Reference procedures and test procedures for TTCN development	755
8.3.4.3	NB-IoT Test case postambles for TTCN development	755
8.3.5	NB-IoT Default RRC message and information element contents	755
8.3.6	NB-IoT Default NAS message and information element contents	755
8.3.7	NB-IoT Timer tolerances.....	755
8.4	NB-IOT Test environment for RRM tests	756
8.4.1	NB-IoT Requirements of test equipment	756
8.4.2	NB-IoT RRM Reference system configurations.....	756
8.4.2.1	NB-IoT Common parameters for simulated NB-IoT cells	756
8.4.2.1.1	NB-IoT Combinations of system information blocks.....	756
8.4.2.1.2	NB-IoT Scheduling of system information blocks	756
8.4.2.1.3	NB-IoT Common contents of system information messages	756
8.4.2A	NB-IoT Generic RRM procedures.....	756
8.4.3	NB-IoT Default RRC message and information elements contents.....	757
8.4.3.1	NB-IoT Radio resource control information elements	757
8.4.4	NB-IoT Default NAS message and information elements contents.....	757
8.4.5	NB-IoT Reference radio bearer configurations.....	757
8.4.5.1	NB-IoT SRB and DRB parameters	757
Annex A (informative):	Connection Diagrams	758
Annex B (informative):	Change history	870
History		900

Foreword

This Technical Specification has been produced by the 3rd Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

x the first digit:

- 1 presented to TSG for information;
- 2 presented to TSG for approval;
- 3 or greater indicates TSG approved document under change control.

y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.

z the third digit is incremented when editorial only changes have been incorporated in the document.

Introduction

The definition of the Conformance Tests for UE in E-UTRAN will be a complex task as the complete test suite covers RF, EMC and Protocol aspects of the UE.

Each test requires a Test Environment to be defined in which the UE has to operate to defined standards, constraints and performance. The overall task can be simplified if there are a number of well defined and agreed Common Test Environments where every one can be used for a number of tests. Hence the present document defines testing conditions that are common to several tests avoiding the need to duplicate the same information for every single test.

The present document defines default values for a variety of common areas. Where values are not specified in test cases, the defaults in the present document will apply. If specified, the test case values will take precedence.

1 Scope

The present document contains definitions of reference conditions and test signals, default parameters, reference radio bearer configurations used in radio bearer interoperability testing, common radio bearer configurations for other test purposes, common requirements for test equipment and generic set-up procedures for use in conformance tests for the 3rd Generation E-UTRAN User Equipment (UE).

2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document in the same Release as the present document unless the context in which the reference is made suggests a different Release is relevant (information on the applicable release in a particular context can be found in e.g. test case title, description or applicability, message description or content).

- [1] 3GPP TR 21.905: "Vocabulary for 3GPP Specifications".
- [2] 3GPP TS 23.003: "Numbering, addressing and identification".
- [3] 3GPP TS 23.122: "Non-Access-Stratum functions related to Mobile Station (MS) in idle mode".
- [4] 3GPP TS 24.008: "Mobile radio interface Layer 3 specification; Core network protocols; Stage 3".
- [5] 3GPP TS 34.108: "Common Test Environments for User Equipment (UE); Conformance testing".
- [6] 3GPP TS 34.109: "Terminal logical test interface; Special conformance testing functions".
- [7] 3GPP TS 34.123-1: "User Equipment (UE) conformance specification; Part 1: Protocol conformance specification".
- [8] 3GPP TS 34.123-2: "User Equipment (UE) conformance specification; Part 2: Implementation conformance statement (ICS) specification".
- [9] 3GPP TS 34.123-3: "User Equipment (UE) conformance specification; Part 3: Abstract test suites (ATSS)".
- [10] 3GPP TS 36.300: "Evolved Universal Terrestrial Radio Access (E-UTRA) and Evolved Universal Terrestrial Radio Access Network (E-UTRAN); Overall description; Stage 2".
- [11] 3GPP TS 36.302: "Evolved Universal Terrestrial Radio Access (E-UTRA); Services provided by the physical layer".
- [12] 3GPP TS 36.304: "Evolved Universal Terrestrial Radio Access (E-UTRA); User Equipment (UE) procedures in idle mode".
- [13] 3GPP TS 36.306: "Evolved Universal Terrestrial Radio Access (E-UTRA); User Equipment (UE) radio access capabilities".
- [14] 3GPP TS 36.321: "Evolved Universal Terrestrial Radio Access (E-UTRA); Medium Access Control (MAC) protocol specification".
- [15] 3GPP TS 36.322: "Evolved Universal Terrestrial Radio Access (E-UTRA); Radio Link Control (RLC) protocol specification".